

Gebrauchsanweisung für 14 Tage Tischuhr

Diese Uhr wurde nach traditioneller Uhrmacherkunst gefertigt. Sie hat ein 14-Tage-Federzug-Pendelwerk und schlägt zu jeder vollen Stunde jeweils ein Schlag auf Glocke.

Aufstellen der Uhr

Die Uhr vorsichtig aus der Verpackung nehmen. Stellen Sie die Uhr an den ausgewählten Platz. Pendel aus der Verpackung lösen und in die Öse der Pendelverlängerung einhängen.

Aufziehen der Uhr

Diese Uhr läuft voll aufgezogen mindestens 14 Tage. Die Uhr wird mit beiliegendem Aufzugsschlüssel aufgezogen. Stecken Sie dazu den Aufzugsschlüssel auf den Vierkant in der unteren Hälfte der Rückseite des Uhrwerkes und drehen ihn im Uhrzeigersinn bis zum Anschlag.

Starten des Uhrwerkes

Die Pendellinse aus dem Lot führen und loslassen. Das Pendel schwingt und es reguliert sich selbstständig auf die richtige Schwingungsweite ein.

Stellen des Uhrwerkes

Minutenzeiger nur im Uhrzeigersinn drehen bis die Uhrzeit stimmt.

Regulieren der Ganggenauigkeit

Über die Pendelmutter unterhalb der Pendellinse wird die Uhr reguliert. Drehen der Pendelmutter und damit der Pendelscheibe nach oben macht die Uhr schneller, nach unten wird die Uhr langsamer. Eine Umdrehung entspricht dabei 3 min/Tag.

Operating Instructions for 14 days Table Clock

This clock is made with traditional clock-makers skills. It has 14 days pendulum movement with a passing strike on the hour.

To position the Clock

Lift the clock from its packing carefully. Choose a suitable dry and clean position for the clock. Loosen the pendulum from the polystyrene packing and take elastic rubber out of the pendulum extension. Hold pendulum extension with one hand and engage the pendulum hook into the eye of the pendulum extension. Attention: Don't twist or drag pendulum arm with hard strength, to avoid breakage of upper suspension

To set the Time

Turn the minute hand clockwise only until the time is correct.

To wind up the Clock

This clock runs approximately 14 days. Insert key into square at the bottom half of the back side of the movement and turn clockwise until there is a solid stop. If necessary swing the pendulum as before.

To start the Movement

Hold the pendulum bob from the vertical and release. The pendulum swings and regulates the correct rhythm independently.

Regulating the Clock

Your clock can be regulated accurately personally by sliding the pendulum bob up or down the pendulum rod. Sliding it up makes the clock faster and sliding it down makes the clock slower. If the clock does not keep proper time, please adjust the pendulum bob by turning the rating nut to the right (pendulum bob moves up). Turning rating nut to the left (pendulum bob moves down). One turn of the regulating nut corresponds to a time difference of approx. 3 minutes per day.