Bedienungsanleitung für die Finger-Touch-Herzfrequenzüberwachungsuhr

Inhaltsverzeichnis

1. Einführung 01
2. Tastenfunktionen 01
3. Hauptmenü-Einstellungen 01
4. Sportmodus 02
5. Herzfrequenzmessung 03
6. Schlafüberwachung 04
7. Fitness-Erinnerung 04
8. Verbindung mit Smartphone 04
9. Fehlerbehebung 05

1. Einführung

Vielen Dank für den Kauf dieses Produkts. Bitte lesen Sie diese Bedienungsanleitung vor der ersten Verwendung sorgfältig durch, um sicherzustellen, dass Sie alle Funktionen und Vorsichtsmaßnahmen kennen. Bewahren Sie diese Anleitung zum späteren Nachschlagen auf.

2. Tastenfunktionen

- **Kurzer Druck:** Zur Navigation durch Menüoptionen oder zum Ändern von Einstellungen.
- **Langer Druck:** Zum Bestätigen einer Auswahl oder zum Eingeben des Einstellungsmodus.
- **Zurück-Taste:** Zum Zurückkehren zum vorherigen Menü oder zum Abbrechen einer Aktion.

3. Hauptmenü-Einstellungen

- Einstellen von Uhrzeit, Datum, Kalender, Alter, Größe, Gewicht, Schritte, Distanz, Kalorien
- Einstellen von Einheiten (Metrisch/Imperial)
- Einstellen von Benutzerprofil (Geschlecht, Alter, Größe, Gewicht, Schrittlänge)
- Einstellen von Alarmen (Wecker, Sitzerinnerung, Trinkerinnerung)
- Einstellen von Benachrichtigungen (Anrufe, Nachrichten, Apps)
- Einstellen von Hintergrundbeleuchtung (Helligkeit, Timeout)
- Einstellen von Sprache
- Einstellen von Bluetooth (Verbindung, Kopplung)
- Einstellen von Herzfrequenzüberwachung (Ein/Aus, Intervall)
- Einstellen von Schlafüberwachung (Ein/Aus, Ziel)
- Einstellen von Sportmodi (Laufen, Radfahren, Schwimmen, etc.)
- Einstellen von Fitness-Erinnerungen (Ein/Aus, Intervall)
- Einstellen von Display-Stil (Analog, Digital)
- Einstellen von Hintergrundbild
- Einstellen von Sperrbildschirm
- Einstellen von Werkseinstellungen zurücksetzen
- Einstellen von Software-Update
- Einstellen von Geräteinformationen (Modell, Seriennummer, Softwareversion)

4. Sportmodus

- Verwenden Sie die Tasten, um den Sportmodus auszuwählen (z. B. Laufen, Radfahren, Schwimmen).
- Drücken Sie die Bestätigungstaste, um den Sportmodus zu starten.
- Während des Trainings können Sie die Zurück-Taste drücken, um zwischen verschiedenen Anzeigen zu wechseln (z. B. Herzfrequenz, Zeit, Distanz, Kalorien).
- Drücken Sie die Bestätigungstaste lange, um das Training zu beenden.

5. Herzfrequenzmessung

- Tragen Sie die Uhr am Handgelenk, sodass der Herzfrequenzsensor Ihre Haut berührt.
- Die Herzfrequenz wird automatisch gemessen und angezeigt.
- Sie können die Herzfrequenzüberwachung in den Einstellungen ein- oder ausschalten.

6. Schlafüberwachung

- Die Uhr überwacht automatisch Ihre Schlafqualität, einschließlich Tiefschlaf, Leichtschlaf und Wachzeiten.
- Sie können Ihr Schlafziel in den Einstellungen festlegen.
- Am nächsten Morgen können Sie Ihre Schlafdaten in der App anzeigen.

7. Fitness-Erinnerung

- Sie können Erinnerungen für Sitzen, Trinken oder andere Aktivitäten einstellen.
- Die Uhr vibriert, um Sie daran zu erinnern, aufzustehen, sich zu bewegen oder Wasser zu trinken.

8. Verbindung mit Smartphone

- Laden Sie die Fitness-Tracker-App aus dem App Store herunter.
- Aktivieren Sie Bluetooth auf Ihrem Smartphone und öffnen Sie die App.
- Folgen Sie den Anweisungen in der App, um Ihre Uhr zu koppeln.
- Synchronisieren Sie Ihre Daten, um Ihre Fortschritte zu verfolgen.

9. Fehlerbehebung

- **Uhr lässt sich nicht einschalten:** Laden Sie die Uhr mindestens 30 Minuten lang auf.
- **Bluetooth-Verbindung fehlgeschlagen:** Stellen Sie sicher, dass Bluetooth aktiviert ist und die Uhr sich in der Nähe befindet.
- **Herzfrequenz wird nicht gemessen:** Stellen Sie sicher, dass der Sensor Ihre Haut berührt.
- **Schlafdaten werden nicht synchronisiert:** Überprüfen Sie die Bluetooth-Verbindung.

1 Bedienungsanleitung

1.1 Übersicht über Tastenfunktionen

Taste	Funktion
Zurück-Taste	Kurzer Druck: Zurück zum vorherigen Menü Langer Druck: Zurück zum Hauptmenü
Auf-Taste	Kurzer Druck: Nach oben navigieren, Wert erhöhen Langer Druck: Schnelles Erhöhen des Wertes
Ab-Taste	Kurzer Druck: Nach unten navigieren, Wert verringern Langer Druck: Schnelles Verringern des Wertes
Bestätigungstaste	Kurzer Druck: Auswahl bestätigen, Menü aufrufen Langer Druck: Einstellungsmodus aufrufen, Einstellungen speichern

1.2 Bedienungsanleitung

1. Drücken Sie die Zurück-Taste, um zurückzukehren.
2. Drücken Sie die Auf- oder Ab-Taste, um durch die Menüoptionen zu navigieren.
3. Drücken Sie die Bestätigungstaste, um eine Auswahl zu bestätigen.
4. Drücken Sie die Bestätigungstaste lange, um den Einstellungsmodus aufzurufen.
5. Drücken Sie die Auf- oder Ab-Taste, um Werte zu ändern.
6. Drücken Sie die Bestätigungstaste, um Einstellungen zu speichern.

1.3 Ladeanleitung

1. Schließen Sie das Ladekabel an den Ladeanschluss der Uhr an.
2. Schließen Sie das andere Ende des Ladekabels an eine USB-Stromquelle an.
3. Die Uhr beginnt zu laden. Während des Ladevorgangs wird ein Ladesymbol angezeigt.
4. Laden Sie die Uhr vollständig auf, bevor Sie sie zum ersten Mal verwenden.

1.4 Bluetooth-Verbindung

1. Laden Sie die Fitness-Tracker-App aus dem App Store herunter.
2. Aktivieren Sie Bluetooth auf Ihrem Smartphone und öffnen Sie die App.
3. Folgen Sie den Anweisungen in der App, um Ihre Uhr zu koppeln.
4. Synchronisieren Sie Ihre Daten, um Ihre Fortschritte zu verfolgen.

1.5 Fehlerbehebung

- **Uhr lässt sich nicht einschalten:** Laden Sie die Uhr mindestens 30 Minuten lang auf.
- **Bluetooth-Verbindung fehlgeschlagen:** Stellen Sie sicher, dass Bluetooth aktiviert ist und die Uhr sich in der Nähe befindet.
- **Herzfrequenz wird nicht gemessen:** Stellen Sie sicher, dass der Sensor Ihre Haut berührt.
- **Schlafdaten werden nicht synchronisiert:** Überprüfen Sie die Bluetooth-Verbindung.

2.0 Home Screen

Choose Your Style and Wear as Desired

2.1 Navigation Functions

- Short press the Up button to navigate through the menu options.
- Short press the Down button to navigate through the menu options.
- Short press the Confirm button to enter the selected menu or confirm the setting.
- Long press the Back button to return to the previous menu.

2.2 Setting Functions

- Short press the Up button to increase the value.
- Short press the Down button to decrease the value.
- Short press the Confirm button to save the setting.
- Long press the Back button to cancel the setting.

2.3 Charging

1. Connect the charging cable to the charging port on the watch.
2. Connect the other end of the charging cable to a USB power source.
3. The watch will start charging. A charging icon will be displayed.
4. Fully charge the watch before first use.

2.4 Bluetooth Connection

1. Download the Fitness Tracker app from the App Store.
2. Enable Bluetooth on your phone and open the app.
3. Follow the instructions in the app to pair your watch.
4. Sync your data to track your progress.

2.5 Troubleshooting

- **Watch won't turn on:** Charge the watch for at least 30 minutes.
- **Bluetooth connection failed:** Ensure Bluetooth is enabled and the watch is nearby.
- **Heart rate not measuring:** Make sure the sensor is in contact with your skin.
- **Sleep data not syncing:** Check the Bluetooth connection.

3 Hauptmenü-Einstellungen

Drücken Sie die Bestätigungstaste lange, um das Hauptmenü aufzurufen. Verwenden Sie die Auf- und Ab-Tasten, um durch die Optionen zu navigieren, und die Bestätigungstaste, um eine Auswahl zu treffen.

- **Heute Schritte:** Aktuelle Schrittzahl des Tages anzeigen
- **Kalorien:** Verbrannte Kalorien anzeigen
- **Herzfrequenz:** Herzfrequenzmessung starten
- **Schlaf:** Schlafdaten anzeigen
- **Sport:** Sportmodus auswählen
- **Einstellungen:** Uhr einstellen

3.1 Heute Schritte

- Drücken Sie die Auf- oder Ab-Taste, um Heute Schritte auszuwählen.
- Drücken Sie die Bestätigungstaste, um die aktuelle Schrittzahl des Tages anzuzeigen.

3.2 Kalorien

- Drücken Sie die Auf- oder Ab-Taste, um Kalorien auszuwählen.
- Drücken Sie die Bestätigungstaste, um die verbrannten Kalorien anzuzeigen.

3.3 Herzfrequenz

- Drücken Sie die Auf- oder Ab-Taste, um Herzfrequenz auszuwählen.
- Drücken Sie die Bestätigungstaste, um die Herzfrequenzmessung zu starten.

3.4 Schlaf

- Drücken Sie die Auf- oder Ab-Taste, um Schlaf auszuwählen.
- Drücken Sie die Bestätigungstaste, um Ihre Schlafdaten anzuzeigen.

3.5 Sport

- Drücken Sie die Auf- oder Ab-Taste, um Sport auszuwählen.
- Drücken Sie die Bestätigungstaste, um den Sportmodus auszuwählen.

3.6 Einstellungen

- Drücken Sie die Auf- oder Ab-Taste, um Einstellungen auszuwählen.
- Drücken Sie die Bestätigungstaste, um die Einstellungen aufzurufen.

4 Sportmodus

Verwenden Sie die Tasten, um den Sportmodus auszuwählen (z. B. Laufen, Radfahren, Schwimmen).

Drücken Sie die Bestätigungstaste, um den Sportmodus zu starten.

Während des Trainings können Sie die Zurück-Taste drücken, um zwischen verschiedenen Anzeigen zu wechseln (z. B. Herzfrequenz, Zeit, Distanz, Kalorien).

Drücken Sie die Bestätigungstaste lange, um das Training zu beenden.

5 Herzfrequenzmessung

Tragen Sie die Uhr am Handgelenk, sodass der Herzfrequenzsensor Ihre Haut berührt.

Die Herzfrequenz wird automatisch gemessen und angezeigt.

Sie können die Herzfrequenzüberwachung in den Einstellungen ein- oder ausschalten.

6 Schlafüberwachung

Die Uhr überwacht automatisch Ihre Schlafqualität, einschließlich Tiefschlaf, Leichtschlaf und Wachzeiten.

Sie können Ihr Schlafziel in den Einstellungen festlegen.

Am nächsten Morgen können Sie Ihre Schlafdaten in der App anzeigen.

7 Fitness-Erinnerung

Sie können Erinnerungen für Sitzen, Trinken oder andere Aktivitäten einstellen.

Die Uhr vibriert, um Sie daran zu erinnern, aufzustehen, sich zu bewegen oder Wasser zu trinken.

8 Verbindung mit Smartphone

Laden Sie die Fitness-Tracker-App aus dem App Store herunter.

Aktivieren Sie Bluetooth auf Ihrem Smartphone und öffnen Sie die App.

Folgen Sie den Anweisungen in der App, um Ihre Uhr zu koppeln.

Synchronisieren Sie Ihre Daten, um Ihre Fortschritte zu verfolgen.

9 Fehlerbehebung

Uhr lässt sich nicht einschalten: Laden Sie die Uhr mindestens 30 Minuten lang auf.

Bluetooth-Verbindung fehlgeschlagen: Stellen Sie sicher, dass Bluetooth aktiviert ist und die Uhr sich in der Nähe befindet.

Herzfrequenz wird nicht gemessen: Stellen Sie sicher, dass der Sensor Ihre Haut berührt.

Schlafdaten werden nicht synchronisiert: Überprüfen Sie die Bluetooth-Verbindung

Finger-Touch Heart Rate Monitor Watch User Manual

TABLE OF CONTENT

1. Product Introduction 01
2. Product Specification 01
3. Package Contents 01
4. Product Overview 01
5. Wearing Instructions 02
6. Charging Instructions 02
7. Operation Instructions 02
8. Bluetooth Connection 03
9. Function Introduction 03
10. Sedentary Reminder 04
11. Alarm Clock 04
12. Find Phone 04
13. Camera Remote Control 04
14. Music Control 04
15. Weather Forecast 04
16. Heart Rate Measurement 05
17. Blood Pressure Measurement 05
18. Blood Oxygen Measurement 05
19. Sleep Monitoring 05
20. Sports Mode 06
21. Multi-Sport Mode 06
22. Menstrual Cycle Reminder 06
23. Restore Factory Settings 06
24. Frequently Asked Questions and Solutions 07
25. Precautions 08
26. Maintenance 08
27. Warranty Terms 08
28. Disposal Method 08
29. Declaration of Conformity 08
30. Bluetooth Technology Introduction 09
31. FCC Statement 09

1. Product Introduction

1.1 Product Description

This watch is a multi-functional smart watch with a full-color screen, which:

- Measures your exercise data (such as steps, distance, calories, sports duration, etc.) and sleep data (such as sleep duration, deep sleep duration, light sleep duration, etc.), and records your daily activity and sleep status;
- Measures your heart rate, blood pressure, and blood oxygen levels in real time, and records your daily heart rate, blood pressure, and blood oxygen data;
- Reminds you of incoming calls, messages, and app notifications from your phone;
- Controls your phone's camera, music playback, and volume;
- Displays weather forecasts;
- Reminds you to stand up and move after prolonged sedentary periods;
- Reminds you to drink water at regular intervals;
- Reminds you to take medication at scheduled times;
- Reminds you of your menstrual cycle;
- Provides a stopwatch function;
- Provides a countdown timer;
- Provides a sunrise and sunset reminder;
- Provides a find phone function;
- Provides a remote shutter function;
- Provides a multi-sport mode.

1.2 Product Specification

- Screen: 1.43-inch AMOLED screen, 466×466 pixels, resolution 326 ppi, brightness 600 nits
- Battery: 350 mAh lithium-ion battery, standby time approximately 7 days, fully charged in approximately 2 hours
- Charging: Magnetic charging, 5V/1A
- Bluetooth: Bluetooth 5.2 BLE
- Water Resistance: IP68

2. Package Contents

- 1 × Smart watch
- 1 × Magnetic charging cable
- 1 × User manual

3. Product Overview

4. Wearing Instructions

5. Charging Instructions

Battery Level	Condition
Low Battery	The screen automatically turns off. Charging is required.
Charging	Connect to the USB charger.
Fully Charged	The screen displays "Fully Charged". Disconnect the charger from the watch.

6. Operation Instructions

Operation	Description
Wake Up	Raise your wrist naturally, or tap the screen.
Sleep	The screen automatically turns off after a period of inactivity.
Select	Tap the screen.
Switch	Swipe left or right on the screen.
Return	Swipe down on the screen.

7. Bluetooth Connection

7.1 Wear Mode Activation

7.2 Bluetooth Pairing

7.3 Bluetooth Reconnection

- If the watch and phone are disconnected, they will automatically reconnect when they are within Bluetooth range of each other.
- If reconnection fails, you can manually reconnect in the Bluetooth settings of your phone.

7.4 Data Synchronization

- Data is synchronized automatically when the watch and phone are connected.
- You can also manually synchronize data in the app.

7.5 Time Sync

- The watch automatically synchronizes the time of your phone.
- If the time is incorrect, check that the phone and watch time zones are set correctly.

7.6 Notification Settings

- Enable Bluetooth notifications.
- Enable app notifications.
- Enable call notifications.
- Enable message notifications.
- Enable app notifications for the apps you want to receive notifications from.

8. Function Introduction

8.1 Personal Functions

- Set your personal information (gender, age, height, weight, wearing hand) in the app.
- Set your daily step goal in the app.

8.2 Time Format Setting

- Set the time format (12-hour or 24-hour) in the app.

8.3 Unit Setting

- Set the unit system (metric or imperial) in the app.

8.4 Watch Face Switching

- Swipe left or right on the watch face to switch between different watch faces.
- Select your preferred watch face in the app.

8.5 Screen Brightness

- Adjust the screen brightness in the app.

8.6 Screen Orientation

- Set the screen orientation (left hand or right hand) in the app.

8.7 Do Not Disturb

- Enable Do Not Disturb mode in the app.
- During the set time period, the watch will not vibrate or light up the screen for notifications.

8.8 Screen Lock

- Enable screen lock in the app.
- The watch will require you to enter a password to unlock the screen.

8.9 Factory Reset

- Perform a factory reset in the app.
- All data will be erased and the watch will restore to its default settings.

9. Sedentary Reminder

- Enable sedentary reminder in the app.
- The watch will remind you to move after a period of inactivity.

10. Alarm Clock

- Set alarm clocks in the app.
- Supports multiple alarm clocks.
- Supports repeating alarms.

11. Find Phone

- Enable find phone in the app.
- Press and hold the button on the watch to make your phone ring.

12. Camera Remote Control

- Enable camera remote control in the app.
- Open the camera app on your phone.
- Tap the shutter button on the watch to take a photo.

13. Music Control

- Enable music control in the app.
- Control music playback (play/pause, previous/next track) and volume on your phone.

14. Weather Forecast

- Enable weather forecast in the app.
- The watch will display the weather forecast for the next 3 days.

15. Heart Rate Measurement

- Enable heart rate measurement in the app.
- The watch will measure your heart rate in real time.
- You can view your heart rate history in the app.

16. Blood Pressure Measurement

- Enable blood pressure measurement in the app.
- The watch will measure your blood pressure in real time.
- You can view your blood pressure history in the app.

17. Blood Oxygen Measurement

- Enable blood oxygen measurement in the app.
- The watch will measure your blood oxygen level in real time.
- You can view your blood oxygen history in the app.

18. Sleep Monitoring

- Enable sleep monitoring in the app.
- The watch will automatically monitor your sleep.
- You can view your sleep history in the app.

19. Sports Mode

- Enable sports mode in the app.
- Supports multiple sports modes.
- You can view your sports history in the app.

20. Multi-Sport Mode

- Enable multi-sport mode in the app.
- Supports switching between multiple sports modes during exercise.
- You can view your multi-sport history in the app.

21. Menstrual Cycle Reminder

- Enable menstrual cycle reminder in the app.
- Set your last menstrual period and cycle length in the app.
- The watch will remind you of your menstrual cycle.

22. Restore Factory Settings

- Perform a factory reset in the app.
- All data will be erased and the watch will restore to its default settings.

23. Frequently Asked Questions and Solutions

Problem	Solution
Cannot connect to Bluetooth	Make sure Bluetooth is enabled on your phone and the watch. Restart Bluetooth on your phone and the watch. Forget the device in your phone's Bluetooth settings and pair again.
Inaccurate heart rate reading	Make sure the watch is worn snugly on your wrist. Clean the sensor on the back of the watch. Avoid movement during measurement.
Inaccurate step count	Make sure the watch is worn correctly. Check that your step goal is set appropriately.
Inaccurate sleep data	Make sure the watch is worn while sleeping. Check that sleep monitoring is enabled.
Inaccurate blood pressure reading	Make sure the watch is worn snugly on your wrist. Avoid movement during measurement. Recalibrate blood pressure.
Inaccurate blood oxygen reading	Make sure the watch is worn snugly on your wrist. Avoid movement during measurement.
Screen is unresponsive	Restart the watch. Perform a factory reset.
Battery drains quickly	Reduce screen brightness. Disable unnecessary notifications. Disable always-on display.
Cannot receive notifications	Make sure notifications are enabled in the app. Check that Do Not Disturb mode is not enabled.
Cannot control camera	Make sure camera remote control is enabled in the app. Open the camera app on your phone.
Cannot control music	Make sure music control is enabled in the app. Start playing music on your phone.

24. Precautions

- Please read the instructions carefully before use.
- Do not use the watch in extreme temperatures or humidity.
- Do not drop or impact the watch.
- Do not disassemble or modify the watch.
- Use only the charging cable provided.
- Do not use the watch if the screen is damaged.
- Do not use the watch if the battery is swollen.

25. Maintenance

- Clean the watch with a soft, dry cloth.
- Avoid contact with chemicals.
- Store the watch in a cool, dry place.
- Charge the watch regularly.

26. Warranty Terms

Item	Warranty Period	Warranty Scope	Exclusions
Watch Body	12 months	Non-human damage, battery issues, screen issues	Human damage, water damage, unauthorized disassembly
Charging Cable	6 months	Non-human damage, charging issues	Human damage, water damage, unauthorized disassembly
Battery	6 months	Battery capacity below 80%	Human damage, water damage, unauthorized disassembly

27. Disposal Method

Please dispose of the product and its packaging in accordance with local regulations. Do not dispose of it in household waste.

28. Declaration of Conformity

Hereby, [manufacturer / PSN] declares that the radio equipment type [product name] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [internet address].

29. Bluetooth Technology Introduction

29.1 Bluetooth Introduction

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by [manufacturer / PSN] is under license. Other trademarks and trade names are those of their respective owners.

Bluetooth is a short-range wireless communication technology that enables the exchange of data between devices over short distances using radio waves. It is commonly used for connecting devices such as smartphones, computers, headphones, and speakers, allowing them to communicate without the need for cables.

29.2 Bluetooth Version

This product supports Bluetooth 5.2 BLE.

29.3 Bluetooth Profiles

Profile	Description	Supported
GAP	Generic Access Profile	Yes
GATT	Generic Attribute Profile	Yes
HFP	Hands-Free Profile	No
A2DP	Advanced Audio Distribution Profile	No
AVRCP	Audio/Video Remote Control Profile	No
HID	Human Interface Device Profile	No

30. FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE RoHS WEEE

CHIP Trading GmbH, Theodor-Heuss-Straße 29 - 37269 Eschwege, Germany