

D30A Instruction Manual

Contains three languages: English, Japanese, German

01. Item Checklist

Label Maker*1, Instruction Manual*1, USB Cable*1

*The number of label rolls on the checklist is determined by the contents of the shipped package.

02. Specifications

| | |
|-----------------------|---|
| Name | Smart Mini Label Maker |
| Model | D30A |
| Technology | Thermal printing |
| Connectable width | 12x50mm |
| Supported Consumables | Black mark Thermal Label, Pre-cut Label, Continuous Label |
| Darkness | Light, Medium, High |
| Resolution | 203 dpi |
| Connectable Language | 12 Languages |
| Communication Port | Bluetooth |
| Product Dimensions | 131.5*75.5*29 mm (5.17*2.9*1.2 inch) |
| Power Input | 5Vx2A |
| Power Supply | Lithium Battery |
| Power Supply | Micro USB |
| OS Supported | Android |
| OS Supported | iOS |

03. Product Introduction Parts and Features

04. Features of Labels

Various labels are available for purchase

04. How to Use

- Open the label compartment.
- Take out the label roll, tear the anti-bleeding stickers.
- Place the label roll into the label compartment with the printing side facing left.
- Pull out 5mm of the label of the Label Maker.
- Close the cover.
- Hold the power button for 3s to turn on the Label Maker.
- Press the power button once, and the Label Maker will start detecting the position of the label.
- When the label comes out, the positioning of the label is complete.

05. Downloading the App

After installing the label roll for the first time or replacing the label roll, remember to reposition the label (Step No. 8). If you do not reposition the label (Step No. 8), the first label you print will be printed incorrectly (printing contents, not aligning to the center, etc.).

06. Connecting the Label Maker

In compliance with Google's requirement, Android phones must enable GPS Location Services before using Bluetooth.

Method 1: Turn on GPS Location Services (Android phones only).
Method 2: Open Print Master.

Method 1: Tap the "Connect" button.
Method 2: Press "Start using".

Method 1: In compliance with Google's requirement, Android phones must enable GPS Location Services before using Bluetooth. Before connecting to your device in Print Master, please make sure your phone is turned on and your phone's Bluetooth is on.

Method 1: Check your label package.
Method 2: Measure with a ruler.

08. How to Print Selecting an Edit Mode

Life Mode: Simple editing and fast printing
Creation Mode: More functions and materials

09. How to Print Life Mode

- Select the correct label size (The label size shown below is just for example. Please choose the size of the label you need).
- Select Blank label to enter your text.
- Edit Functions.
- After you have completed editing, tap "Print".

If the matching template is not selected, there will be undesirable situations such as centered layout of printed content, uneven layout, etc.

10. FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- reorient or relocate the receiving antenna
- increase the separation between the equipment and receiver
- connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- consult the dealer or an experienced radio/TV technician for help.

*RF warning for portable device:
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

01. バックアップ内容

アンダー1目, USBケーブル1本, 説明書1冊

*同梱品に含まれるロール紙の数は実際異なる場合があります。

02. 機能について 印刷モード

01 プリンター本体の表示
02 ラベル紙の長さ
03 ラベル紙の幅
04 印刷内容の編集
05 印刷スタート

02. 機能について 電源と状態表示ランプ

| ランプ | 状態 | 電源 |
|-----|-------|-------|
| 緑点灯 | 電源オン | 電源オン |
| 緑点滅 | 電源オフ | 電源オフ |
| 赤点灯 | 電源エラー | 電源エラー |
| 赤点滅 | 電源エラー | 電源エラー |
| 赤点滅 | 電源エラー | 電源エラー |

03. 使用方法について

01 プリンターを開けてください
02 ラベル紙を巻き出してください

01 プリンターを閉じてください
02 ラベル紙を巻き戻してください

日本語

本製品使用にあたり本説明書をお読みください。

QRコードをスキャンすれば、本製品の日本語説明書をお読みいただけます。

04. アプリのダウンロード

本製品はスマホでプリンターに接続して使用する必要があります。Google Play または App Store から「Print Master」アプリをダウンロードしてください。

05. プリンターへの接続

01 電源をオンにしてください
02 アプリを開いてください

06. ラベルサイズの確認

01 ラベル紙の長さ
02 ラベル紙の幅

07. プリンターの方法 印刷モード

01 ラベル紙の長さ
02 ラベル紙の幅

08. プリンターの方法 印刷モード

01 ラベル紙の長さ
02 ラベル紙の幅

09. 印刷内容の編集

01 印刷内容の編集
02 印刷スタート

02. Beschreibung des Geräts Stromversorgung und Anzeigebereich

01. Anweisungen zum Gebrauch
02. Beschreibung des Geräts

03. Anweisungen zum Gebrauch

01. Öffnen Sie den Deckel des Etikettens
02. Nehmen Sie das Etikettpapier heraus, wenn Sie den Etikettens ausklappen ab.
03. Legen Sie die Papierrolle mit der Druckseite nach links in das Papierfach.
04. Das Etikettpapier kann gedruckt werden, um einen normalen Druck zu ermöglichen.
05. Deckel drauf tun.
06. Sie lang drücken, um das Gerät einschalten.

04. アプリのダウンロード

本製品はスマホでプリンターに接続して使用する必要があります。Google Play または App Store から「Print Master」アプリをダウンロードしてください。

05. プリンターへの接続

01 電源をオンにしてください
02 アプリを開いてください

06. ラベルサイズの確認

01 ラベル紙の長さ
02 ラベル紙の幅

07. プリンターの方法 印刷モード

01 ラベル紙の長さ
02 ラベル紙の幅

08. プリンターの方法 印刷モード

01 ラベル紙の長さ
02 ラベル紙の幅

09. 印刷内容の編集

01 印刷内容の編集
02 印刷スタート

02. Beschreibung des Geräts Stromversorgung und Anzeigebereich

01. Anweisungen zum Gebrauch
02. Beschreibung des Geräts

03. Anweisungen zum Gebrauch

01. Öffnen Sie den Deckel des Etikettens
02. Nehmen Sie das Etikettpapier heraus, wenn Sie den Etikettens ausklappen ab.
03. Legen Sie die Papierrolle mit der Druckseite nach links in das Papierfach.
04. Das Etikettpapier kann gedruckt werden, um einen normalen Druck zu ermöglichen.
05. Deckel drauf tun.
06. Sie lang drücken, um das Gerät einschalten.

Deutsch

Lesen Sie sich diese Bedienungsanleitung vor dem Gebrauch sorgfältig durch.

QR-Code scannen, um die Bedienungsanleitung des Produkts zu lesen.

Maintenance Card / 保証書 / Garantierte

Registriert / 登録済 / Registered

Return / 返品 / Return

User Information / 保証書に記入する / User Information

Model / 保証書に記入する / Model

Serial Number / 保証書に記入する / Serial Number

Product Information / 保証書に記入する / Product Information

Product name / 保証書に記入する / Product name

Product number / 保証書に記入する / Product number

Reason for Return / 保証書に記入する / Reason for Return

Return date / 保証書に記入する / Return date

Signature / 保証書に記入する / Signature

Return address / 保証書に記入する / Return address