



nean



Fahrrad Panzerschloss mit Zahlenkombination Ø 20 x 1000 mm

Bedienungsanleitung

- Der werkseitig voreingestellte Code ist „00000“. Öffne bitte das Schloss.
- Drehe bitte das kleine geriffelte Rädchen mit dem Aufdruck „Set“ um 90 Grad nach rechts, **bis es spürbar einrastet**.
- Stelle bitte deinen gewünschten Zahlencode ein.
- Drehe nun bitte das geriffelte Rädchen um 90 Grad zurück nach links in die Ausgangsposition.
- **Fertig!** Der eigene Code wurde nun eingestellt.

Häufig gestellte Fragen

Was ist mit „Einrasten“ des geriffelten Rädchens gemeint?

Das Schloss muss beim ersten Einstellen des eigenen Codes einmalig freigeschaltet werden. Dabei ist es wichtig, dass das geriffelte Rädchen korrekt in die 90-Grad-Position gedreht wird und dort einrastet. Bis zum Anschlag drehen reicht nicht, es muss ein Einrasten zu spüren sein. Am besten funktioniert es mit etwas Schwung.

Mein Schloss steckt zur Hälfte im Schlosskopf und lässt sich nicht mehr öffnen oder schließen. / Ich bekomme mein Schloss trotz meiner eingestellten Kombination nicht auf.

Das passiert möglicherweise, wenn Du das geriffelte Rädchen am Anfang nicht bis zum Einrasten in die 90 Grad Position gedreht hast. Dadurch hat sich beim Zurückdrehen des Rädchens der Code innerhalb der Mechanik wieder verstellt und ist nun ein anderer als der, den Du eingestellt hast. Hier hilft nur auszuprobieren, ob sich das Schloss beim Drehen einiger Nachbarzahlen zufällig noch öffnen lässt. Manchmal hat man Glück und es hat sich nur eine Ziffer verstellt. Funktioniert das nicht, so ist das Schloss leider nicht mehr zu öffnen.

Das Schloss ist offen. Ich kann es aber nicht mehr mit meinem Code zusammenstecken.

Bitte versuche den Code neu einzustellen. Schaue mit einer Leuchte in den Schlosskopf und drehe die Zahlenrädchen solange, bis der Weg im Inneren für jeden Zahlenring wieder so eingestellt ist, dass er frei ist und sich der Zapfen wieder bis zum Anschlag einschieben lässt. Das erkennst Du beim hineinschauen an den kleinen Lücken beim Drehen. Ziehe den Zapfen danach wieder heraus und stelle dann den Code wieder nach der Anleitung ab dem zweiten Schritt neu ein.

Kann man das Schloss wieder auf die Werkseinstellung zurücksetzen oder gibt es einen Notfallcode?

Selbstverständlich gibt es keinen Notfallcode. Denn sollte sich dieser herumsprechen, dann wäre der Nutzen unserer Schlösser sinnlos.

Ich habe meinen Code vergessen!

Hier gibt es leider keine Option mehr. Sollte der korrekte Code nicht mehr vorliegen hilft nur noch rohe Gewalt und ein neues Schloss.

Das Schloss lässt sich vor der erstmaligen Freischaltung in der Werksstellung „00000“ nicht öffnen. Kein Problem. Bitte kontaktiere uns für einen schnellen Austausch.

Für weitere Fragen wende Dich gerne an unser Serviceteam.

Bicycle Armoured Lock with Number Combination Ø 20 x 1000 mm

Instruction manual

- The factory setting code is “00000”. Please open the lock.
- Please turn the knurled wheel with the imprint “Set” to the right into a 90-degrees position **until you feel a click and it snaps in**.
- Now please set the numbers of your personal code.
- Finally turn the knurled wheel to the left back to its starting position.
- **Ready!** Your personal code now has been set.

Frequently Asked Questions

What do you mean by “snap in” of the knurled wheel?

The lock must be unlocked once by setting your own code for the first time. It is very important that the knurled wheel is turned correctly to the 90-degree position and snaps into place. Turning it to the stop is not enough, you must feel it snap into place. It works best with a little momentum.

My lock is halfway in the lock head and got stuck. / I can't open my lock despite the combination I have set.

This possibly happens if you did not turn the knurled wheel into the 90-degree position until it snapped at the beginning. As a result, when you turn the knurled wheel back, the code within the mechanics has then changed again and is now different from the one you have set before. The only thing that helps here is to try out whether the lock can still be opened by trying only the neighbouring numbers (+1 or -1). Sometimes you are lucky and only one digit has changed. If that doesn't work, the lock can unfortunately no longer be opened.

The lock is open. But I can't put it together with my code anymore.

Please try to reset the code. Look into the head of the lock with a lamp and turn the number wheels until the path inside for each number ring is adjusted so that it is free and the pin can be pushed in again as far as it will go. You can see that by looking at the small gaps when turning. Then pull the pin out again and then set the code again according to the instructions beginning from step 2.

Can the lock be reset to the 'factory settings' or is there an emergency code?

Of course, there is no emergency code. Because if word got around, then the use of our locks would be pointless.

I forgot my code!

Unfortunately, there is no longer an option here. If the correct code is no longer available, only brute force and a new lock will help out.

My lock cannot be opened for the very first setting with the factory code "00000".

No problem. Please contact us for a quick exchange.

If you have any further questions, please do not hesitate to contact our service team.