

Instruction of Disassemble & Reassemble the Clock


Step 1: Take the clock board off.

We need to take out the 6pcs metal thread spring from the back side. Please press from one side of the metal spring to take all spring out.





Step 2: 1) Take the CLOCK BOARD out from frame then turn around to the front, unscrew the GOLD NUT (in CCW) by a pair of pliers, then we can take off the hands.



3)Move the Hook under the number 60, then screw the 5pcs screws back.







Step 3: Assemble hands.

Aligning to 12 O'clock, insert hour hand into shaft, then insert minute hand and screw nut cap back.

Keep both hands parallel and turn the longer minute hand two full cycles to ensure the hands are not touching each other.

Tips: Short hour hand should be pressed tightly, but minute hand is loose before we screwing the Cap Nut;





Step 4:Put AA batteries to test hands and gears before assembling.

Put all the metal spring into the back of the frame and assembling completed.





Thanks so much for reading this instruction.