



Otto-Brenner-Str. 26, 52353 Düren, Germany

DOCUMENT CONTAINS	ASSEMBLY INSTRUCTIONS: SIDE TABLE MALIBU
STEP 1	THREE HOLES TO INSERT THE BOLTS Holes
STEP 2	UN SCREWS ALL THREE BOLTS
STEP 3 BOTTOM VIEW	PLACE ALL THREE BOLTS ON THE HOLES AND TIGHT 100% FROM THE BOTTOM SIDE OF TABLE.
STEP 4	YOUR TABLE IS READY TO USE