



- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓓ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | Ⓡⓞ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |

Ausgabe: 20221010









Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	
Nr. • No. • N° • Номер • Č • Sz	4897 1225
Typ • Type • Tip • Típus • Tipo Тип	YS-WR6992




A D15 X10	B X14	C M4X30MM X7	D M6X12MM X8	E X1
F M6X25MM X11	G X4	H D12 X4	J M4X25MM X4	




1





2

A	D15
	X2





3

C	M4X30MM
	X7





4

A D15
 X2






5

A D15
 X6






6

D	M6X12MM	E	
	X8		X1








7

G	X4	A	M6X30MM	X11
				



8

G	M4X25MM	B	H	D12	
	X4		X4		X4



9

