



# Parennes (3)



- |  |   |                                     |
|--|---|-------------------------------------|
|  | <b>(D)</b> Montageanleitung             | <b>(GB)</b> Assembly instructions   |
|  | <b>(FR)</b> Notice de montage           | <b>(IT)</b> Istruzioni di montaggio |
|  | <b>(NL)</b> Handleiding voor de montage | <b>(PL)</b> Instrukcja montażu      |
|  | <b>(CZ)</b> Montážní návod              | <b>(SK)</b> Návod na montáž         |
|  | <b>(HU)</b> Szerelési útmutató          | <b>(RO)</b> Instrucțiuni de montaj  |
|  | <b>(TR)</b> Montaj talimati             | <b>(RU)</b> Инструкция по монтажу   |



110 kg-MAX

LKZ 41507



# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •  
Nazwa • Jméno • Název • Név •  
Denumire • İsim • Название



Parennes (3)

Nr. • No. • N° • Номер • Č • Sz  
81386436,53900519,22605648

Typ • Type • Tip •  
Típus • Típo • Тип



1



<b>A</b>		<b>B</b>		<b>C</b>		<b>D</b>		<b>E</b>		<b>F</b>		<b>G</b>	
H80	x4	M8x70	x4	SW4	x1	H80	x2	D40	x2	x4		x2	

