

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
DeLonghi	FH1163	MULTIFRY FH1163
DeLonghi	FH1363	MULTIFRY FH1363
DeLonghi	FH1163/1.BK	MULTIFRY FH1163/1.BK
DeLonghi	FH1363/1.BK	MULTIFRY FH1363/1.BK
DeLonghi	FH1130/1	MULTIFRY FH1130/1
DeLonghi	FH1363/1	MULTIFRY FH1363/1
DeLonghi	FH1130/1.BK 127V	MULTIFRY FH1130/1.BK 127V
DeLonghi	FH1100/1	MULTIFRY FH1100/1
DeLonghi	FH1363/1.BK (127V)	MULTIFRY FH1363/1.BK (127V)
DeLonghi	FH1363/1.BK (220V)	MULTIFRY FH1363/1.BK (220V)
DeLonghi	FH1163/1	MULTIFRY FH1163/1
DeLonghi	FH1163/1 (UK-PLUG)	MULTIFRY FH1163/1 (UK-PLUG)
DeLonghi	FH1130	MULTIFRY FH1130
DeLonghi	FH1363/1 (UK-PLUG)	MULTIFRY FH1363/1 (UK-PLUG)
DeLonghi	FH1394/1	MULTIFRY FH1394/1
DeLonghi	FH1394/1.BK	MULTIFRY FH1394/1.BK
DeLonghi	FH1396/1.BK	MULTIFRY FH1396/1.BK
DeLonghi	FH1396/1	MULTIFRY FH1396/1
DeLonghi	FH1163/1 (EU-PLUG)	MULTIFRY FH1163/1 (EU-PLUG)
DeLonghi	FH1100/1 (EU-PLUG)	MULTIFRY FH1100/1 (EU-PLUG)
DeLonghi	FH1130/1 (EU-PLUG)	MULTIFRY FH1130/1 (EU-PLUG)
DeLonghi	FH1363/1 (EU-plug)	MULTIFRY FH1363/1 (EU-plug)
DeLonghi	FH1394/1 (EU-plug)	MULTIFRY FH1394/1 (EU-plug)
DeLonghi	FH1394/2	MULTIFRY FH1394/2
DeLonghi	FH1396/1 (EU-plug)	MULTIFRY FH1396/1 (EU-plug)
DeLonghi	FH1396/1 (UK-plug)	MULTIFRY FH1396/1 (UK-plug)
DeLonghi	FH1130/1.BK (220V)	MULTIFRY FH1130/1.BK (220V)

DeLonghi	FH1163/1.BK (127V)	MULTIFRY FH1163/1.BK (127V)
DeLonghi	FH1163/1.BK (220V)	MULTIFRY FH1163/1.BK (220V)
DeLonghi	FH1394/2 (UK-plug)	MULTIFRY FH1394/2 (UK-plug)
DeLonghi	FH1394/2 (EU-plug)	MULTIFRY FH1394/2 (EU-plug)
DeLonghi	FH1394/2.BK (220V)	MULTIFRY FH1394/2.BK (220V)
DeLonghi	FH1173/2	MULTIFRY FH1173/2
DeLonghi	FH1373/2	MULTIFRY FH1373/2
DeLonghi	FH1394	MULTIFRY FH1394
DeLonghi	FH1394/2.BK	MULTIFRY FH1394/2.BK
DeLonghi	FH1394/2.BK (EU Plug)	MULTIFRY FH1394/2.BK (EU Plug)
DeLonghi	FH1396/1.BK EX:1	MULTIFRY FH1396/1.BK EX:1
DeLonghi	FH1394/2. EX:1	MULTIFRY FH1394/2. EX:1
DeLonghi	FH1394/2.BK EX:1	MULTIFRY FH1394/2.BK EX:1
DeLonghi	FH1396/1 EX:1	MULTIFRY FH1396/1 EX:1
DeLonghi	FH1173/2 (UK plug)	MULTIFRY FH1173/2 (UK plug)
DeLonghi	FH1373/2 (UK plug)	MULTIFRY FH1373/2 (UK plug)
DeLonghi	FH1373/2 (EU plug)	MULTIFRY FH1373/2 (EU plug)
DeLonghi	FH1173/2 (EU plug)	MULTIFRY FH1173/2 (EU plug)
DeLonghi	FH1394.BK	MULTIFRY FH1394.BK
DeLonghi	FH1100	MULTIFRY FH1100
DeLonghi	FH1394/1.BK (220V)	MULTIFRY FH1394/1.BK (220V)
DeLonghi	FH1394/1.BK (127V)	MULTIFRY FH1394/1.BK (127V)
DeLonghi	FH1130/1.BK	MULTIFRY FH1130/1.BK