

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
AEG	FAV52850S	
AEG	F55200W0	
AEG	F55210S0	
AEG	F57202W0	
AEG	F57202S0	
AEG	F55200VI0	
AEG	FAV52850S	
AEG	FAV52850	
AEG	FAV45250VI	
AEG	FAV52860	
AEG	F52860S	
AEG	FAV54200S	
AEG	F55200W0	
AEG	F55210S0	
AEG	F45260VI	
AEG	FAV45270VI	
AEG	F55200VI0	
Arthur Martin	ASL2435/1	
Arthur Martin	ASF2440	
Arthur Martin	ASL2435	
Arthur Martin	ASF2445	
Arthur Martin	ASF2450W	
Arthur Martin	ASL2450W	
Dometic	DW2440S	
Dometic	DW2300OS	
Electrolux	ESF2420	
Electrolux	ESF2420SSILVER	
Electrolux	ESF2440	
Electrolux	ESF2440S	
Electrolux	ESF2420S	
Electrolux	ESF2440 EJ AVH HONGK	
Electrolux	ESL2435	
Electrolux	ESF2440 S	
Electrolux	ESF2440 E	
Electrolux	ESF2450W	
Electrolux	ESF2450S EUR	
Electrolux	ESF2450S	
Electrolux	ESF2300OW	
Electrolux	ESF2300OH	
Electrolux	ESF2300OK	
Electrolux	ESF2300OS	
Electrolux	ESF2420 C	
Electrolux	ESF2430W P,E	
Electrolux	ESF2430W	
Electrolux	ESF2430S	

Electrolux	ESF2210DW	
Electrolux	ESF2210DK	
Electrolux	ESL2460W	
Electrolux	ESL2450W	
Electrolux	WA1100	
Electrolux	WA850	
Juno	JSL45012	
Juno	JSV65550	
Juno	JSL4501	
Juno	F45250VI	
Rex	RSF2420	
Rex	TCC800	
Rex	RSF2420S	
Rex	TCC8E	
Rex	RSF2440S	
Rex	RSF2450S	
Rex	RSF2300OK	
Rex	RSF2300O	
Rex	RSF2300OS	
Rex	RSF2300OH	
Rex	RSF2420	
Rex	RSF2210D	
Rex	RSF2210DW	
Rex	TCC800	
Samsung	WD80J6400AW/EN	
Samsung	WD906P4SAWQ/EG	
Samsung	WD91J6400AW/EN	
Samsung	WF1704YSW/XEN	
Samsung	WF90F7E6P6W3EN	
Samsung	WW80H7600EW/EN	
Samsung	WW80J6600CW/EN	
Samsung	WW80J6603EW/EN	
Samsung	WW80K6604QW/EN	
Samsung	WW80K6605SW/EN	
Samsung	WW80K7605OW/EN	
Samsung	WW81H7400EW/EN	
Samsung	WW81J6600CW/EN	
Samsung	WW81K6604QW/EN	
Samsung	WW81K7605OW/EN	
Samsung	WW90H7410EW/EU	
Samsung	WW90H7600EW/EN	
Samsung	WW90J6600CW/EN	
Samsung	WW90J6603EW/EN	
Samsung	WW90K6604QW/EN	
Samsung	WW90K6605SW/EN	
Samsung	WW90K7605OW/EN	
Samsung	WW91J6600CW/EN	
Samsung	WW91K6604QW/EN	

Samsung	WW91K7605OW/EN	
Samsung	WF1704YSWXEN	
Whirlpool	S20DRCB10	
Whirlpool	3XS20DRCB20 S20DRCB20	
Whirlpool	ARZ726/W	
Whirlpool	ARZ726/B	
Whirlpool	ARZ730/W	
Whirlpool	ARZ730/B	
Whirlpool	ARZ735/W	
Whirlpool	ARZ735/S	
Whirlpool	ARZ737/B	
Whirlpool	ARZ740/W	
Whirlpool	ARZ740/B	
Whirlpool	ARZ767/S	
Whirlpool	ARG488/G/BLACK	
Whirlpool	ARG496/G/WP	
Whirlpool	ARG496/G	
Whirlpool	8340NF	
Whirlpool	ART710	
Whirlpool	ART720	
Whirlpool	ART721/BLACK	
Whirlpool	ART722	
Whirlpool	ART725	
Whirlpool	ART730	
Whirlpool	ART731	
Whirlpool	ART732	
Whirlpool	ART735	
Whirlpool	ART745	
Whirlpool	ART749SSFC	
Whirlpool	ARZ710/W	
Whirlpool	US20DRCB10	
Whirlpool	US20DRCB20	
Whirlpool	US20DRSB22	
Whirlpool	ARZ730/W/UK	
Whirlpool	ARZ740/S	
Whirlpool	ARZ742/W	
Whirlpool	ARZ767/SSFC	
Whirlpool	ART700	
Whirlpool	ART700/UK	
Whirlpool	ART705/G/ROPER	
Whirlpool	ART730/UK	
Whirlpool	ART749SSFC/UK	
Zanker	800	
Zanker	1000 EXCLUSIV	
Zanker	5050	
Zanker	100	
Zanussi	ZSF2450S	
Zanussi	ZSF2450	

Zanussi	ZDM16301SA	
Zanussi	ZDM16301WA	
Zanussi	ZSF2430	
Zanussi	ZDM11301WA	
Zanussi	R814	
Zanussi	ZSF2420	
Zanussi	ZSF2440S	
Zanussi	ZSF2440	
Zanussi	ZSF2440S SILVER IRAN	
Zanussi	ZSF2440 E	
Zanussi	ZSF2450 C	
Zanussi	ZSF2450S	
Zanussi	ZSF2430 U	