

Passend fuer die folgenden Modelle:

Marke	Typennummer	Modell
Philips	HX6711/24	Sonicare HealthyWhite
Philips	HX8911/01	Sonicare HealthyWhite+
Philips	HX6732/33	Sonicare HealthyWhite
Philips	HX6781/02	Sonicare HealthyWhite
Philips	HX6732/02	Sonicare HealthyWhite
Philips	HX8923/34	Sonicare HealthyWhite+
Philips	HX6733/33	Sonicare HealthyWhite
Philips	HX6721/35	Sonicare HealthyWhite
Philips	HX6733/90	Sonicare HealthyWhite
Philips	HX6730/05	Sonicare HealthyWhite
Philips	HX6762/35	Sonicare HealthyWhite
Philips	HX8962/05	Sonicare HealthyWhite+
Philips	HX9142/32	Sonicare FlexCare Platinum
Philips	HX6732/37	Sonicare HealthyWhite
Philips	HX6762/43	Sonicare HealthyWhite
Philips	HX6730/33	Sonicare HealthyWhite
Philips	HX8922/90	Sonicare HealthyWhite+
Philips	HX8911/02	Sonicare HealthyWhite+
Philips	HX8918/10	Sonicare HealthyWhite+
Philips	HX6732/43	Sonicare HealthyWhite
Philips	HX6732/90	Sonicare HealthyWhite
Philips	HX8911/22	Sonicare HealthyWhite+
Philips	HX6732/42	Sonicare HealthyWhite
Philips	HX8982/02	Sonicare HealthyWhite+
Philips	HX6782/33	Sonicare HealthyWhite
Philips	HX6731/02	Sonicare HealthyWhite
Philips	HX6711/22	Sonicare HealthyWhite

Philips	HX6782/02	Sonicare HealthyWhite
Philips	HX6730/02	Sonicare HealthyWhite
Philips	HX6711/02	Sonicare HealthyWhite
Philips	HX6780/02	Sonicare HealthyWhite
Philips	HX8911/04	Sonicare HealthyWhite+
Philips	HX9142/10	Sonicare FlexCare Platinum
Philips	HX6733/70	Sonicare HealthyWhite
Philips	HX8911/35	Sonicare HealthyWhite+
Philips	HX9142/31	Sonicare FlexCare Platinum