
















Assembly Instructions

XRocker

Warning!

Chair arms are for gaming support only. To avoid damage or injury, do not sit on the arms.
Do not use arms to EXIT from the chair or to MOVE or LIFT the chair.

A		1
B		1
C		1
D		2
E		1
F	M6 	1
G	 M8*25	4
H	 Ø8*Ø18	4
I		8
J	 M8*35	6



If there are any parts missing or you need further assistance, contact X Rocker at: www.xrocker.com/pages/support



Manufactured by: Ace Casual Limited, Bradford Road,
Brighouse, UK, HD6 4DJ

EU Authorised Representative: X Rocker GMBH, Bremen City
Gate, Bahnhofplatz 42, 28195 Bremen, Germany.