

Passend fuer folgende Modelle:

Marke	Typennummer	Modell
Beko	7502920008	FSA21340_ EU2 (F5210-HC)
Beko	7397910001	CHK 31000
Beko	7510720002	CHA23000_ RUSSIA (K5220NF-HC)
Beko	7510020003	CSA21000_ EU2 (K5210-HC)
Beko	7502920041	FSA 21320_ EU2 (F5210-HC)
Beko	7510720009	CHA23000_ RUSSIA (K5220NF-HC)
Beko	7506620022	CSA29000_ FRANCE (K5270-HC)
Beko	7502920027	FSA21340_ EU2 (F5210-HC)
Beko	7510620003	CHA27000_ RUSSIA (K5250NF-HC)
Beko	7513220008	CHA 28000_ EU2 (K5280NF-HC)
Beko	7502920040	FSA 21300_ UKRAINE (F5210-HC)
Beko	7505220015	CSA 24000_ RUSSIA (K5240-HC)
Beko	7510620006	CHA27000_ RUSSIA (K5250NF-HC)
Beko	7502920054	FSA 21000_ RUSSIA (F5210-HC)
Beko	7506620014	CSA 29012_ POLAND (K5270-HC)
Beko	7502920028	FSA21300/ EU2 (F5210-HC)
Beko	7512720003	CSA 22002_ EU2 (K5225-HC)
Beko	7502920058	FSA 210 _ BENELUX (F5210-HC)
Beko	7512720004	CSA 22010_ EU1 (K5225-HC)
Beko	7398920001	CSK31000_ EU2 (K5300)
Beko	7513120021	CSA 31000_ RUSSIA (K5300-HC)
Beko	7505220017	CSA 24012_ POLAND (K5240-HC)
Beko	7513220003	CHA 28000_ EU2 (K5280NF-HC)
Beko	7502920062	FSA21921 _ NIGERIA (F5210-HC)
Beko	7505220016	CSA 24002_ EU2 (K5240-HC)
Beko	7505220010	CSA 24000_ EU2 (K5240-HC)
Beko	7505220012	CSA 24010_ EU1 (K5240-HC)

Beko	7399020001	CSK25000 _EU2 (K5250)
Beko	7502920052	FS220 A++ _POOL (F5210-HC++)
Beko	7506620010	CSA 29010_ EU1 (K5270-HC)
Beko	7502920010	FSA21300_ EU2 (F5210-HC)
Beko	7510020007	CSA 21010EU1 _ (K5210-HC)
Beko	7502920012	FSA21000_ RUSSIA (F5210-HC)
Beko	7512720007	CSA22030_ EU2_ EU2 (K5225-HC)
Beko	7510020010	CSA 21030EU2 _ (K5210-HC ++)
Beko	7502920030	FSA21000_ RUSSIA (F5210-HC)
Beko	7502920023	FS210_ EU2 (F5210-HC)
Beko	7502920024	FS220_ EU2 (F5210-HC A+)
Beko	7512720002	CSA 22012_ EU1 (K5225-HC)