

**Passend für die folgenden Modelle:**

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
PHILIPS	RQ1095/22	arcitec
PHILIPS	RQ1060/20	arcitec
PHILIPS	RQ1085/21	arcitec
PHILIPS	RQ1061/18	arcitec
PHILIPS	RQ1060/19	arcitec
PHILIPS	RQ1050/29	arcitec
PHILIPS	RQ1090/20	arcitec
PHILIPS	RQ1075/22	arcitec
PHILIPS	RQ1090/17	arcitec
PHILIPS	RQ1050/17	arcitec
PHILIPS	RQ1050/18	arcitec
PHILIPS	RQ1090/19	arcitec
PHILIPS	RQ1053/18	arcitec
PHILIPS	RQ1075/21	arcitec
PHILIPS	RQ1095/21	arcitec
PHILIPS	RQ1090/03	arcitec
PHILIPS	RQ1060/17	arcitec
PHILIPS	RQ1060/15	arcitec
PHILIPS	RQ1051/18	arcitec
PHILIPS	RQ1051/28	arcitec
PHILIPS	RQ1050/16	arcitec
PHILIPS	RQ1050/15	arcitec
PHILIPS	S5210/06	5000 series
PHILIPS	S5270/06	5000 series
PHILIPS	S7788/82	Shaver series 7000
PHILIPS	S5380/26	series 5000
PHILIPS	S5335/12	series 5000
PHILIPS	S5330/41	series 5000
PHILIPS	RQ1260/17	SensoTouch
PHILIPS	S7720/26	series 7000
PHILIPS	S5251/12	5000 series
PHILIPS	S5466/17	series 5000
PHILIPS	S5320/08	series 5000
PHILIPS	S7520/50	series 7000
PHILIPS	S5584/50	series 5000
PHILIPS	S5520/45	series 5000
PHILIPS	S5672/41	series 5000
PHILIPS	S5579/60	series 5000
PHILIPS	S7320/12	AquaTouch series 7000
PHILIPS	S5210/86	5000 series
PHILIPS	RQ1297/23	Shaver Series 9000 SensoTouch Wet & Dry
PHILIPS	S7710/15	series 7000
PHILIPS	RQ1250/32	SensoTouch
PHILIPS	S5252/12	5000 series
PHILIPS	S7371/84	series 7000

PHILIPS	S7720/31	series 7000
PHILIPS	S5579/50	series 5000
PHILIPS	S7340/41	series 7000
PHILIPS	S5070/92	AquaTouch
PHILIPS	S5080/03	5000 series
PHILIPS	S5340/06	series 5000
PHILIPS	S5100/06	series 5000
PHILIPS	RQ1251/82	SensoTouch
PHILIPS	RQ1150/17	SensoTouch
PHILIPS	S5585/10	series 5000
PHILIPS	S5211/12	5000 series
PHILIPS	RQ1197/39	SensoTouch
PHILIPS	RQ1141/16	SensoTouch 2D
PHILIPS	S7520/69	series 7000
PHILIPS	RQ1260/03	SensoTouch 3D
PHILIPS	RQ1155/82	SensoTouch
PHILIPS	RQ1180/22	SensoTouch
PHILIPS	RQ1160/22	SensoTouch
PHILIPS	S7920/65	series 7000
PHILIPS	RQ1275/16	SensoTouch
PHILIPS	S5231/12	5000 series
PHILIPS	RQ1285/83	SensoTouch 3D
PHILIPS	RQ1160/17	SensoTouch
PHILIPS	S5320/06	series 5000
PHILIPS	RQ1180/17	SensoTouch
PHILIPS	S7310/12	series 7000
PHILIPS	S5400/41	AquaTouch
PHILIPS	S5579/80	series 5000
PHILIPS	RQ1155/32	SensoTouch
PHILIPS	RQ1195/21	SensoTouch
PHILIPS	S5588/10	Shaver series 5000
PHILIPS	S5310/26	series 5000
PHILIPS	RQ1145/32	SensoTouch
PHILIPS	RQ1178/17	SensoTouch
PHILIPS	RQ1296/23	SensoTouch
PHILIPS	S5579/69	series 5000
PHILIPS	S5090/58	5000 series
PHILIPS	S7740/84	series 7000
PHILIPS	S5273/12	series 5000
PHILIPS	S5100/08	series 5000
PHILIPS	RQ1180/16	SensoTouch
PHILIPS	RQ1285/21	SensoTouch 3D
PHILIPS	S5395/12	series 5000
PHILIPS	S7550/50	series 7000
PHILIPS	S5400/06	AquaTouch
PHILIPS	RQ1167/54	SensoTouch
PHILIPS	S5140/26	series 5000
PHILIPS	S5588/81	Shaver series 5000

PHILIPS	RQ1150/16	SensoTouch
PHILIPS	RQ1275/17	SensoTouch
PHILIPS	S5290/12	5000 series
PHILIPS	S5085/06	5000 series
PHILIPS	RQ1265/21	SensoTouch
PHILIPS	S5205/81	5000 series
PHILIPS	S7311/12	series 7000
PHILIPS	S7980/68	series 7000
PHILIPS	S5077/03	5000 series
PHILIPS	S5672/12	series 5000
PHILIPS	S7740/69	series 7000
PHILIPS	S7360/42	series 7000
PHILIPS	RQ1261/17	SensoTouch
PHILIPS	S5212/12	5000 series
PHILIPS	RQ1285/17	SensoTouch 3D
PHILIPS	S5466/18	series 5000
PHILIPS	S5340/08	series 5000
PHILIPS	RQ1253/17	SensoTouch
PHILIPS	S5390/26	series 5000
PHILIPS	S5588/30	series 5000
PHILIPS	S5078/04	5000 series
PHILIPS	S5310/06	series 5000
PHILIPS	RQ1285/16	SensoTouch 3D
PHILIPS	S7921/51	series 7000
PHILIPS	RQ1155/16	SensoTouch
PHILIPS	S5050/64	AquaTouch
PHILIPS	RQ1250/21	SensoTouch
PHILIPS	S5400/04	AquaTouch
PHILIPS	S5130/08	series 5000
PHILIPS	S5584/57	series 5000
PHILIPS	RQ1141/17	SensoTouch 2D
PHILIPS	S7522/50	series 7000
PHILIPS	S5086/06	5000 series
PHILIPS	S5272/12	series 5000
PHILIPS	S5587/30	series 5000
PHILIPS	RQ1195/22	SensoTouch
PHILIPS	RQ1175/84	SensoTouch
PHILIPS	RQ1151/16	SensoTouch 2D
PHILIPS	RQ1290/23	SensoTouch 3D
PHILIPS	S5585/35	series 5000
PHILIPS	S5672/26	series 5000
PHILIPS	S5010/03	5000 series
PHILIPS	S5150/63	series 5000
PHILIPS	S5391/12	series 5000
PHILIPS	S7788/59	Shaver series 7000
PHILIPS	RQ1167/17	SensoTouch
PHILIPS	S5588/30	Shaver series 5000
PHILIPS	RQ1275/82	SensoTouch

PHILIPS	RQ1160/21	SensoTouch
PHILIPS	S5130/06	series 5000
PHILIPS	RQ1175/17	SensoTouch
PHILIPS	RQ1151/17	SensoTouch 2D
PHILIPS	S5082/61	5000 series
PHILIPS	RQ1284/21	SensoTouch 3D
PHILIPS	S5008/04	5000 series
PHILIPS	RQ1175/16	SensoTouch
PHILIPS	S5571/68	series 5000
PHILIPS	RQ1148/17	SensoTouch
PHILIPS	S5013/26	5000 series
PHILIPS	S7521/12	series 7000
PHILIPS	RQ1250/17	SensoTouch
PHILIPS	S5585/30	series 5000
PHILIPS	RQ1261/16	SensoTouch
PHILIPS	S5230/06	5000 series
PHILIPS	S7561/12	series 7000
PHILIPS	S5560/06	series 5000
PHILIPS	S5210/81	5000 series
PHILIPS	RQ1280/22	SensoTouch 3D
PHILIPS	RQ1286/21	SensoTouch
PHILIPS	S5600/41	AquaTouch
PHILIPS	RQ1185/22	SensoTouch
PHILIPS	S7530/50	series 7000
PHILIPS	S5587/10	series 5000
PHILIPS	RQ1286/22	SensoTouch
PHILIPS	RQ1280/21	SensoTouch 3D
PHILIPS	S5070/59	AquaTouch
PHILIPS	S5070/06	AquaTouch
PHILIPS	S5110/06	series 5000
PHILIPS	RQ1187/16	SensoTouch
PHILIPS	RQ1280/17	SensoTouch 3D
PHILIPS	S5230/08	5000 series
PHILIPS	RQ1155/80	SensoTouch
PHILIPS	S5070/04	AquaTouch
PHILIPS	S7710/26	series 7000
PHILIPS	RQ1155/17	SensoTouch
PHILIPS	RQ1145/16	SensoTouch
PHILIPS	S5620/41	AquaTouch
PHILIPS	S5010/06	5000 series
PHILIPS	S7788/55	Shaver series 7000
PHILIPS	S5420/08	AquaTouch
PHILIPS	S5588/26	Shaver series 5000
PHILIPS	S5213/12	5000 series
PHILIPS	S7370/12	series 7000
PHILIPS	S5011/04	5000 series
PHILIPS	S5620/12	AquaTouch
PHILIPS	S5110/04	series 5000

PHILIPS	S5600/12	AquaTouch
PHILIPS	S5091/50	5000 series
PHILIPS	S5588/25	Shaver series 5000
PHILIPS	S7560/12	series 7000
PHILIPS	RQ1167/80	SensoTouch
PHILIPS	S5015/61	5000 series
PHILIPS	RQ1260/22	SensoTouch
PHILIPS	S5075/06	5000 series
PHILIPS	S5355/82	series 5000
PHILIPS	RQ1160/16	SensoTouch
PHILIPS	S5588/17	Shaver series 5000
PHILIPS	RQ1250/22	SensoTouch
PHILIPS	S5570/66	series 5000
PHILIPS	RQ1295/23	SensoTouch 3D
PHILIPS	S7370/41	series 7000
PHILIPS	RQ1260/21	SensoTouch
PHILIPS	S5360/06	series 5000
PHILIPS	S7311/66	series 7000
PHILIPS	S5510/45	series 5000
PHILIPS	RQ1187/45	SensoTouch
PHILIPS	S7311/26	series 7000
PHILIPS	RQ1280/16	SensoTouch 3D
PHILIPS	S5586/64	series 5000
PHILIPS	S5572/73R1	series 5000
PHILIPS	RQ1175/32	SensoTouch
PHILIPS	S7780/64	series 7000
PHILIPS	S5050/06	AquaTouch
PHILIPS	RQ1145/17	SensoTouch
PHILIPS	RQ1141/80	SensoTouch 2D
PHILIPS	S5510/37	series 5000
PHILIPS	S5095/58	5000 series
PHILIPS	S5396/12	series 5000
PHILIPS	RQ1195/17	SensoTouch
PHILIPS	S5420/06	AquaTouch
PHILIPS	S5370/26	series 5000
PHILIPS	S5570/71	series 5000
PHILIPS	S5081/04	5000 series
PHILIPS	S7510/41	series 7000
PHILIPS	S5271/12	5000 series
PHILIPS	RQ1260/16	SensoTouch
PHILIPS	S5050/67	AquaTouch
PHILIPS	RQ1273/16	SensoTouch
PHILIPS	RQ1250/80	SensoTouch
PHILIPS	RQ1250/16	SensoTouch
PHILIPS	S5079/04	5000 series
PHILIPS	S5588/38	Shaver series 5000
PHILIPS	S5586/66	series 5000
PHILIPS	S5395/26	series 5000

PHILIPS	S5150/26	series 5000
PHILIPS	S7350/12	series 7000
PHILIPS	S5390/81	series 5000
PHILIPS	RQ1155/81	SensoTouch
PHILIPS	S5586/50	series 5000
PHILIPS	RQ1185/21	SensoTouch
PHILIPS	S7788/54	Shaver series 7000
PHILIPS	S5420/04	AquaTouch
PHILIPS	SP9821/12	Wet and Dry Prestige
PHILIPS	SP9820/16	Wet and Dry Prestige
PHILIPS	SP9820/12	Wet and Dry S9000 Prestige
PHILIPS	SP9820/18	Wet and Dry Prestige
PHILIPS	S7788/20	Shaver series 7000
PHILIPS	S7788/58	Shaver series 7000
PHILIPS	S7788/61	Shaver series 7000