

Gebrauchsanweisung für 8 Tage Pendeluhr

Diese Uhr ist nach traditioneller Uhrmacherkunst gefertigt. Das 8-Tage-Gewichtszug-Pendelwerk schlägt zu jeder vollen Stunde jeweils ein Schlag auf Glocke.

Aufhängen der Uhr

Die Uhr vorsichtig aus der Verpackung nehmen, ca. 1,90 m über dem Boden Nagel, Haken oder Schraube setzen und die Uhr senkrecht aufhängen. Pendel vom Deckel der Styroporverpackung lösen und in die Öse der Pendelverlängerung sowie das Gewicht in den Haken der Kette einhängen.

Starten des Uhrwerkes

Die Pendellinse etwa 10 cm aus dem Lot führen und loslassen. Das Pendel schwingt und es reguliert sich selbstständig auf die richtige Schwingungsweite ein.

Stellen des Uhrwerkes

Minutenzeiger nur im Uhrzeigersinn drehen bis die Uhrzeit stimmt.

Aufziehen der Uhr

Diese Uhr läuft etwa eine Woche bei Ausnutzung der vollen Kettenlänge. Aufziehen der Uhr erfolgt indem am freien Kettenende das Aufzugsgewicht bis zum Anschlag gezogen wird. Zur Entlastung des Uhrwerkes sollte das Gewicht dabei etwas angehoben werden.

Regulieren der Ganggenauigkeit

Über die Pendelmutter unterhalb der Pendellinse wird die Uhr reguliert. Drehen der Pendelmutter und damit der Pendelscheibe nach oben macht die Uhr schneller, nach unten wird die Uhr langsamer. Eine Umdrehung entspricht dabei 1 min/Tag.

Operating Instructions for 8 days Pendulum Clock

This clock is made with traditional clock-makers skills. It has an 8 days weight-driven pendulum movement with a passing strike on the hour.

To hang the Clock

Lift the clock from its packing carefully. Choose a suitable position for the clock (approx. 1,9 m above the floor). Mark the position of the hangers (nail, hook or screw) on the wall. Bear in mind the weight of the clock and of the driving-weight when choosing the type of the hanger. Fix the hanger into the wall at the place marked and hang the clock perpendicularly on the hanging hole at the rear of the clock. Make sure that the chain wheel catches properly in the driving-chain. Loosen the pendulum from the polystyrene packing. Engage the pendulum hook into the eye of the pendulum extension and suspend the driving-weight onto the hook of the driving-chain.

To start the Movement

Hold the pendulum bob approximately 10 cm from the vertical and release. The pendulum swings and regulates the correct rhythm independently.

To set the Time

Turn the minute hand clockwise only until the time is correct.

To wind up the Clock

This clock runs approximately one week before the whole length of the chain is used. Draw up the free end of the chain until the driving-weight reaches the top. At the same time, lift the weight a little to relieve tension on the clock and hanger. If necessary swing the pendulum as before.

Regulating the Clock

Your clock can be regulated accurately personally by sliding the pendulum bob up or down the pendulum rod. Sliding it up makes the clock faster and sliding it down makes the clock slower. If the clock does not keep proper time, please adjust the pendulum bob by turning the rating nut to the right (pendulum bob moves up). Turning rating nut to the left (pendulum bob moves down). One turn of the regulating nut corresponds to a time difference of approx. 1 minute per day.