

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
Electrolux	92550307100	FI22/11ES
Electrolux	92550307001	FI22/11E
Neue	92551500601	IFF552W
REX	92550300500	FI22/11E
REX	92550300601	FI22/11ES
REX	92550300700	FI22/12E
REX	92550300501	FI22/11E
REX	92550300600	FI22/11ES
Frigidaire	92551501000	FRBIFF501
Neue	92551500600	IFF552W
Electrolux	92551301101	FI18/11E
Zoppas	92551300800	PBB25431SK
Electrolux	92551301100	FI18/11E
Zanker	92550304202	KBB29011SK
Progress	92550304500	PKG1843C
Zoppas	92550304301	PBB29431SK
Electrolux	92550305900	ENN2900EOW
Küppersbusch	92550303100	IKE326022T
Küppersbusch	92550303101	IKE326022T
Leonard	92550303902	LKG1843
Küppersbusch	92550303102	IKE326022T
Küppersbusch	92550303201	IK32622TCN
Zoppas	92550304303	PBB29431SK
Progress	92551300500	PKG1643
Progress	92550304100	PKG1843
Küppersbusch	92550307900	IKE326032T
Electrolux	92550307200	ENN2802AOW

Zanker	92550304201	KBB29011SK
Electrolux	92550306900	RNN2800AOL
Electrolux	92550307101	FI22/11ES
Electrolux	92550306600	RNN2800AOW
Electrolux	92550306601	RNN2800AOW
Electrolux	92550306901	RNN2800AOL
Electrolux	92550307000	FI22/11E
Electrolux	92550306800	RNN2800AOR
Electrolux	92550306801	RNN2800AOR
Electrolux	92550305901	ENN2900EOW
Progress	92550304102	PKG1843
Leonard	92550303900	LKG1843
Leonard	92550303901	LKG1843
Zanker	92551300600	KBB25011SK
Progress	92550304101	PKG1843
Zanker	92551300602	KBB25011SK
Electrolux	92551301102	FI18/11E
Neue	92551500603	IFF552W
Neue	92551500602	IFF552W
Frigidaire	92551501001	FRBIFF501
Frigidaire	92551501002	FRBIFF501
Progress	92551300502	PKG1643
Electrolux	92550307004	FI22/11E
Electrolux	92550308803	ENN2910EOW
Electrolux	92551301103	FI18/11E
Electrolux	92550307203	ENN2802AOW
Electrolux	92550306604	RNN2800AOW
Electrolux	92550305904	ENN2900EOW
Electrolux	92550307104	FI22/11ES

Electrolux	92550306904	RNN2800AOL
Electrolux	92550306804	RNN2800AOR
Electrolux	92550308802	ENN2910EOW
Electrolux	92550307003	FI22/11E
Electrolux	92550306903	RNN2800AOL
Electrolux	92550306803	RNN2800AOR
Electrolux	92550305903	ENN2900EOW
Electrolux	92550307201	ENN2802AOW
Electrolux	92550307002	FI22/11E
Electrolux	92550306602	RNN2800AOW
Electrolux	92550306802	RNN2800AOR
Electrolux	92550307102	FI22/11ES
Electrolux	92550305902	ENN2900EOW
Electrolux	92550306902	RNN2800AOL
Electrolux	92550307202	ENN2802AOW
Electrolux	92550308801	ENN2910EOW
Electrolux	92550308800	ENN2910EOW
Küppersbusch	92550315500	FKG8300.0I
Küppersbusch	92550307901	IKE326032T
Küppersbusch	92550307902	IKE326032T
Leonard	92550303905	LKG1843
Leonard	92550303903	LKG1843
Neue	92551502100	IFF553W
Progress	92551300503	PKG1643
Progress	92550304105	PKG1843
Progress	92550304103	PKG1843
Progress	92550304504	PKG1843C
Zanker	92551300603	KBB25011SK
Zanker	92550304205	KBB29011SK

Zanker	92550304203	KBB29011SK
Zoppas	92550304304	PBB29431SK