



REEBOKFITNESSEQUIPMENT.COM/PRODUCTSUPPORT


Reebok
ONE SERIES



ONE GX40
ASSEMBLY GUIDE



Reebok
ONE SERIES

GX40





	A-1		E-1
	F-26 F-27		F-31 F-32 F-33 F-34
	F-28 F-29		P
	F-21		K-1
	F-19 F-20		I-3
	J-1		C-1 C-4
	I-1		B-1
	E-1		F-17 F-18
	F-1		F-30 D-1



01




02




03





04





05





06





07





08



09





ITEM		DESCRIPTION	QTY	
A-1	RVON-10111BK	Console (incl. A-1)	1	SET
A-2	RVON-10111BK	Screw	4	PCS
B-1	RVON-10111BK	Front handlebar set (incl. B1-B6)	1	SET
	RVON-10111BK	Hand pulse sensor	2	pcs
	RVON-10111BK	Hand pulse wire	1	PCS
B-2	RVON-10111BK	Foam grip	2	PCS
B-3	RVON-10111BK	Handlebar end cap	2	PCS
B-4	RVON-10111BK	Hand pulse sensor	2	PCS
B-5	RVON-10111BK	screw	2	PCS
B-6	RVON-10111BK	Hand pulse wire	1	PCS
B-7	RVON-10111BK	Washer	2	PCS
C-1	RVON-10111BK	Upper handlebar, left (incl. C-2, -3)	1	PCS
C-2	RVON-10111BK	Handlebar end cap	2	PCS
C-3	RVON-10111BK	Foam grip	2	PCS
C-4	RVON-10111BK	Upper handlebar, right (incl. C-2, -3)	1	PCS
D-1	RVON-10111BK	Handlebar post set	1	SET
D-2	RVON-10111BK	Sensor wire, upper	1	PCS
D-3	RVON-10111BK	screw	2	PCS
D-4	RVON-10111BK	Sleeve	2	PCS
D-5	RVON-10111BK	Screw	4	PCS
D-6	RVON-10111BK	Tension controller, upper	1	PCS
E-1	RVON-10111BK	Lower handlebar	2	SET
E-2	RVON-10111BK	Sleeve	4	PCS
E-3	RVON-10111BK	Fixed axle of lower handlebar	2	PCS
E-4	RVON-10111BK	Sleeve of axle	4	PCS
E-5	RVON-10111BK	Screw	4	PCS
F-1	RVON-10111BK	Main frame set	1	SET
F-2	RVON-10111BK	C ring	1	PCS
F-3	RVON-10111BK	Wave washer	1	PCS
F-4	RVON-10111BK	Flat washer	1	PCS
F-5	RVON-10111BK	Wire	1	PCS
F-6	RVON-10111BK	Sensor bracket	1	PCS
F-7	RVON-10111BK	DC wire	1	PCS
F-8	RVON-10111BK	Screw	1	PCS
F-9	RVON-10111BK	Bearing	2	PCS
F-10	RVON-10111BK	Nut	2	PCS
F-11	RVON-10111BK	Belt	1	PCS
F-12	RVON-10111BK	Screw	4	PCS
F-13	RVON-10111BK	Screw	8	PCS
F-14	RVON-10111BK	Left cover	1	PCS
F-15	RVON-10111BK	Right cover	1	PCS
F-16	RVON-10111BK	Cap of handlebar post	1	PCS
F-17	RVON-10111BK	Footplate tube, left front cover	2	PCS
F-18	RVON-10111BK	Footplate tube, right front cover	2	PCS
F-19	RVON-10111BK	Left pedal	1	PCS
F-20	RVON-10111BK	Right pedal	1	PCS
F-21	RVON-10111BK	Fixed shaft of handlebar	1	PCS
F-23	RVON-10111BK	Screw	6	PCS
F-24	RVON-10111BK	Flat washer	6	PCS
F-25	RVON-10111BK	Spring washer	6	PCS
F-26	RVON-10111BK	Front cap of upper handlebar	2	PCS
F-27	RVON-10111BK	Rear cap of upper handlebar	2	PCS
F-28	RVON-10111BK	Front cover of handlebar	1	PCS
F-29	RVON-10111BK	Rear cover of handlebar	1	PCS
F-30	RVON-10111BK	Water bottle holder	1	PCS
F-31	RVON-10111BK	Footplate tube rear cover, upper left	1	PCS
F-32	RVON-10111BK	Footplate tube rear cover, upper right	1	PCS
F-33	RVON-10111BK	Footplate tube rear cover, lower left	1	PCS
F-34	RVON-10111BK	Footplate tube rear cover, lower right	1	PCS

G	RVON-10111BK	Flywheel set	1	SET
G-1	RVON-10111BK	Flywheel axle	1	PCS
G-2	RVON-10111BK	Nut	5	PCS
G-3	RVON-10111BK	Flywheel axle	1	PCS
G-4	RVON-10111BK	Flat washer	1	PCS
G-5	RVON-10111BK	Bearing	1	PCS
G-6	RVON-10111BK	Bearing	1	PCS
G-7	RVON-10111BK	Bushing	1	PCS
G-8	RVON-10111BK	Star washer	2	PCS
H	RVON-10111BK	Magnet set	1	SET
H-1	RVON-10111BK	Screw	2	PCS
H-2	RVON-10111BK	Flat washer	2	PCS
H-3	RVON-10111BK	Spring washer	2	PCS
H-4	RVON-10111BK	Spring	1	PCS
I-2	RVON-10111BK	Screw	4	PCS
I-3	RVON-10111BK	Right pedal tube set	1	SET
J-1	RVON-10111BK	Front stabilizer set	1	SET
J-2	RVON-10111BK	Nap	2	PCS
J-3	RVON-10111BK	Roller	2	PCS
J-4	RVON-10111BK	Nut	2	PCS
J-5	RVON-10111BK	End cap	2	PCS
J-6	RVON-10111BK	Bushing	2	PCS
J-7	RVON-10111BK	C ring	2	PCS
K-1	RVON-10111BK	Rear stabilizer set	1	SET
K-2	RVON-10111BK	End cap	2	PCS
K-3	RVON-10111BK	Nap	2	PCS
L-1	RVON-10111BK	Idler set	1	SET
L-2	RVON-10111BK	Screw	1	PCS
L-3	RVON-10111BK	Flat washer	1	PCS
L-4	RVON-10111BK	Jockey wheel	1	PCS
L-5	RVON-10111BK	Flat washer	1	PCS
L-6	RVON-10111BK	Screw	1	PCS
L-7	RVON-10111BK	Nut	1	PCS
L-8	RVON-10111BK	Spring	1	PCS
L-9	RVON-10111BK	Spring bracket	1	PCS
L-10	RVON-10111BK	Wave washer	2	PCS
L-11	RVON-10111BK	Screw	1	PCS
P	RVON-10111BK	Hardware kit	1	SET
P-1	RVON-10111BK	Screw	4	PCS
P-2	RVON-10111BK	Nut	8	PCS
P-3	RVON-10111BK	Screw	4	PCS
P-4	RVON-10111BK	Semi washer	4	PCS
P-5	RVON-10111BK	Flat washer	2	PCS
P-6	RVON-10111BK	Nylon	2	PCS
P-7	RVON-10111BK	Flat washer	2	PCS
P-8	RVON-10111BK	Knob of pedal	4	PCS
P-9	RVON-10111BK	SCREW	4	PCS
P-10	RVON-10111BK	Sping washer	4	PCS
P-11	RVON-10111BK	Bushing	4	PCS
P-12	RVON-10111BK	Screw	1	PCS
P-13	RVON-10111BK	Flat washer	1	PCS
P-14	RVON-10111BK	Spring washer	1	PCS
P-15	RVON-10111BK	Screw	8	PCS
P-16	RVON-10111BK	Screw	4	PCS
P-17	RVON-10111BK	Flat washer	4	PCS
P-18	RVON-10111BK	Flat washer	4	PCS
P-19	RVON-10111BK	Bushing wrench	2	PCS
P-20	RVON-10111BK	Six wrench	2	PCS
P-21	RVON-10111BK	Six wrench	1	PCS

Q-1	RVON-10111BK	Axle set	1	SET
Q-2	RVON-10111BK	Bushing	1	PCS
Q-3	RVON-10111BK	Screw	3	PCS
Q-4	RVON-10111BK	Pulley	1	PCS
R-1	RVON-10111BK	Disc set	2	SET
R-2	RVON-10111BK	Cross-brace	2	PCS
R-3	RVON-10111BK	Disc	2	PCS
R-4	RVON-10111BK	Screw	8	PCS
R-5	RVON-10111BK	Flat washer	8	PCS
S-1	RVON-10111BK	Pedal bracket set	2	SET
S-2	RVON-10111BK	Bearing	4	PCS
S-3	RVON-10111BK	Flat washer	2	PCS
S-4	RVON-10111BK	Rubber washer	4	PCS
S-5	RVON-10111BK	Nut	2	PCS
S-6	RVON-10111BK	Wave washer	2	PCS
S-7	RVON-10111BK	Flat washer	4	PCS
S-8	RVON-10111BK	C ring	2	PCS