








# HANAU 1

- |  |  |
|--|--|
| <b>D</b> Montageanleitung<br><< HANAU 1 >>             | <b>GB</b> Assembly instructions<br><< HANAU 1 >>   |
| <b>FR</b> Notice de montage<br><< HANAU 1 >>           | <b>IT</b> Istruzioni di montaggio<br><< HANAU 1 >> |
| <b>NL</b> Handleiding voor de montage<br><< HANAU 1 >> | <b>PL</b> Instrukcja montażu<br><< HANAU 1 >>      |
| <b>CZ</b> Montážní návod<br><< HANAU 1 >>              | <b>SK</b> Návod na montáž<br><< HANAU 1 >>         |
| <b>HU</b> Szerelési útmutató<br><< HANAU 1 >>          | <b>RO</b> Instrucțiuni de montaj<br><< HANAU 1 >>  |
| <b>TR</b> Montaj talimatı<br><< HANAU 1 >>             | <b>RU</b> Инструкция по монтажу<br><< HANAU 1 >>   |




 <b>60 MIN</b>	 <b>x2</b>	   <b>10 mm</b>
--	---	--



L





R





I L





I R





II L




II R





III L





III R




IV L





IV R





V



VI L



VI R




**Service • Assistenza • Dienstverlening • Serwis  
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam  
Nazwa • Jméno • Názov • Név  
Denumire • Isim • Название

**HANAU 1**

Nr. • No. • N° • Номер • Č • Sz

**11196069  
20256765  
24413366  
96142107**



Ax1	Bx1	Cx1	Dx1	Ex1	Fx1	Gx1	Hx1	Ix1	Jx1	Kx1	Lx1	L1x1	L2x1	Mx1	Nx1	Px1	Rx2
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	------	------	-----	-----	-----	-----

①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬
12	4	8	4	2	4	2	1	1	4	44	16	4
M6x35	M6x50	M6x80	Ø4.5x18	25x25	M6x70	Ø3.5x30		60x60	Ø3.5x16	Ø 6	M6	Ø8x30





# HANAU 1

**(D)** Montageanleitung  
<< HANAU 1 >>

**(FR)** Notice de montage  
<< HANAU 1 >>

**(NL)** Handleiding voor de montage  
<< HANAU 1 >>

**(CZ)** Montážní návod  
<< HANAU 1 >>

**(HU)** Szerelési útmutató  
<< HANAU 1 >>

**(TR)** Montaj talimati  
<< HANAU 1 >>

**(GB)** Assembly instructions  
<< HANAU 1 >>



**(IT)** Istruzioni di montaggio  
<< HANAU 1 >>

**(PL)** Instrukcja montażu  
<< HANAU 1 >>


**(SK)** Návod na montáž  
<< HANAU 1 >>

**(RO)** Instrucțiuni de montaj  
<< HANAU 1 >>


**(RU)** Инструкция по монтажу  
<< HANAU 1 >>




1




2



3




4



Service • Assistenza • Dienstverlening • Serwis  
 Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam  
 Nazwa • Jméno • Názov • Név  
 Denumire • Isim • Название

HANAU 1








Nr. • No. • N° • Номер • Č • Sz

14855764  
 33738619



Ax1 Bx2 Cx1

①	②	③	④	⑤
7	7	4	7	4
		7X70 mm		
				

0 10 20 30 40 50 60 70 80 90 100

