



MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 INSTRUKCJA MONTAŻU
 ИНСТРУКЦИЯ СБОРКИ
 KÜCHEN SCHRÄNKE
 KITCHEN CABINET
 SZAFKI KUCHENNE
 КУХОННЫЙ ШКАФЪ



TYPE:R






















TYPE:L

D12R





ST *fabryka mebli* LPLYT®

EXTOM
MEBLE









TYPE:L





FOX GOLD



FOX BRONZE



TYPE:R



FOX SILVER,
FOX SILVER LUX,
FOX PLATINUM

