

# User's manual

## Instructions for use

- Insert the charger into the wall outlet.  
( Connect one end of the charging cable to the charging port of the device  
(phone, portable speaker, external battery, etc.)
- Connect the other end of the cable to the port  
USB of the charger.
- Disconnect the device when it is complete Loaded.

## Precautions

- To beware of children and pets.
- Protect the product from humidity. Do not expose the product to rain or charged air With moisture. Beware liquid product.
- Protect the product from fire and heat sources. Not close the product to the fire or other sources of heating (stoves, radiators et.)
- Discarding the product. Do not throw away the product or the other electronic components together with household garbage, Use only specialized centers for the collection of electronic waste.

### WASTE DISPOSAL:

The adjacent symbol shows that, in accordance with local laws and regulations, your product and /or its battery must be disposed of separately from the waste Household. When this product reaches the end of its life, take them to a collection point designated by the local authorities. For information about local collection centers please contact the city hall your locality.

MADE IN CHINA

