



BINGO

SOFA



15 min



(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions






(IT) Istruzioni di montaggio

(PL) Instrukcja montażu


(SK) Návod na montáž

(RO) Instrucțiuni de montaj


(RU) Инструкция по монтажу






1



2



3



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба





Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Isim • Название

BINGO


Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo •
Тип


SOFA




Ax...



Bx...



Cx...



Dx...

