






Art. Nr. 1570 1051,4621 2763

LKZ 41164



- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montazu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instrucțiuni de montaj |
| (TR) Montaj talimati | (RU) Инструкция по монтажу |








N	Size/MaB (mm)	Qty	✓	N	Size/MaB (mm)	Qty	✓
1	2020x261x22	2		4	970x150x16	1	
2	1898x60x16	1		5	952x261x19	1	
3	1898x60x16	1		6	986x1160x72	1	
				7	1900x48x35	2	

Service - Dienstverlening - Serwis - Servis - Сервисная служба

Name - Naam - Nazwa - Isim - Название

Nr. - No. - Номер


Typ - Type - Тип - Тип



1

x2

134613





x4

010942



4x16


x16



2



x2

000151



8x35

x10




3

000146




15x12

x4



4

A
090913
L
230041







7x32






x2






22x16

x3




5

B		x2
C		15x12 x2
J		x2
K		M8 x2
L		22x16 x2




6 x2


172324 4x50
x12



7

101608 7x50
x14





- H**
000083 M6x12
x8
- M**
238966 inosign
x1
- H**
010942 4x16
x16

