











<p><b>Ax1</b></p> 	<p><b>Bx1</b></p> 	<p><b>Cx4</b></p> 	<p><b>Dx12</b></p>  <p>M8*12MM</p>	<p><b>E x 4</b></p>  <p>M6*12MM</p>
<p><b>Fx1</b></p>  <p>M5</p>	<p><b>Gx8</b></p>  <p>M8*16MM</p>			



- (D) Bitte überprüfen Sie in regelmäßigen Abständen den festen Sitz der Schrauben!
- (GB) Please check the screws for tightness at regular intervals!
- (F) Veuillez contrôler régulièrement que les vis sont convenablement serrées !
- (ES) ¡Compruebe periódicamente que los tornillos estén bien apretados!
- (IT) Controllare regolarmente che le viti siano ben strette!
- (PL) Należy regularnie sprawdzać dokręcenie śrub!
- (NL) Controleer op regelmatige afstanden of de schroeven goed vast zitten.
- (SWE) Kontrollera med jämna mellanrum att skruvarna sitter fast ordentligt!
- (SK) V pravidelných intervaloch kontrolujte pevné dotiahnutie skrutiek!
- (SL) Redno preverjajte, ali so vijaki trdno priviti!
- (HR) Redovito provjeravajte čvrsto nalijeganje vijaka!