


MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 INSTRUKCJA MONTAŻU
 ИНСТРУКЦИЯ СБОРКИ
 KÜCHEN SCHRÄNKE
 KITCHEN CABINET
 SZAFKI KUCHENNE
 КУХОННЫЙ ШКАФЪ



FOX




TYPE:L TYPE:R
 D14DP

ST fabryka mebli LPLYT®





EXTOM
 MEBLE





TYPE:L





TYPE:R





FOX GOLD




FOX BRONZE



FOX SILVER, SILVER+
FOX SILVER LUX,
FOX PLATINUM, PLATINIUM+



Klotz, Block, Griff, Handle,
Клосок, Кубик, Uchwyt, Ручка



8

3

n1

n2

o1

o1

o2