





- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (HU) Szerelési útmutató
- (GB) Assembly instructions



- (PL) Instrukcja montażu
- (RO) Instrucțiuni de montaj
- (FR) Notice de montage
- (CZ) Montážní návod
- (TR) Montaj talimatı
- (IT) Istruzioni di montaggio
- (SK) Návod na montáž
- (RU) Инструкция по монтажу

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название


Nr. • No. • N° • Номер • Č • Sz

Tur • Type • Tip • Típus • Tipo •
Тип




1	1x	ca. 2002 x 330 mm
2	1x	ca. 1983 x 330 mm
3	1x	ca. 2002 x 330 mm
4	1x	ca. 318 x 330 mm
5	1x	ca. 318 x 315 mm





6	1x	ca. 318 x 315 mm
7	2x	ca. 1074 x 172 mm
8	2x	ca. 1044 x 307 mm
9	2x	ca. 1057 x 104 mm
10	2x	ca. 347 x 459 mm




A 8,0 x 30 mm 16x	B 16x	C 16x	D 6x	E 3,9 x 9,5 mm 12x	F 7x	G 4,0 x 20 mm 7x
H 4x	I 4x	J M4,0 x 9 mm 4x	K 2,7 x 20 mm 6x	L 27 x 310 mm 4x	M 6,3 x 13 mm 16x	
N 1x	O 8x					




1





2



A 8,0 x 30 mm  16x	B  16x	C  16x	I  4x	h=2	L 27 x 310 mm  4x	M 6,3 x 13 mm  8x
D  6x	E 3,9 x 9,5 mm  12x					




3



4





D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей




5

J M4,0 x 9 mm
4x




➔ 7 / 8




- (D) **Push-To-Open** einstellen
- (GB) Adjusting the Push-To-Open
- (FR) Régler les **Push-To-Open**
- (IT) Sistemare **Push-To-Open**
- (NL) **Push-To-Open** instellen
- (PL) Nastawić **Push-To-Open**
- (CZ) Vyrovnajte **Push-To-Open**
- (RO) Nastavenie **Push-To-Open**
- (HU) Állítsa be az **Push-To-Open**
- (SK) Reglare **Push-To-Open**
- (TR) **Push-To-Open** ayarlanması
- (RU) Регулировка **Push-To-Open**

➔ 8 / 8



- (D) **Türen einstellen**
(Scharniere justieren)
- (GB) Adjusting the doors
(adjusting the hinges)
- (FR) Régler les portes
(ajuster les charnières)
- (IT) Sistemare le porte
(regolare le cerniere)
- (NL) Deuren instellen
(scharnieren afstellen)
- (PL) Nastawić drzwi
(wyregulować zawiasy)
- (CZ) Vyrovnajte dvířka
(seřid'te závěsy)
- (RO) Nastavenie dverí
(nastavenie závesov)
- (HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)
- (SK) Reglare uši
(ajustare balamale)
- (TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)
- (RU) Регулировка дверей
(регулировка шарнира)



(D) **Push-To-Open** einstellen

(GB) **Adjusting the Push-To-Open**

(FR) **Régler les Push-To-Open**

(IT) **Sistemare Push-To-Open**

(NL) **Push-To-Open** instellen

(PL) **Nastawić Push-To-Open**

(CZ) **Vyrovnejte Push-To-Open**

(RO) **Nastavenie Push-To-Open**


(HU) **Állítsa be az Push-To-Open**

(SK) **Reglare Push-To-Open**



(TR) **Push-To-Open** ayarlanması


(RU) **Регулировка Push-To-Open**

1.



2.





(D) Türen einstellen
(Scharniere justieren)

(GB) Adjusting the doors
(adjusting the hinges)

(FR) Régler les portes
(ajuster les charnières)

(IT) Sistemare le porte
(regolare le cerniere)

(NL) Deuren instellen
(scharnieren afstellen)

(PL) Nastawić drzwi
(wyregulować zawiasy)

(CZ) Vyrovnajte dvířka
(seřid'te závěsy)

(RO) Nastavenie dverí
(nastavenie závesov)

(HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)

(SK) Reglare uši
(ajustare balamale)

(TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)

(RU) Регулировка дверей
(регулировка шарнира)

