



MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 INSTRUKCJA MONTAŻU
 ИНСТРУКЦИЯ СБОРКИ
 KÜCHEN SCHRÄNKE
 KITCHEN CABINET
 SZAFKI KUCHEENNE
 КУХОННЫЙ ШКАФЪ

FOX

















D8Z






ST fabryka mebli **LPLYT**®

EXTOM
MEBLE




 b1 x4	 c1 Euro 4x13 x8	 g0 x6	 g1 7x50 x6	 n1 3x16 x20	 n2 3,5x16 x28	 o1 x4	 o2 x4	 p0 x4	 r x2	 a1 8x35 x6	 b0 x4
---	--	--	---	--	--	---	---	---	--	---	---








FOX GOLD



FOX BRONZE



**FOX SILVER,
FOX SILVER LUX,
FOX PLATINUM**



Klotz, Block, Griff, Handle, Клосек, Кубик, Uchwyt, Ручка

