

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
Tefal	814220	Handmixer 814220 Prep'Line
SEB	814224	prep'line200+PiedMixer
SEB	814230	prep'line
SEB	814231	prep'line200+PiedMixer
SEB	814281	prep'line200+PiedMixer
SEB	814282	prep'line
SEB	814204A	prep'line200+PiedMixer
SEB	814211A	prep'line200+PiedMixer
SEB	814213A	prep'line200+PiedMixer
SEB	814227A	prep'line200+PiedMixer
SEB	814237A	prep'line200+PiedMixer
SEB	814288A	prep'line200+PiedMixer
SEB	814290A	prep'line200+PiedMixer
SEB	814295A	prep'line200+PiedMixer
Tefal	814413A (DE)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814413A (TR)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814211A (AT)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (BA)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (BG)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (DE)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (HR)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (RO)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (SI)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814211A (YU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814490A (TR)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814213A (AT)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (BA)	GARDES PREP'LINE 200 PIED MIXER

Tefal	814213A (BG)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (CH)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (HR)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (RO)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (RU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (SA)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (SI)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (TR)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814213A (YU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814288A (RU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (BA)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (BG)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (DE)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (HR)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (RO)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (SI)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814231 (YU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814431 (AT)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814431 (PT)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814431 (RU)	GARDES PREP'LINE MIXER STAND BOWL 200
Tefal	814281 (RU)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (AT)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (BA)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (BG)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (DE)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (DK)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (ES)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (FI)	GARDES PREP'LINE 200 PIED MIXER
Tefal	814290A (HR)	GARDES PREP'LINE 200 PIED MIXER

Tefal	814290A (IT)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (NL)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (NO)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (PT)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (RO)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (RU)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (SE)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (SI)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (TR)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814290A (YU)	GARDES PREP`LINE 200 PIED MIXER
Tefal	814230 (DE)	GARDES PREP`LINE
Tefal	814230 (NL)	GARDES PREP`LINE
Tefal	814230/BV0 (DE)	GARDES PREP`LINE
Tefal	814230/BV0 (NL)	GARDES PREP`LINE
SEB	814227A (FR)	GARDES PREP`LINE 200 PIED MIXER
SEB	814295A (FR)	GARDES PREP`LINE 200 PIED MIXER
SEB	814224 (FR)	GARDES PREP`LINE 200 PIED MIXER
SEB	814237A (FR)	GARDES PREP`LINE 200 PIED MIXER
SEB	814204A (BE)	GARDES PREP`LINE 200 PIED MIXER
SEB	814204A (FR)	GARDES PREP`LINE 200 PIED MIXER
SEB	814220 (BE)	GARDES PREP`LINE
SEB	814220/BV0 (BE)	GARDES PREP`LINE
Tefal	HT411100/BVB	GARDES PREP`LINE
Tefal	HT411133/BVB	GARDES PREP`LINE
Tefal	HT411138/BVB	GARDES PREP`LINE
Tefal	HT41313E/BVB	GARDES PREP`LINE STAND BOWL
Tefal	HT411138/BV0	GARDES PREP`LINE
Tefal	HT411138/BVA	GARDES PREP`LINE
Tefal	HT411133/BV0	GARDES PREP`LINE

Tefal	HT411133/BVA	GARDES PREP`LINE
Tefal	HT41113E/BV0	GARDES PREP`LINE
Tefal	HT41313E/BVA	GARDES PREP`LINE STAND BOWL
Tefal	HT41313E/BV0	GARDES PREP`LINE STAND BOWL
Moulinex	HM411110/BVB	GARDES PREP`LINE
Moulinex	HM411110/BVA	GARDES PREP`LINE
Moulinex	HM411184/BV0	GARDES PREP`LINE
Moulinex	HM41313E/BV0	GARDES PREP`LINE STAND BOWL
SEB	HT411100/BV0	GARDES PREP`LINE
SEB	HT411100/BVA	GARDES PREP`LINE
SEB	HT411121/BV0	GARDES PREP`LINE
Tefal	814432	GARDES PREP`LINE STAND BOWL
Tefal	814432/BV0	GARDES PREP`LINE STAND BOWL
Tefal	814230/BV0	GARDES PREP`LINE
Tefal	814431	GARDES PREP`LINE + MIXER + STAND BOWL 200
Tefal	814282/BV0	GARDES PREP`LINE
Tefal	814413A	GARDES PREP`LINE + MIXER + STAND BOWL 200
Tefal	814490A	GARDES PREP`LINE + MIXER + STAND BOWL 200
SEB	814220/BV0	GARDES PREP`LINE