



















Lindhus






Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Ísim • Название				
Nr. • No. • N° • Номер • Č • Sz				
Typ • Type • Tip • Típus • Tipo Тип				
				
				
AX3			X1	X2
BX1			√	
CX1				√
DX1			√	
EX1				√
FX2			X1	X1
GX3			X1	X2
HX8			√	
IX1			√	
JX1			√	

		2/2	1/2
KX1		✓	
LX8		✓	
MX8		✓	
NX2		✓	
QX16	 M6x25mm	✓	
RX5	 M6x25mm	✓	
SX8	 M6x35mm	✓	
TX1		✓	







1




2




3




4




5




6



7





8





9



①



②



③



④

