

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Moulinex	HM41013EBV0	prepiline
Moulinex	HM411110BVA	prepiline
Moulinex	HM410131BV0	prepiline
Moulinex	HM411184BV0	prepiline
SEB	814131	prepiline200
SEB	814161	prepiline200
SEB	814181	prepiline200
SEB	814187	prepiline200
SEB	814189	prepiline200
SEB	814190	prepiline200
SEB	814194	prepiline200
SEB	814195	prepiline200
SEB	814202	prepiline200+PiedMixer
SEB	814204	prepiline200+PiedMixer
SEB	814211	prepiline200+PiedMixer
SEB	814213	prepiline200+PiedMixer
SEB	814224	prepiline200+PiedMixer
SEB	814227	prepiline200+PiedMixer
SEB	814230	prepiline
SEB	814231	prepiline200+PiedMixer
SEB	814237	prepiline200+PiedMixer
SEB	814281	prepiline200+PiedMixer
SEB	814282	prepiline
SEB	814290	prepiline200+PiedMixer
SEB	814295	prepiline200+PiedMixer
SEB	814101BV0	prepiline200
SEB	81410E32BV0	prepiline

SEB	814117BV0	prepiline
SEB	814120BV0	prepiline
SEB	814130BV0	prepiline
SEB	814137BV0	prepiline
SEB	8141605D0	prepiline
SEB	814160BV0	prepiline
SEB	8141705D0	prepiline
SEB	814170BV0	prepiline
SEB	814182BV0	prepiline
SEB	814204A	prepiline200+PiedMixer
SEB	814211A	prepiline200+PiedMixer
SEB	814213A	prepiline200+PiedMixer
SEB	814220BV0	prepiline
SEB	814227A	prepiline200+PiedMixer
SEB	814230BV0	prepiline
SEB	814237A	prepiline200+PiedMixer
SEB	814282BV0	prepiline
SEB	814288A	prepiline200+PiedMixer
SEB	814290A	prepiline200+PiedMixer
SEB	814295A	prepiline200+PiedMixer
SEB	HT410121BV0	prepiline
SEB	HT410133BV0	prepiline
SEB	HT410138BV0	prepiline
SEB	HT41013EBV0	prepiline
SEB	HT410151BV0	prepiline
SEB	HT410162BV0	prepiline
SEB	HT410E32BV0	prepiline
SEB	HT411100BV0	prepiline
SEB	HT411121BV0	prepiline

SEB	HT411133BV0	prepíline
SEB	HT411138BV0	prepíline
SEB	HT41113EBV0	prepíline
Tefal	814120	Handmixer 814120 PrepíLine
Tefal	814101	Handmixer 814101 PrepíLine
Tefal	8141	Handmixer 8141 PrepíLine
Tefal	8140	Handmixer 8140 PrepíLine
Tefal	814220	Handmixer 814220 PrepíLine
Tefal	814182	Handmixer prepíline
Tefal	814130	Handmixer prepíline