


MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 INSTRUKCJA MONTAŻU
 ИНСТРУКЦИЯ СБОРКИ
 KÜCHEN SCHRÄNKE
 KITCHEN CABINET
 SZAFKI KUCHEENNE
 КУХОННЫЙ ШКАФЪ


FOX



TYPE:L TYPE:R
 D14 RU

ST fabryka mebli LPLYT®


EXTOM
 MEBLE







a1 8x35 x40	b0 x4	b1 x4	c1 Euro 4x13 x8	d2 x4
------------------------------	---------------------	---------------------	----------------------------------	---------------------

g0 x30	g1 7x50 x30	n1 3x16 x10	n2 3,5x16 x28	o1 x4	o2 x4	p0 x10	p9 x1	r4 x20	w x2
----------------------	------------------------------	------------------------------	--------------------------------	---------------------	---------------------	----------------------	---------------------	----------------------	--------------------



TYPE:L






TYPE:R



FOX GOLD



FOX BRONZE



FOX SILVER, SILVER+
FOX SILVER LUX,
FOX PLATINUM, PLATINIUM+

