

# Instructions for use



**1**  
Open the waterproof case. find the ① lock button to open it

**2**  
Put in the action camera



**3**  
Lock the waterproof case and buckle the back cover to complete