






# PP198788AAG/ PP198788AAP/ PP198789AAG

## CUSTOMER SERVICE

All the legs and screws of the dining chair are placed at the bottom of the chair. Opening the cover and you will see them.

If you are missing parts or have any questions about this product, contact our customer service representative first!

HARDWARE LIST	CODE	PARTS	QTY.
	1	BACK	1
	2	SEAT	1
	3	BACK LEG B	2
	4	FRONT LEG F	2

HARDWARE LIST	CODE	PARTS	QTY.
	A	M8x55MM  	9
	B	M8x60MM  	4
	C	ALLEN KEY 	1

