

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
Neff	B84H42N3MC/01	Mega SHH 8442 N
Neff	B84H42N5MC/01	Mega SHH 8445 N
Neff	B44S42N3GB/01	
Neff	B46E74N0S/01	
Neff	B86H54N1MC/01	
Neff	B85H42N0MC/35	
Neff	B45M42N0/35	
Neff	B45E42N0RU/01	
Neff	B85H54N0MC/01	
Neff	B45E62N0/35	
Neff	B46E74N1/01	
Neff	B45E42N0/35	
Neff	B45SW5N0/35	
Neff	B46C74N3FR/01	
Neff	B85H64N0MC/35	
Neff	B45E42N0S/01	
Neff	B48H52N0KE/35	
Neff	B45SW5N0/01	
Neff	B46E74N0S/35	
Neff	B45E62N0/01	
Neff	B45M42N0/01	
Neff	B45M44N0/01	
Neff	B46E74N0/01	
Neff	B45E42N0/01	
Neff	B44M52N5FR/01	
Neff	B45E54N0/01	
Neff	B95H72N0MK/01	

Neff	B85H42N0MC/01	
Neff	B85H64N0MC/01	
Neff	B48H52N0KE/01	
Neff	B46W74N0/01	
Neff	B46W74N0/07	
Neff	B45M44N0/35	
Neff	B46E74N0RU/35	
Neff	B46E74N0RU/01	
Neff	B86H54N3MC/01	
Neff	B45E54N0/35	
Neff	B95H72N0MK/35	
Neff	B44M62N0FR/01	
Neff	B44M42N0/01	
Neff	B45E52N0FR/01	
Neff	B45E42N0GB/35	
Neff	B46E64N0AU/35	
Neff	B96C43N0MK/01	
Neff	B45E74N0GB/01	
Neff	B44M62N0FR/35	
Neff	B45C42N3RU/01	
Neff	B46E64N0AU/01	
Neff	B86C74N0MC/35	
Neff	B46C74N0GB/01	
Neff	B44M62N0GB/01	
Neff	B46E74N0GB/01	
Neff	B45M62N0GB/35	
Neff	B46C74N0/35	
Neff	B85C64N0MC/35	
Neff	B44M42N0GB/01	

Neff	B45E54N0GB/35	
Neff	B44M42N3S/01	
Neff	B44M52N0FR/01	
Neff	B45M42N0GB/01	
Neff	B44M62N0GB/35	
Neff	B46W74N0GB/01	
Neff	B45C42N0/01	
Neff	B45C42N0GB/35	
Neff	B46E74N0GB/35	
Neff	B45E52N0FR/35	
Neff	B46C74N0S/01	
Neff	B46C42N0/01	
Neff	B45E42N3S/01	
Neff	B45E42N0GB/01	
Neff	B44M52N0FR/35	
Neff	B44M42N0S/01	
Neff	B45E54N0GB/01	
Neff	B45C42N0GB/01	
Neff	B45M62N0GB/01	
Neff	B46C42N0/35	
Neff	B45M42N0GB/35	
Neff	B46C74N0/01	
Neff	B86C74N0MC/01	
Neff	B45E54N3/01	
Neff	B96C43N0MK/35	
Neff	B85C64N0MC/01	
Neff	B46C74N0GB/35	
Neff	B46W74N0GB/07	
Neff	B45C42N0/35	

Neff	B44M42N0/35	
Neff	B44M42N5/70	
Neff	B44M62N5FR/70	
Neff	B44M52N5FR/70	
Neff	B48E52N3KE/01	
Neff	B45C42N3/01	
Neff	B44M42N3/01	Mega SHM 4442 N
Neff	B46E74N3FR/01	
Neff	B45M52N3GB/01	
Neff	B44M42N5GB/01	
Neff	B44S52N5GB/01	
Neff	B45M42N3AU/05	
Neff	B45C44N3AU/05	
Neff	B46C74N3GB/01	
Neff	B46E54N3GB/04	
Neff	B45E54N3GB/01	
Neff	B46E74N3AU/04	
Neff	B44M42N5/01	Mega SHM 4445 N
Neff	B46E74N3GB/01	
Neff	B45E62N3/01	
Neff	B45M42N5FR/01	
Neff	B96C43N3MK/01	
Neff	B45E44N3AU/01	
Neff	B46C74N3AU/04	
Neff	B46E74N3AU/05	
Neff	B45E43N3FR/01	
Neff	B45E42N3FR/01	
Neff	B44S42N3GB/04	
Neff	B45M42N3/01	Mega SHM 4542 N

Neff	B46E74N3/01	
Neff	B45E52N3GB/01	
Neff	B44M62N3FR/01	
Neff	B46C74N3S/01	
Neff	B44M62N5FR/01	
Neff	B45E44N3AU/04	
Neff	B46E74N3AU/01	
Neff	B45E42N3RU/01	
Neff	B45M42N3RU/01	
Neff	B44M42N3GB/04	
Neff	B45M42N5/01	Mega SHM 4545 N
Neff	B46C74N3AU/01	
Neff	B45M42N3AU/01	
Neff	B45C42N3FR/01	
Neff	B44M42N3FR/01	
Neff	B85C64N3MC/01	
Neff	B45E42N3/01	
Neff	B46C74N3AU/05	
Neff	B44M43N5GB/01	
Neff	B44S32N3GB/04	
Neff	B45M42N3AU/04	
Neff	B46E74N3GB/04	
Neff	B45M62N5FR/01	
Neff	B45CA5N3/01	
Neff	B45C52N3GB/01	
Neff	B44S53N5GB/01	
Neff	B44S43N3GB/01	
Neff	B45E44N3AU/05	
Neff	B45E74N3GB/04	

Neff	B46E54N3GB/01	
Neff	B45C44N3AU/01	
Neff	B45E52N3FR/01	
Neff	B95H72N3MK/01	
Neff	B85H42N3MC/01	
Neff	B46C42N3/01	
Neff	B44M52N3FR/01	
Neff	B46E74N3RU/01	
Neff	B45E52N3GB/04	
Neff	B45M42N3S/01	
Neff	B46C74N3GB/04	
Neff	B45E54N3GB/04	
Neff	B45C42N3S/01	
Neff	B45M62N3FR/01	
Neff	B44M43N3GB/01	
Neff	B46C74N3/01	
Neff	B45M54N3GB/01	
Neff	B95H42N3MK/01	
Neff	B45M54N3GB/04	
Neff	B45C44N3AU/04	
Neff	B46E74N3S/01	
Neff	B44S32N3GB/01	
Neff	B45M52N3GB/04	
Neff	B45E74N3GB/01	
Neff	B86C74N3MC/01	
Neff	B45M44N3/01	
Neff	B44S32N5GB/01	
Neff	B46W74N3/01	
Neff	B44M42N3GB/01	

Neff	B85H64N3MC/01	
Neff	B45C52N3GB/04	
Neff	B84H42N5MC/70	
Neff	B45M42N5/70	
Neff	B45M42N5FR/70	
Neff	B45E42N0RU/35	
Neff	B46W74N0/35	