

# ASSEMBLY INSTRUCTIONS

Couchtisch  
Buyer Code:- 71004-40



Dx10




Ex10




Fx1



1




3




(A+B+C)+D+E+F

2



4

ASSEMBLED VIEW



A+B+C