


# HAITI II (2AL-MaxiRC)



- |    |                             |    |                           |
|----|-----------------------------|----|---------------------------|
| ⓁⒹ | Montageanleitung            | ⓁⒹ | Istruzioni di montaggio   |
| Ⓟ  | Instrukcja montażu          | ⓁⒹ | Notice de montage         |
| ⓃⓁ | Handleiding voor de montage | ⓇⓄ | Instructiuni de asamblare |
| ⒼⒷ | Assembly instructions       | ⓈⓀ | Montážny návod            |
| ⓉⓇ | Montaj talimatı             | ⒸⓏ | Montážní návod            |
| ⓇⓊ | Инструкция по монтажу       | ⓇⓊ | Szerelési útmutató        |




Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio  
 Service - Serviciu - Služby - Szolgáltatás

Name - Nazwa - Naam - Name - Isim - название  
 Nome - Nom - Numele - Meno - Jméno - Neve









HAITI II (2AL-MaxiRC)

F1 L-280 H-70  x3	F2 L-200 H-70  x2	F3 H-70  x4	S1 M5x50  x14	T1  x14	P1 55x55  x5	P2 45x45  x2
----------------------------	----------------------------	----------------------	------------------------	---------------	-----------------------	-----------------------









# 2AL



 <b>F1</b>	L-280 H-70	 <b>F2</b>	L-200 H-70	 <b>F3</b>	H-70	 <b>S1</b>	M5x50	 <b>T1</b>	x6
<b>x1</b>		<b>x1</b>		<b>x2</b>		<b>x6</b>		<b>x6</b>	

# MaxiRC



 <b>F1</b>	L-280 H-70	 <b>F2</b>	L-200 H-70	 <b>F3</b>	H-70	 <b>S1</b>	M5x50	 <b>T1</b>	x8
<b>x2</b>		<b>x1</b>		<b>x2</b>		<b>x8</b>		<b>x8</b>	