
BW92000 Instruction for Installation and Operation

⚠ WARNING! THIS INSTRUCTION MANUAL SHALL BE READ BEOFRE THE USE AND THE INSTALLATION OF THE PRODUCT ⚠ WARNING - IT IS IMPORTANT FOR SAFETY OF PERSONS TO FOLLOW THESE INSTRUCTIONS. SAVE THESE INSTRUCTIONS

FOR FUTURE REFERENCE

DO NOT RELEASE THE HANDLE GRIP WHEN

EXTRACTING/RETRACTING THE FABRIC SCREEN



Contents


| ►Specifications/Precautions and safety | | | | | | |
|---|-----------|--|--|--|--|--|
| warnings for installation and operation. | • 1 | | | | | |
| ► Accessories and required tools · · · | • (2) | | | | | |
| ►Installation procedure | • (3) (4) | | | | | |
| ► Operation instructions · · · · · · | • 4 | | | | | |
| ► Maintenance · · · · · · · · · · · · · · · · · · · | • (5) | | | | | |
| ►Name list of parts · · · · · · | • 6 | | | | | |

Specification

| Artical number | Actual size (cm) | Shade Dimension (cm) | Net weight (Kg) | Fabric | Wind resistance class |
|----------------|------------------|-------------------------|-----------------|-----------|-----------------------|
| BW92000 | 160×300 | 151×300 | | Polyester | Class 1 (28Km/h) |



Precautions and safety warning for installation and operation



READ THE INSTRUCTION BEFORE USING THE PRODUCT

Attention! 1


Before opening the folding screen, make sure all the fixing bolts and security devices are properly installed and tightened.

Always close the folding screen during rainy days, windy days or the folding screen is not in use. Failed to observe the instrution may lead to material and constructional damage of the folding screen. Never try to disassemble the folding screen or repiar the folding screen by yourself. Consult a competent technician for help.


Symbol explanation:

- Means it is forbidden
- Means important
- Never install it in high and windy places, as the sunshade may drop and hurt people.
- When you are ready to unpack and assemble the folding screen, make sure that you have the appropriate tools, sufficient operators (2 persons are suggested) and space, and a clean and dry area to perform the installation."
- Don't use it in places that have vibrations or impulsions.
- The installation can be made by non-professionals assuming the instruction is followed correctly. Should you have any trouble during assembly, please consult a qualified person for help.
- Please use all the screws and nuts correctly during installation as it is very dangerous if you leave it loose.
- Se careful with your finger during installation.
- Don't use it in places of high temperature such as walls near furnaces.
- Don't hang anything on the frame or on the folding arms as the awning may fall down and cause damage or personal injury.
- Never use it in rainy and windy days.
- Never use it for other purposes.
- The operation in frosty conditions may damage the folding screen.
- Please close the awning in windy and rainy days.
- No modification of the folding screen in any kind is allowed.
- Save enough free space around the awning while rolling or unrolling.
- Do not barbecue under the folding screen or ignite a fire near to the folding screen.
- O Do not open the folding screen when maintenance, such as window cleaning, is being carried out in the vicinity.
- Check the awning every 3 months to ensure all fixing are tightened and no damage on the products.
- ① Do not use the folding screen if repair is needed.Do not try to repair the product by yourself,contact qaulified person for repairing.
- Do not use the folding screen in frosty conditions.
- Prohibit Peng rapid recovery, so as to avoid injuring people and damage to the pont.


Accessories and required tools




Please prepare below tools before installation:




Power drill with drilling bit of Ø8mm and Ø10mm




Tape measure




Wrench (wrenches of M6)




Screwdriver



The other installation method when two wall face to each other:




Opened the folding screen and fix the handle grip on the fastness bracket.



Operation instructions


CAUTION! DO NOT RELEASE THE HANDLE GRIP WHEN EXTRACTING / RETRACTING THE FABRIC SCREEN!

- 1) Open / Extraction
- i) Hold the handle grip firmly throughout the whole extraction process.
- ii) Pull the handle grip out of the folding screen gently.
- iii) Slowly walk toward the fastness bracket.
- iv) Secure the handle grip on the knot of fastness bracket.
- 2) Close / Retraction
- i) Hold the handle grip firmly throughout the whole retraction process.
- ii) Unlock the handle grip from the fastness bracket.
- iii) Slowly walk toward the folding screen until whole fabric screen be rolled into it.



Maintenance

- 1. Always close the Fold Screen in windy days, heavy rain and when you are not using it.
- 2. Pls do not unpick and wash the fabric. If you need replace the fabric, please turn to experts for help.
- 3. Check the overall installation and all the fasteners regularly, especially at the beginning of a new season, to ensure the fasteners are tightened and in good conditions.



※Note:

1. When the parts with ◆ are damaged, don't use the product before they are replaced.