




Hoskins



- | | | | |
|-------------|------------------------------------|-------------|--------------------------------|
| (D) | Montageanleitung | (GB) | Assembly instructions |
| (FR) | Notice de montage | (IT) | Istruzioni di montaggio |
| (NL) | Handleiding voor de montage | (PL) | Instrukcja montażu |
| (CZ) | Montážní návod | (SK) | Návod na montáž |
| (HU) | Szerelési útmutató | (RO) | Instrukțiuni de montaj |
| (TR) | Montaj talimati | (RU) | Инструкция по монтажу |



110 kg-MAX



LKZ 41507

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**




Name • Nom • Nome • Naam •
Nazwa • Jméno • Název • Név •
Denúmir • Ísim • Название **Hoskins**

Nr. • No. • N° • Номер • Č • Sz
69730347, 38701050, 97923022, 23942466,
28813926, 17684842

Typ • Type • Tip •
Típus • Tipo • Тип



1



A H=60 x4	B 5x50 x4	C Luch L200 x2	D Luch x2	E 4x20 x16
----------------------------	----------------------------	---------------------------------	----------------------------	-----------------------------

x2

