




# **INSTALLATION GUIDE**



# WALL MOUNTED BATHROOM SINK FAUCET

MODEL	FINISH
S1393CI	CHROME
S1393NI	BRUSHED NICKEL
S1393DI	MATTE DARK
S1393OI	OIL RUBBER BRONZE
S1393BGI	Brushed Gold



### **THANK YOU**

**Dear Valued Customer,** 

SUMERAIN would like to take this opportunity to thank you for purchasing SUMERAIN products. It is our sincere hope that you are completely satisfied with your new purchase. All SUMERAIN products are carefully engineered, and factory tested to provide long trouble-free use under normal conditions. This product is easy to install using basic tools and our easy to follow illustrated instructions. We welcome any questions or comments you may have and look forward to assisting you in the future. If you have any questions regarding this product, call +1-866-203-0866 or email to <a href="mailtosupports@sumerain.com">supports@sumerain.com</a>. Sincerely,

**SUMERAIN** customer service department

## **BEFORE PROCEEDING**

- 1. Unpack your new product and ensure that all the parts are contained in the packaging. Keep the product in its original box until you ready to install it.
- 2. Locate water supply inlets and shut off the water supply valves. These are usually found near the water meter. if you are replacing an existing unit, remove the old unit and clean the mounting surface thoroughly.
- 3. Observe all plumbing and building codes in your area.
- 4. It is recommends calling professional if you are uncertain about installing this product.

### **TOOLS RECOMMENDED**



### LIMITED LIFETIME CONSUMER WARRANTY

**VERSION: 140320.15.3** 

This product has been manufactured and tested to the highest quality standards by SUMERAIN sanitary Inc("SUMERAIN"). This warranty is limited to SUMERAIN products which are purchased by a consumer in the China after Jan 1,2010 and installed in China or the state which has SUMERAIN technical support department locally. (visit http://www.sumerain.com/en/supportcenter.asp for review the state list of SUMERAIN technical support department). If the faucet should leak or drip during normal use, SUMERAIN will, free of charge, mail to the purchaser the cartridge necessary to put the faucet in good working condition. If a defect is found in normal residential use, SUMERAIN will, at its election, repair, provide a replacement part or product, or make appropriate adjustment.

#### WHO IS COVERED BY THE WARRANTY

This warranty extends to the original consumer purchaser only (exclusive online retail original customer, online retail original customer cover by the "Online CONSUMER Limited Lifetime WARRANTY & Return policy"), This warranty is not-transferable.

#### WHAT IS COVERED BY THE WARRANTY

This warranty covers only your SUMERAIN manufactured product. SUMERAIN warrants this product against defects in material or workmanship as follows: SUMERAIN will repair at no charge for parts only or, at its option, replace any product or part of the product that proves defective because of improper workmanship and/or material, under normal installation, use, service and maintenance. If SUMERAIN unable to provide replacement, SUMERAIN may elect to provide similar model upon close value.

#### **FINISH WARRANTY**

It is the responsibility of the customer to check for any material finish defects before installation. SUMERAIN doesn't warranty these finishes after the fixture has been installed.

#### **ELECTRONIC FAUCETS WARRANTY**

SUMERAIN warrants that its electronic faucets, valves and controls to be free from manufacturing defects in material and workmanship under normal use for three(3) years from the date of purchase and waterflow impeller-dynamo (generate power for LED faucet) for six(6) months from the date of purchase.

### **LENGTH OF WARRANTY**

Replacement or repaired parts of products will be covered for the term of this warranty as stated in the following two sentences, if you are a consumer who purchased the product for use primarily for personal, family, or household purposes, this warranty extends for 5 years since the product originally installed (Extend max 1 month From the date of purchase). if you purchased the product for use primarily for any other purpose, including, without limitation, a commercial purpose or is installed outside of China, or if the finish is gold, non-Vibrant or a painted or powder coated color finish this warranty extends only for one year, with respect to SUMERAIN and commercial products.

#### THIS WARRANTY DOES NOT COVER, AND SUMERAIN WILL NOT PAY FOR:

- **A.** Conditions, malfunctions or damage not resulting from defects in material or workmanship.
- **B.** Conditions, malfunctions or damage resulting from normal wear and tear, improper installation, improper maintenance, misuse, abuse,negligence,accident or alteration or the use of abrasive or caustic cleaning agents or "no-rinse" cleaning products, or the use of the product in any manner contrary to the product instructions. Conditions in the home such as excessive water pressure or corrosion.
- **C.** Labor or other expenses for the disconnection, deinstallation, or return of the product for warranty service, or for installation or reinstallation of the product.
- **D.** Accessories, connected materials and products (including but not limited in handshower flexible hose, spray flexible hose, handshower), or related products not manufactured by SUMERAIN

### TO OBTAIN WARRANTY PARTS OR INFORMATION

Contact your SUMERAIN retailer or contact technical service at: supports@sumerain.com,In requesting warranty service, you will need to provide

- 1. The sales receipt or other evidence of the date and the place of purchase.
- 2. A description of the problem (Download URL: <a href="http://www.sumerain.com/download/servicerequest/sheet.pdf">http://www.sumerain.com/download/servicerequest/sheet.pdf</a> and fill out the Service Request Sheet).
- 3. Delivery of the product or the defective part, postage prepaid and carefully packed and insured to sumerain When warranty service is completed, any repaired or replacement product or part will be returned to you postage prepaid.

#### **EXCLUSIONS AND LIMITATIONS**

Repair or replacement (or, in limited circumstances, refund of the purchase price) as provided under this warranty is the exclusive remedy of the purchaser. SUMERAIN neither assumes nor authorizes any person to create for it any obligation or liability in connection with this product. SUMERAIN shall not be liable to purchaser or any person for any incidental, special, or consequential damages, arising out of breach of this warranty or any implied warranty (including merchantability) Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal right, and you may have other rights which vary from state to state. You may be required by law to give us a reasonable opportunity to correct or cure any failure to comply before you can bring any action in court against us under the Magnusson-moss warranty Act.

#### PRODUCT INSTRUCTIONS AND QUESTIONS

Upon purchase or prior to installation, please carefully inspect your SUMERAIN product for any damage or visible defect. Prior to installing, always carefully study the enclosed instructions on the proper installation and the care and maintenance of the product. if you have questions at any time about the use,installation,or performance of your SUMERAIN product, or this warranty, please call or email us at +1-866-203-0866, supports@sumerain.com.




# **FUNCTIONS AND SPECIFICATION**


Function	Bathroom Sink Faucets
Feature	Wall mount
Theme	Modern ,Contemporary
Configuration	Vessel
Finish	Chrome/Nickel brushed/Matte Black/Oil rubber bronze/Gold/Brushed Gold
Installation Holes	Three
Number of Handles	Two
Handle style	Knob
Faucet Total Height	Adjustable
Spout Reach	192mm [7-1/2 Inch]
Spout Height	Adjustable
Spout rotatable	Yes,360degree
Installation type	Wall mount
Valve Type	Ceramic disc
Faucet Body Material	Brass
Spout Material	Brass
Handle Material	Metal
Net Weight	1.35 KG [2,97 lbs ]
Gross Weight	1.55 KG [3,41 lbs ]
Working water press	0.2 ~0.8 Mpa
Flow Rate	6.8L/M [ 1.8 GPM ]
Packing box size	370mm(14-1/2") x 255mm(10") x 70 mm(2-3/4")



# **DIMENSION**



FRONT VIEW OF FAUCET



**LEFT VIEW OF FAUCET** 



### **INSTALLATION STEPS**

## 1. BEFORE PROCEEDING




**WARNING:** Read all the instructions completely before proceeding. SUMERAIN recommends calling a professional if you are uncertain about installing this product!, this product should be installed in accordance with all local and state plumbing and building codes.

## 2. SHUT OFF WATER SUPPLY

Locate water supply inlets and shut off the water supply valves. These are usually found near the water meter. if you are replacing an existing unit, remove the old unit and clean the mounting surface thoroughly.

# 3. CHECKING THE CONTENTS OF THE BOX

Upon opening the box, check to ensure that all the following items are included.





If any of these items are missing, please contact SUMERAIN consumer service by email to: <a href="mailto:supports@sumerain.com">supports@sumerain.com</a>



# 4. VALVE TRIM INSTALLATION


**4.1** Make a mounting rack (normally use woods as materials) for preparing install the rough-in valve trim. The mounting board's face should be 58mm (2-9/32") at least and max 88mm(3-15/32") behind the finish wall surface.









**4.2** Secure the rough-in valve to the mounting board with screws by Philips screwdriver.




**4.3** Turn on your shut-off valve for cleaning the hot and cold water supply tube before connect to the valve trim, allow the water flush 3~5 minutes to flush out dirt and debris. Shut off the water supply again after finish.




**4.4** Apply Teflon tape on the thread of tube inlet and then connect to rough-in valve. Rough-in Valve thread for Hot&Cold water inlet: 1/2"-14 NPT ( US, CA )




## 4.5 Install finish wall




# **4.6** Apply Teflon tape on the thread of spout feed pipe




# **4.7** Install spout to rough-in valve.




# 4.8 Attach flange(Escutcheon) to finish wall across spout



# **4.9** Screw the escutcheons to hot and cold cartridge.




**4.10** Slip the escutcheons on to sleeves and attach to finish wall.




**4.11** Seal the wall around the escutcheons with waterproof sealant




**WARNING:** Failure to seal the wall can lead to possible water damage.



# **4.12** Attach and Secure the knobs to cartridge stem with screw by Allen key.



## 4.13 Install Finish.



## **ASSEMBLE FINISHED**

### 5. INSPECTION

**5.1** Turn on hold and cold water supply and check all connection for ensuring no leaking anywhere.

### **INSTALL FINISH**

#### **CLEARNING RECOMMENDATION FOR SUMERAIN PRODUCTS**

Modern lavatory faucets, kitchen faucets, and showers consist of very different materials to comply with the needs of the market with regard to design and functionality. To avoid damage and returns, it is necessary to consider certain criteria when cleaning.

#### **Cleaning Materials for faucets and showers**

Acids are a necessary ingredient of cleaning materials for removing lime, however please pay attention to the following points when cleaning faucets and showers:

- Only use cleaning materials which are explicitly intended for this type of application.
- Never use cleaning materials which contain hydrochloric, formic, phosphoric, or acetic acid, as they cause considerable damage.
- Never mix one cleaning material with another.
- Never use cleaning materials or appliances with an abrasive effect, such as unsuitable cleaning powders, sponge pads, or micro fiber cloths.

#### Cleaning instructions for faucets and showers

Please follow the cleaning material manufacturer's instructions. In addition, pay attention to the following points:

- Clean the faucets and showers as and when required.
- Use the amount of cleaning product and the amount of time recommended by the manufacturer. Do not leave the cleaner on the fixture longer than necessary.
- Regular cleaning can prevent calcification, if scale deposits are noticed on the faucet surface or the spout, you can clean it by a commercial limescale remover, such as Lime-Away® or CLR®. Dilute the remover according to the label instructions.
- The faucets might have some rusty if your faucet under hard water condition, please rub it with aluminum foil dipped in water until the surface is nice and smooth, and wipe it use a small amount of chrome polish or maybe something like car wax(such as Meguiar®,Turtle Wax®) or polish.
- For stainless steel faucet and spout both made of solid stainless, normally this finish has not protective coating on it(in particular waterfall spout inside), stainless steel is by its material nature very tarnish resistant, but by no means tarnish or stain proof. This finish might oxidize naturally over time and react to its environment. Keep your stainless fixture wiped clean and dry and use only a cleaner specifically made for stainless steel (such as Weiman®, CLR®).
- When using spray cleaners, spray first onto a soft cloth or sponge, never spray directly onto the faucet as droplets can enter openings and gaps and cause damage.
- After cleaning, rinse thoroughly with clean water to remove any cleaner residue.

### **Important**

Residues of liquid soaps, shampoos, and shower foams can also cause damage, so rinse with clean water after using.



Please note: if the surface is already damaged, the effect of cleaning materials will cause further damage.

Components with damaged surfaces must be replaced or injury could result. Damage caused by improper treatment is not covered under the warranty.

### **TROUBLESHOOTING**

Symptom	Solution
Faucet leaks from the handle	A. Tighten the packing nut
	B. Replace the "O" ring or packing
The water pressure is too low	A. Make sure the water supply valves under the sink are turned on all the way
	B. Clean or replace the aerator
	C. Check plumbing system for water pressure problems
The spout sprays water all over	A. Clean or replace the aerator
	B. Replace the aerator washer
Water is leaking from the faucet under the sink	A. Check the water supply connections to the faucet
	B. Inspect the water supply lines or hoses for leaks
Handle is loose	A. Remove the cap and tighten the screw
	B. Locate and tighten the hex set screw
	C. Remove the handle and check for stripped teeth on the stem.





#### HONGKONG SUMERAIN SANITARY INDUSTRY CO..LIMITED

Address: ROOM 1018, HOLLYWOOD PLAZA 610 NATHAN ROAD MONGKOK,

KL,HONGKONG

Factory Address: 25 building Tangkou Industrial Park, Shuikou town, Kaiping City,

Guangdong Province,

China

**Factory Tel:** +86-750-2731579 **Web:** http://www.sumerain.com **E-mail:** <a href="mailto:supports@sumerain.com">supports@sumerain.com</a>

**SUMERAIN AMERICA SUPPORT** 

**Address:** Pershing Rd Chicago IL 60632

USA

Tel: +1(866)203-0866 / +1 (773) 240-5009

E-mail: <a href="mailto:supports@sumerain.us">supports@sumerain.us</a>

**SUMERAIN GERMANY SUPPORT** 

Address: Danziger Strasse 142

10407 Berlin Deutschland Tel: +49 (0)30/23975898

E-mail: <a href="mailto:supports@sumerain.com">supports@sumerain.com</a>

