

Passend für die folgenden Modelle:

Candy	CCTOS 502W	
HOOVER	HCSB 5172 WK/P	
Baumatic	34900410	BRCI 3180 E
Baumatic	34900411	BRCLO 3580 E
Baumatic	34900409	BRCIF 3050 E
Candy	CCBS 5154XN	
Candy	CCBS 6182XH/2N	
Candy	CTLP 130WK	
Candy	CCDS 6172FWHN	
Candy	CCBS 5154WN	
Candy	34002121	CCBS6182WHV
Candy	CHOL 6174W/N	
Candy	CHCS 6184XF	
Candy	CCOLS 6172WH/N	
Candy	CCDS 6172FXHN	
Candy	CCDS 6172XN	
Candy	CCDS 5142W	
Candy	CCS 5172WN	
Candy	CSC 1745 WE/P	
Candy	CCTLS 544WHN	
Candy	CHOL 6174W	
Candy	CSS 5175 WE/P	
Candy	34002122	CCBS6182XHV
Candy	34002119	CCDS 4251 SH
Candy	CCDS 6172WN	
Candy	34002079	CCDS 5140WH7
Candy	CSC 1745 SE/P	
Candy	34001935	CKOLS 5142W
Candy	CCTLS 542WHN	
Candy	34002333	CCDS4256XH
Candy	34002334	CCTOS 156XH
Candy	34002346	CTLP130
Candy	34002352	CCTOS WH405
Candy	34002355	CCTOS 544XH
Candy	34002298	CCTOS542S
Candy	34002091	CKCS6184SV/1
Candy	34002078	CCODS 5142 W
Candy	34001907	CKBS 5162W
Candy	34001851	CCTOS 504WH
Candy	34900353	CKBC 3180E/1
Candy	34001861	CCDS 5142WH
Candy	34900351	CKBC 3160E/1
Candy	34001670	CSC1745WE
Candy	34002261	CCTL582WK
Candy	34900402	CKBF 3180 E
Candy	34002190	CCBS 6182W/1

Candy	34002264	CCTOS542XHRU
Candy	34001883	CKBS 5152W
Candy	34001884	CKBS 5152X
Candy	34900170	CFBD2450/1ES
Candy	34900349	CFBD 2450/2E
Candy	34002184	CCBS 6184XH
Candy	34001878	CCBS 5152S
Candy	34001868	CCDS 5122WH
Candy	34002260	CSS5175BE
Candy	34900348	CKBC 3150E/1
Candy	34001930	CCBS 6182W
Candy	34001914	CCTOS 154 SH
Candy	34900377	CFBD2650E/1S
Candy	34001920	CKBS 5172W
Candy	34900375	CKBC3380E/1
Candy	34900381	CKBC3350E/1S
Candy	34001847	CCTOS 502WH
Candy	34001893	CCDS 5144WH
Candy	34001919	CCBS 5172XH
Candy	34900400	CIL 220 EE
Candy	34001859	CCTOS 544WH
Candy	34001932	CCBS 6182XH
Candy	34001875	CKDS 5162W
Candy	34001864	CCDS 5142X
Candy	34001900	CKDS 5144X
Candy	34900290	CIL 200 E
Candy	34002183	CCBS 6184WH
Candy	34002120	CKCS6184WV/1
Candy	34900354	CFBC3050E/1K
Candy	34001853	CCTLS 544WH
Candy	34001886	CKDS 6172X
Candy	34002310	CCS 5172X
Candy	34001945	CKBS 5174W
Candy	34900355	CFBF3050E/1K
Candy	34001849	CCTOS 502XH
Candy	34900169	CFBD 2450/1E
Candy	34001898	CKDS 5122X
Candy	34002139	CCBS 2165WH
Candy	34001909	CKBS 5162X
Candy	34001937	CCOLS 5144WH
Candy	34002118	CCDS 6174FSH
Candy	34900395	C142FD
Candy	34900360	CKBC3150E/1S
Candy	34900378	CKBC3380EE/1
Candy	34001852	CCTLS 542WH
Candy	34900352	CKBC3180EE/1
Candy	34001899	CKDS 5144W
Candy	34001931	CCBS 6182WH

Candy	34900401	CIO 225 EE
Candy	34002116	CCDS 6172FWH
Candy	34002157	CCBS 5174X
Candy	34001903	CKBS 5154X
Candy	34002188	CCBS 6182WH
Candy	34900357	CFBD2450/2ES
Candy	34002266	CCTOS502SHRU
Candy	34001929	CCTOS 205WH
Candy	34001916	CCBS 5172W
Candy	34001939	CCOLS 6172WH
Candy	34001946	CKBS 5174X
Candy	34001877	CCBS 5152W
Candy	34002265	CCTOS502WRU
Candy	34001860	CCDS 5142W
Candy	34001889	CCBS 5154W
Candy	34002117	CCDS 6172FXH
Candy	34001869	CCDS 5122W
Candy	34001921	CKBS 5172X
Candy	34001672	CSC1745SE
Candy	34001872	CKDS 5142W
Candy	34002272	CKBS 6180SRU
Candy	34001850	CCTOS 502SH
Candy	34001871	CKDS 5122W
Candy	34001938	CCODS 5142WH
Candy	34002271	CCPS 6180SRU
Candy	34002138	CCDS2145WH
Candy	34001673	CSC1745BE
Candy	34002140	CCTOS 542W
Candy	34002268	CCTOS542WHRU
Candy	34002269	CCTLS542WHRU
Candy	34001917	CCBS 5172WH
Candy	34001862	CCDS 5142S
Candy	34001885	CKDS 6172W
Candy	34001848	CCTOS 502W
Candy	34900358	CFBO3580E/1
Candy	34001879	CCBS 5152X
Candy	34900376	CFBD2650E/1
Candy	34001943	CCDS 6172WH
Candy	34001641	CSS5166WE
Candy	34001890	CCTOS 542XH
Candy	34900359	CFLO3550E/1
Candy	34001913	KDCS 4152W/1
Candy	34001874	CCDS 5162W
Candy	34900374	CKBC3350E/1
Candy	34001934	CCOLS 5142WH
Candy	34001918	CCBS 5172X
Candy	34001865	CCDS 5142XH
Candy	34001888	CCBS 5154X

Candy	34900503	CFBD 2450/5E
Candy	34002259	CSS5175WE
Candy	34001880	CCDS 6172W
Candy	34002270	CCPS 6180WRU
Candy	34900350	CKBC3150E/1K
Candy	34900291	CIO 200 E
Candy	34900412	CCS250A
Candy	34002189	CCBS 6182XH
Candy	34001908	CKBS 2165W
Candy	34001857	CCTOS 542WH
Candy	34001894	CCDS 5144SH
Candy	34001193	CTSE 5142 W
Candy	34001873	CKDS 5142X
Candy	34001902	CCDS 6172X
Candy	34900362	CKBC3180E/1S
Candy	34900356	CFBO3550E/1
Candy	34001911	CKDS 2145W
Candy	CCBS6182XHV/1	
Gasfire	34900365	GBD 240/1 E
Gasfire	34900364	GBC 311/1 E
Gasfire	34900366	GBD 240/1 ES
Gasfire	34900245	GBD 240 E
Helkama	34002049	HHJP 1856S2X
HOOVER	HVTL542BHKN	
HOOVER	HVTL542WHKN	
HOOVER	34001854	HVTLS 542WH
HOOVER	34002036	HVBS 5162AK
HOOVER	34002082	HDCS186FXD/1
HOOVER	34002031	HFLE54B
HOOVER	34001927	HVBS 5172XH
HOOVER	HHVBS5152WH	
HOOVER	34001895	HVDS5144WH
HOOVER	34002026	HSC574S
HOOVER	34002012	HVBS 5174XH
HOOVER	34002027	HSC574B
HOOVER	34002030	HFLE54W
HOOVER	34002025	HSC574W
HOOVER	34002080	HDCS 184FA/1
HOOVER	34002043	HVTL542WHK
HOOVER	34002028	HFOE54W
HOOVER	34002029	HFOE54B
HOOVER	34002321	HCS 5172WK
HOOVER	34002035	HVBS 5162WK
HOOVER	34002037	HVBS 5162BK
HOOVER	34002044	HVTL542BHK
HOOVER	34001855	HVTLS 544WH
HOOVER	34001905	HDDS 6172W
HOOVER	34001876	HVDS 5162WH

HOOVER	34900370	HFFBP3050/1K
HOOVER	34001624	HFOE 5485 WE
HOOVER	34002193	HSC185WE/1
HOOVER	34001882	HVDS 6172WH
HOOVER	34900373	HBCP3380/1D
HOOVER	34001925	HDBS 5174X
HOOVER	34001795	HSC17155WE
HOOVER	34001901	HVDS 5162AH
HOOVER	34001866	HVDS 5142WH
HOOVER	34001887	HHVBS5152WH
HOOVER	34900463	HBOL 172
HOOVER	34900416	HVOD 124
HOOVER	34001933	HHJP 1856S2W
HOOVER	34900372	HBOP 3780/1
HOOVER	34900368	HBCP3150/1KD
HOOVER	34001856	HHJA 0855S2W
HOOVER	34001904	HDDS 6172X
HOOVER	34001891	HVTOS 542WH
HOOVER	34001926	HVBS 5172WH
HOOVER	34001858	HHJV 0855S2W
HOOVER	34001867	HHJP 1435S2W
HOOVER	34001896	HVDS 5144XH
HOOVER	34001928	HHJP 1775S2W
HOOVER	34001786	HL54WE
HOOVER	34900388	HBCPP3180/1D
HOOVER	34001892	HVTOS 544WH
HOOVER	34900367	HBCP3180/1D
HOOVER	34900462	HBOD 174
HOOVER	34900369	HBCP3050/1K
HOOVER	34001796	HSC17155SE
HOOVER	34002168	HVBS 6182WH
HOOVER	34001881	HVDS 6172AH
HOOVER	34001906	HVDS 5142AH
HOOVER	34001924	HDBS 5174W
iberna	34001075	IDAP245
iberna	34002187	ICP 360S/1
iberna	34001534	ICP 360S
iberna	34002186	ICP 360/1
Rosieres	34900389	RBLP3683/3
Rosieres	34900382	RBCP 3183/3
Rosieres	34900397	RSOP122
Rosieres	34900386	RBDP 2653/3
Rosieres	34900383	RBCPP3184/3
Rosieres	34900387	RBOP 3683/3
Rosieres	34900384	RBCP 3383/3
Rosieres	34900396	RSLP122
Rosieres	34900385	RBDP 2353/3
Zerowatt	EZSSM 6182WN	

Zerowatt	34002218	ZCP 360S
Zerowatt	34002224	ZDAP 245 S
Zerowatt	34002223	ZDAP 245
Zerowatt	34002222	ZTLP 130
Zerowatt	34002217	ZCP 360
Zerowatt	34900508	ZEBD 152/2S
Zerowatt	34900475	ZEBD 152
Zerowatt	34900474	ZEBBS 100
Zerowatt	34900476	ZEBD 152 S
Zerowatt	34900507	ZEBD 152/2