

User's manual

Instructions for use

- Insert the charger into the wall outlet.
(Connect one end of the charging cable to the charging port of the device
(phone, portable speaker, external battery, etc.)
- Connect the other end of the cable to the port
USB of the charger.
- Disconnect the device when it is complete Loaded.

Precautions

- To beware of children and pets.
- Protect the product from humidity. Do not expose the product to rain or charged air With moisture. Beware liquid product.
- Protect the product from fire and heat sources. Not close the product to the fire or other sources of heating (stoves, radiators et.)
- Discarding the product. Do not throw away the product or the other electronic components together with household garbage. Use only specialized centers for the collection of electronic waste.

WASTE DISPOSAL:

The adjacent symbol shows that, in accordance with local laws and regulations, your product and for its battery must be disposed of separately from the waste Household. When this product reaches the end of its life, take them to a collection point designated by the local authorities. For information about local collection centers please contact the city hall your locality.

MADE IN CHINA

