



Hair Dryer

INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference

Unpacking

1. Air Outlet
2. Switch
3. Air inlet grille
4. Hanger
5. Instruction manual
6. Diffuser
7. Nozzle
8. Bracket



HL310 Button Details




Unpacking

1. Air Outlet
2. Switch
3. Air inlet grille
4. Hanger
5. Instruction manual
6. Diffuser
7. Nozzle
8. Bracket



HL312 Button Details



Styling concentrator:

Keeps the surface of the attachments cool for easy adjustment and close-up styling. Dries hair gently using smooth air. Fast, precise airflow for controlled styling, one section at a time.



Diffuser:

Evenly disperses airflow to dry curls gently and help reduce frizz. Recommended for use on the low temperature and flow settings.



EN

Function:

1. Automatic power off when overheating.
2. Double insulation protection, an insulation composed of basic insulation and additional insulation, which is safe and reliable, and will not cause electric shock accident when the basic insulation is damaged.
3. The electrical contact adopts silver point, which increase the frequency of conductor and enhance the performance of conductor.
4. The plastic shell has high temperature resistance, better insulation and moisture resistance.

Notes on use:

1. It should be used at 110-240V power supply.
2. Do not cover the outlet and inlet during use.
3. Do not use the hair dryer on braid, paper or other flammable materials.
4. Do not use the hair dryer near gas or other highly flammable items.
5. When the hair dryer is used in the bathroom, the plug must be unplugged after use.
6. Close supervision is required when hair dryers are used by children.
7. After use, the switch of the hair dryer must be placed in the "stop" gear and then unplugged from the socket.
8. Do not use it with wet hands to prevent accidents.
9. If the power cord is damaged, it must be replaced by professionals from the manufacturer, its maintenance department or similar departments.
10. Warning: Do not use this product near water-filled bathtubs, showers, washbasins or other utensils.

[Worry-free Purchase] :Thank you for your purchase! We hope you'll pleased with both the products and service you received.

If you have any quality problems , feel free to e-mail Bestauty after-sale service team via support@bestauty.com, All e-mails will responded in 24 hours with helpful advice.

DE

Funktion:

1. Automatische Abschaltung bei Überhitzung.
2. Doppelter Isolierungsschutz, eine Isolierung, die aus Grundisolierung und zusätzlicher Isolierung besteht, die sicher und zuverlässig ist und keinen Stromschlagunfall verursacht, wenn die Grundisolierung beschädigt wird.
3. Der elektrische Kontakt nimmt Silberpunkt an, der die Frequenz des Leiters erhöht und die Leistung des Leiters verbessert.
4. Die Kunststoffschale hat hohe Temperaturbeständigkeit, bessere Isolierung und Feuchtigkeitsbeständigkeit.

Hinweise zur Verwendung:

1. Es sollte an 110-240V Netzteil verwendet werden.
2. Abdeckung des Auslasses und des Einlasses während des Gebrauchs nicht.
3. Verwenden Sie den Haartrockner nicht auf Zöpfen, Papier oder anderen brennbaren Materialien.
4. Verwenden Sie den Haartrockner nicht in der Nähe von Gas oder anderen leicht entzündlichen Gegenständen.
5. Wenn der Haartrockner im Badezimmer verwendet wird, muss der Stecker nach Gebrauch entfernt werden.
6. Eine genaue Überwachung ist erforderlich, wenn Haartrockner von Kindern verwendet werden.
7. Nach Gebrauch muss der Schalter des Föhns in den "Stop"-Gang gesetzt und dann aus der Steckdose gezogen werden.
8. Verwenden Sie es nicht mit nassen Händen, um Unfälle zu vermeiden.
9. Wenn das Netzkabel beschädigt ist, muss es von Fachleuten des Herstellers, seiner Wartungsabteilung oder ähnlichen Abteilungen ersetzt werden.
10. Achtung: Verwenden Sie dieses Produkt nicht in der Nähe von wassergefüllten Badewannen, Duschen, Waschbecken und anderen Utensilien.

[Sorry-free Purchase]: Vielen Dank für Ihren Kauf! Wir hoffen, dass Sie mit den Produkten und dem Service zufrieden sind, den Sie erhalten haben.

Wenn Sie Qualitätsprobleme haben, wenden Sie sich bitte per E-Mail an das Bestauty Kundendienst-Team über support@bestauty.com Alle E-Mails werden rund um die Uhr mit hilfreichen Tipps beantwortet.

Attention:

Things you should be attention base on daily use.

1. Keep the power switch on "0" position and make sure it's unplugged when your hairdryer is not in use.
2. Keep your hair away from air inlet / filter when the hair dryer is working.
3. Do not choke the air inlet / filter, otherwise overheating will happen.
4. We suggest high power for drying hair, and low power for styling;
5. When the hair dryer breaks in any situations , unplug the power source at once to cool it down.
6. If the hairdryer falls into water, unplug and cut the electricity immediately, Do not put your hand into the water.
7. Do not twist, pull, bend, or wrap the cable around the dryer. Keep the cable untwisted during use.
8. Keep the hair dryer in a safe, dry circumstance, make sure it won't be reached by kids.

The air exit and metal ring may be hot during use.

Allow to cool before handling.



NOTES

- 1. Notes: *Do not use in bath or shower.

