

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
ASKO	533087	RFN2274I
ASKO	457545	RF2673I
ASKO	557715	R21183I
Gorenje	328784	R4121AW
Gorenje	329225	RI4101AW
Gorenje	429381	RKI4180BW
Gorenje	339325	RC4181KX
Gorenje	457113	RI4181BW
Gorenje	385458	R4121CX
Gorenje	325583	RBI5121C
Gorenje	328781	NRK4181CW
Gorenje	471239	NRKI4181CW
Gorenje	312762	GSC26178F/01
Gorenje	316422	RAZ-RBI41149
Gorenje	556964	NRKI4182GW
Gorenje	328765	NRKI4181LW
Gorenje	543412	RKI4182EWA
Gorenje	506474	NRKI5182PW
Gorenje	556975	NRKI4181CW
Gorenje	352837	NRK4181CX
Gorenje	329219	NRKI4181LW
Gorenje	471854	NRKI4181CW
Gorenje	374140	NRKI5182PW
Gorenje	588484	RBI4122AW
Gorenje	431432	NRKI4181CW
Gorenje	375400	RI5181PW
Gorenje	329233	RBI5091CW

Gorenje	354882	RBI4121BW
Gorenje	444038	RI5182BW
Gorenje	316390	RAZ-RBI41148
Gorenje	374152	RBI5182PW
Gorenje	506473	NRKI5181LW
Gorenje	329223	RI5121NW
Gorenje	367049	RB4121CX
Gorenje	352717	RBI4122AW
Gorenje	325549	NRKI4181C
Gorenje	409134	GDR66178
Gorenje	329222	RFI4161AW
Gorenje	328785	R4121CW
Gorenje	469461	NRKI4181CW-L
Gorenje	402237	GDC66178FN
Gorenje	328780	RC4181KW
Gorenje	439684	NRKI41285
Gorenje	329224	RBI5121NW
Gorenje	543757	RBI4122AWA
Gorenje	352710	RI5122AW
Gorenje	566189	NRKI4181LW
Gorenje	228895	NRKI41288
Gorenje	471242	RKI4181AW
Gorenje	481154	NRKI5181LW
Gorenje	387498	NRKI84181CW
Gorenje	312653	GDR66088B/01
Gorenje	325567	RI4121CW
Gorenje	393916	NRCI4181CW
Gorenje	444039	RI4182BW
Gorenje	357227	NRKI4181CW

Gorenje	312758	GDC66178F/01
Gorenje	312690	GDR67102FB
Gorenje	312682	GDR67102F
Gorenje	312652	GDR67088
Gorenje	543695	EKI12340
Gorenje	325564	RBI4181A
Gorenje	398033	RKV42200E
Gorenje	444034	RBI4093AW
Gorenje	435881	RBI5093AW
Gorenje	315525	RAZ-RI41199
Gorenje	352760	RKI4182EW
Gorenje	329692	RK1298W
Gorenje	325547	RKI5181A
Gorenje	373885	RBI4120BW
Gorenje	352667	RBI5102AW
Gorenje	354940	RI4181BW
Gorenje	354344	RKI4181BW
Gorenje	395856	RCI5180AW
Gorenje	328782	RF4161AW
Gorenje	328776	RK4181AW
Gorenje	315526	RAZ-RI41198
Gorenje	328778	RC4181AW
Gorenje	543697	EKGI17800
Gorenje	543703	EKI8840
Gorenje	320340	RAZ-RF145A1
Gorenje	320341	RAZ-RF45A1
Gorenje	355966	RC4181AX
Gorenje	354886	RK4181AX
Gorenje	354338	RBI4181BW

Gorenje	329214	RI5181AW
Gorenje	329213	RBI5182BW
Gorenje	352757	RI4102AW
Gorenje	329232	RBI4091AW
Gorenje	329228	RBI4101AW
Gorenje	347460	RCI4181BW
Gorenje	352838	RBI4182BW
Gorenje	352758	RBI4102AW
Gorenje	352712	RKI5182EW
Gorenje	352708	RBI5092AW
Gorenje	373884	RBI4180BW
Gorenje	373889	RCI4180AW
Gorenje	392706	RI4181AW
Gorenje	352709	RI5102AW
Gorenje	325570	RBI4121A
Gorenje	325562	RI4181A
Gorenje	325548	RCI4181AW
Gorenje	325467	RKI4181A
Gorenje	543693	EKI8800
Gorenje	334379	RI5092AW
Gorenje	316423	RAZ-RBI41179
Gorenje	334380	RI4092AW
Gorenje	316421	RAZ-RBI41178
Gorenje	329230	RI4091AW
Gorenje	373958	R4121AW
Gorenje	315527	RAZ-RI41169
Gorenje	315528	RAZ-RI41168
Gorenje	228891	NRKI-ORA
Gorenje	325561	NRCI4181C

Gorenje	323147	GDR67122FB
Gorenje	329215	RKI4181KW
Gorenje	312799	GSR25178B/01
Gorenje	329218	RCI5181KW
Gorenje	320868	NRKI5181LW
Gorenje	543698	EKGI17800NF
Gorenje	367048	R4121AX
Gorenje	352711	RBI5122AW
Gorenje	442431	NRKI5181LW
Gorenje	444035	NRKI5182GW
Gorenje	543694	EKI12300
Gorenje	338188	NRKI4181CW
Gorenje	312787	GDC67178FN
Gorenje	498750	NRKI51ST
Gorenje	325550	NRKI5181C
Gorenje	328787	RB4121CW
Gorenje	352759	NRKI4181GW
Gorenje	325566	RI4121A
Gorenje	405754	RBI4120BW
Gorenje	352785	NRKI5181GW
Gorenje	418695	NRKI4181CW
Gorenje	325568	RI5121CW
Gorenje	306449	RKI2-ORA
Gorenje	471240	RKI4181KW
Gorenje	312741	GDR66122Z
Gorenje	532447	NRKI5181LW
Gorenje	357781	NRKI4181LW
Gorenje	354340	RI4121BW
Gorenje	444036	NRKI4182GW

Gorenje	325582	RBI4121CW
Gorenje	352719	RI4122AW
Gorenje	329221	NRKI5181LW
Gorenje	312737	GSR26122F/01
Gorenje	323146	GDR67122F
Gorenje	381669	RKI4180KW
Gorenje	312753	GDR66122BZ
Gorenje	560142	NRK4181CW
Gorenje	329217	RKI5181KW
K?rting	356928	KRKI4180BW