

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Balay	KI4BYU3/02	
Balay	KI4BYU3/01	
Balay	3FI556B/31	KI 26 R 440
Balay	3FI556B/32	
Balay	KI4BYU2/31	
Balay	3FI556B/33	
Bosch	KIM23472/01	
Bosch	KIM30471FF/01	
Bosch	KIM2974IE/32	
Bosch	KIM2974IE/31	
Bosch	KIM30471/01	
Bosch	KIM29470GB/02	
Bosch	KIM2974GB/32	
Bosch	KIM3074/31	
Bosch	KIM3074GB/31	
Bosch	KIM30470/01	
Bosch	KIM2974IE/33	
Bosch	KIM29473GB/03	
Bosch	KIM29473GB/02	
Bosch	KIM23471FF/01	
Bosch	KIM23470FF/01	
Bosch	KIM23470/01	
Bosch	KIM29470IE/02	
Bosch	KIM29470IE/01	
Bosch	KIM29470/03	
Bosch	KIM29470/02	
Bosch	KIM2674GB/31	

Bosch	KIM23401/01	
Bosch	KIM2674/31	
Bosch	KIM29470IE/03	
Bosch	KIM30471FF/04	
Bosch	KIM29470/01	
Bosch	KIM30471/04	
Bosch	KIM2574/31	
Bosch	KIM25400/02	
Bosch	KIM2674/32	
Bosch	KIM23472/03	
Bosch	KIM23471FF/03	
Bosch	KIM2574/32	
Bosch	KIE28470/01	
Bosch	KIM30471FF/02	
Bosch	KIM29472/04	
Bosch	KIM23471/01	
Bosch	KIM23472/04	
Bosch	KIM2574GB/31	
Bosch	KIM23471FF/02	
Bosch	KIM29472/01	
Bosch	KIM30470FF/01	
Bosch	KIM25400/01	
Bosch	KIM30471/02	
Bosch	KIM29470GB/01	
Bosch	KIM23402/01	
Bosch	KIM2974GB/31	
Bosch	KIM30471/03	
Bosch	KIM23472/02	
Bosch	KIM29472/02	

Bosch	KIM3074/32	
Bosch	KIM2974/31	
Bosch	KIM30471FF/03	
Bosch	KIM29473GB/01	
Constructa	CK65640/31	
Constructa	CK65741/01	
Constructa	CK65641/02	
Constructa	CK65741/02	
Constructa	CK65740/31	
Constructa	CK65641/01	
Junker&Ruh	K25JR40/31	
Junker&Ruh	K25JR440/02	
Junker&Ruh	K29JR440/02	
Junker&Ruh	K25JR440/01	
Junker&Ruh	K29JR440/01	
Junker&Ruh	K29JR40/31	
Neff	K8625X1/01	KG515
Neff	K8514X1/01	KG411
Neff	K8514X2/01	
Neff	K8625X2FF/01	
Neff	K8514X2FF/01	
Neff	K8525X2FF/01	
Neff	K8525X2/01	
Neff	K8514X1FF/01	KG411
Neff	K8514X1/02	KG411
Neff	K8525X3GB/01	
Neff	K8524X4GB/03	
Neff	K8524X4GB/01	
Neff	K8514X4FF/02	

Neff	K8514X4FF/01	
Neff	K8625X4FF/01	
Neff	K8625X0/03	KG515
Neff	K8625X0/31	KG515
Neff	K8625X0IE/03	Neff Excellent
Neff	K8625X2/02	KG515
Neff	K8514X0/31	KG411
Neff	K8525X0/31	KG520
Neff	K8525X1/02	kg520
Neff	K8525X1FF/01	KG520
Neff	K8625X4FF/04	
Neff	K8625X2/01	KG515
Neff	K8625X0/32	KG515
Neff	K8625X0IE/32	K8625
Neff	K8525X1GB/02	k8525
Neff	K8625X4FF/05	
Neff	K8625X2IE/01	K8625
Neff	K8625X1IE/01	K8625
Neff	K8625X4FF/03	
Neff	K8524X4GB/02	
Neff	K8525X0GB/31	K8525
Neff	K8514X4FF/03	
Neff	K8625X4FF/02	
Neff	K8625X0IE/31	K8625
Neff	K8614X3GB/01	
Neff	K8625X2IE/02	K8625
Neff	K8525X1GB/01	k8525
Neff	K8525X1/01	kg520
Pitsos	P1KKA3000V/31	

Pitsos	P1KKA3000V/04	
Pitsos	P1KKA3000V/03	
Pitsos	P1KKA3000V/33	
Pitsos	P1KKA3000V/32	
SIEMENS	KI24M471/05	
SIEMENS	KI30M471/03	
SIEMENS	KI30M471FF/04	
SIEMENS	KI24M471/04	
SIEMENS	KI24M471FF/02	
SIEMENS	KI30M470FF/02	
SIEMENS	KI29M475GB/01	
SIEMENS	KI29M475GB/02	
SIEMENS	KI29M470IE/04	
SIEMENS	KI24M470/01	
SIEMENS	KI26M471GB/02	
SIEMENS	KI30M471/05	
SIEMENS	KI29M470IE/02	
SIEMENS	KI30M470FF/01	
SIEMENS	KI30M74/33	
SIEMENS	KI24M470FF/01	
SIEMENS	KI29M470IE/03	
SIEMENS	KI25M74/31	
SIEMENS	KI25M74/32	
SIEMENS	KI29M74/31	
SIEMENS	KI30M74/31	
SIEMENS	KI30M74/32	
SIEMENS	KI29M74IE/31	
SIEMENS	KI29M470IE/01	
SIEMENS	KI29M74IE/32	

SIEMENS	KI24M471FF/05	
SIEMENS	KI24M470FF/02	
SIEMENS	KI24M471/03	
SIEMENS	KI30M471/04	
SIEMENS	KI30M470/02	
SIEMENS	KI29M74IE/33	
SIEMENS	KI30M471/02	
SIEMENS	KI26M74/32	
SIEMENS	KI30M470/04	
SIEMENS	KI30M470/01	
SIEMENS	KI30M470/03	
SIEMENS	KI24M470/02	
SIEMENS	KI26M471GB/01	
SIEMENS	KI30M471FF/02	
SIEMENS	KI24M471FF/04	
SIEMENS	KI26M74GB/31	
SIEMENS	KI30M74GB/31	
SIEMENS	KI24M471FF/03	
SIEMENS	KI30M471FF/05	
SIEMENS	KI30M471FF/03	
SIEMENS	KI26M74/31	
SIEMENS	KI24M471/02	
Bosch	KIE2640/31	
Bosch	KIE30465/01	
Bosch	KIE30441IE/02	
Bosch	KIE30440IE/01	
Bosch	KIE30441IE/04	
Bosch	KIE26441CH/04	IKE 329- 7Z3
Bosch	KIE28441/05	

Bosch	KIE3040IE/03	
Bosch	KIE26441CH/05	
Bosch	KIE3040TC/34	
Bosch	KIE30441FF/01	
Bosch	KIE2640CH/31	
Bosch	KIM3040GB/31	
Bosch	KIE26440CH/01	
Bosch	KIE3040TC/32	
Bosch	KIM24440/01	IK436-120
Bosch	KIE30441NE/01	
Bosch	KIM24440/02	IKE159-4
Bosch	KIE28440/01	
Bosch	KIE30441/01	
Bosch	KIE28441/06	
Bosch	KIE30440IE/02	
Bosch	KIE30465/04	
Bosch	KIE30441IE/06	
Bosch	KIE26441/04	
Bosch	KIE3040GB/31	
Bosch	KIE30441CH/01	
Bosch	KIE30441IE/03	
Bosch	KIE30440TC/01	
Bosch	KIE28440IE/01	
Bosch	KIE2640/03	
Bosch	KIM30440GB/01	
Bosch	KIE3040TC/04	
Bosch	KIE3040/32	
Bosch	KIE30441IE/07	
Bosch	KIE3040CH/31	

Bosch	KIE26440/01	
Bosch	KIE30441IE/08	
Bosch	KIE30440CH/02	
Bosch	KIE26441/07	IKE329-5Z3
Bosch	KIE30441NE/02	
Bosch	KIE30465/02	
Bosch	KIE30465/03	
Bosch	KIE3040TC/06	
Bosch	KIE30440NE/01	
Bosch	KIE3040TC/33	
Bosch	KIM2640/32	IKE229-4
Bosch	KIE26441/02	
Bosch	KIE26441/05	IKE329-4Z3
Bosch	KIE3040CH/03	
Bosch	KIE30441IE/05	
Bosch	KIE30441NE/03	
Bosch	KIE30465/05	
Bosch	KIE30441IE/09	
Bosch	KIE3040NE/03	
Bosch	KIE3040NE/31	
Bosch	KIE3040NE/32	
Bosch	KIE30441IE/01	
Bosch	KIE26441CH/02	IKE329-6Z3
Bosch	KIE26441CH/01	IKE329-6Z3
Bosch	KIE28441/04	
Bosch	KIE28441/03	
Bosch	KIE26441/01	
Bosch	KIE28440IE/02	
Bosch	KIE26441CH/03	IKE 329- 7Z3

Bosch	KIE26441/03	
Bosch	KIE26441/08	IKE329-6Z3
Bosch	KIE28440/02	
Bosch	KIM2640/31	IKE229-4
Bosch	KIE2640/32	
Bosch	KIE3040IE/32	
Bosch	KIE3040TC/31	
Bosch	KIE3040TC/05	
Bosch	KIE2640CH/03	
Bosch	KIE2640CH/32	
Bosch	KIE3040/31	
Bosch	KIE3040/03	
Bosch	KIE3040CH/32	
Bosch	KIE3040GB/32	
Bosch	KIE3040IE/31	
Bosch	KIE30440/02	
Bosch	KIE30440/01	
Bosch	KIE30440CH/01	
Bosch	KIE30440FF/01	
Bosch	KIM30440GB/02	
Bosch	KIM30440/01	
Bosch	KIM3040/32	
Bosch	KIM3040/31	
Siemens	KI30E440CH/03	
Siemens	KI30M441/01	
Siemens	KI30E441RK/05	
Siemens	KI30M440/03	
Siemens	KI30M441/04	
Siemens	KI30M443GB/03	

Siemens	KI30E441RK/02	
Siemens	KI30E440IE/04	
Siemens	KI30E440IE/06	
Siemens	KI24M440GB/01	
Siemens	KI30M443GB/02	
Siemens	KI30E4H1/02	
Siemens	KI30M440GB/03	
Siemens	KI30E440IE/03	
Siemens	KI30E440FF/06	
Siemens	KI24M440GB/04	
Siemens	KI30M441/02	
Siemens	KI30M440GB/04	
Siemens	KI30E441RK/04	
Siemens	KI30E441NE/03	
Siemens	KI24M443GB/01	
Siemens	KI30E441RK/03	
Siemens	KI30E4H1/04	
Siemens	KI30E4H1/05	
Siemens	KI30E440IE/05	
Siemens	KI24M443GB/04	
Siemens	KI30E440NE/03	
Siemens	KI24M443GB/02	
Siemens	KI30E440/06	
Siemens	KI30E4H1/06	
Siemens	KI30E4H1/03	
Siemens	KI30E441NE/05	
Siemens	KI24M443GB/03	
Siemens	KI30M443GB/01	
Siemens	KI30E440CH/04	

Siemens	KI30E441NE/02	
Siemens	KI30E440CH/07	
Siemens	KI30M441/03	
Siemens	KI30E440FF/04	
Siemens	KI30E441RK/01	
Siemens	KI30M443GB/05	
Siemens	KI30E440FF/05	
Siemens	KI24M440GB/03	
Siemens	KI30E440/03	
Siemens	KI30M443GB/04	
Siemens	KI30E440/04	
Siemens	KI30E441NE/04	
Siemens	KI30E440CH/06	
Siemens	KI30E440CH/05	
Siemens	KI30E440FF/02	
Siemens	KI30E440CH/08	
Siemens	KI30E440FF/03	
Siemens	KI30E440/05	
Siemens	KI30E440IE/07	
Siemens	KI30M441/05	
Siemens	KI30M440/04	
Siemens	KI24M440GB/02	
Bosch	KIE30441/02	
Bosch	KIE30441/03	
Bosch	KIE30441/04	
Bosch	KIE30441/05	
Bosch	KIE30441/07	
Bosch	KIE30441/08	
Bosch	KIE30441CH/02	

Bosch	KIE30441CH/03	
Bosch	KIE30441CH/04	
Bosch	KIE30441CH/05	
Bosch	KIE30441FF/02	
Bosch	KIE30441FF/03	
Bosch	KIE30441FF/04	
Bosch	KIE30441FF/05	
Bosch	KIE30441TC/02	
Bosch	KIE30441TC/03	
Bosch	KIE30441TC/04	
Bosch	KIE30441TC/05	
Bosch	KIE30442NE/01	
Bosch	KIE30442NE/02	
Bosch	KIE30442NE/03	
Bosch	KIE30442NE/04	
Bosch	KIE30442NE/05	
Bosch	KIEKBT1/01	IKE269-52T
Bosch	KIEKBT1/02	IKE269-52T
Bosch	KIEKBY2/01	IKE308-5T2
Bosch	KIEKBY2/02	IKE308-5T2
Bosch	KIEKBY2/03	IKE308-5T2
Bosch	KIEKBY2/04	IKE308-5T2
Bosch	KIEKBY2/05	IKE308-5T2
Bosch	KIM2940/31	
Bosch	KIM2940/32	
Bosch	KIM30441/01	
Bosch	KIM30441/02	
Bosch	KIM30441/03	
Bosch	KIM30441/04	

Bosch	KIM30443GB/01	
Bosch	KIM30443GB/02	
Bosch	KIM30443GB/03	
Bosch	KIM30443GB/04	
Gaggenau	IC191230/03	
Gaggenau	IC191230/04	
Gaggenau	IC191230/05	
Gaggenau	IC191230/06	
Gaggenau	IC191230/07	
Gaggenau	IC191230/08	
Gaggenau	IC191230/31	
Gaggenau	IC191230/32	
Gaggenau	IC191230NE/03	
Gaggenau	IC191230NE/04	
Gaggenau	IC191230NE/05	
Gaggenau	IC191230NE/06	
Gaggenau	IC191230NE/31	
Gaggenau	IC191230NE/32	
Gaggenau	IC191930/01	
Gaggenau	IC191930/02	
Gaggenau	IC191930/03	
Gaggenau	IC192930/01	
Gaggenau	IC192930/02	
Gaggenau	IC192930/03	
Gaggenau	IC192930/04	
Gaggenau	IC192930/05	
K?ppersbusch	KIM24441/01	IKE159-4
K?ppersbusch	KIM24441/02	IKE229-4
K?ppersbusch	KIM24441/03	IKE159-5

K?ppersbusch	KIM24441/04	IKE159-5
K?ppersbusch	KIM2540/31	IKE 159-6
K?ppersbusch	KIM2540/32	IKE229-4
Neff	K8614X0GB/31	
Neff	K8614X1GB/01	
Neff	K8614X1GB/02	
Neff	K9514X4/02	
Neff	K9514X4/03	
Neff	K9514X4/04	KG411
Neff	K9514X4GB/02	
Neff	K9514X4GB/03	
Neff	K9514X4GB/04	
Neff	K9524X4/02	
Neff	K9524X4/03	KG515
Neff	K9524X4/04	KG515
Neff	K9524X4GB/02	KG515
Neff	K9524X4GB/03	K8625
Neff	K9524X4GB/04	K8625
Neff	K9525X4GB/01	
Neff	K9525X4GB/02	
Neff	K9525X4GB/03	
Neff	K9525X4GB/04	
Neff	K9614X4/01	
Neff	K9614X4/02	
Neff	K9614X4/03	
Neff	K9614X4/04	
Neff	K9614X4/05	
Neff	K9615X0/03	KG425
Neff	K9615X0/31	KG425

Neff	K9615X0/32	KG425
Neff	K9615X1/01	KG425
Neff	K9615X2/01	KG425SC
Neff	K9624X4/01	
Neff	K9624X4/02	
Neff	K9624X4/03	
Neff	K9624X4/04	
Neff	K9624X4/05	
Neff	K9625X0/03	KG425
Neff	K9625X0/31	KG425
Neff	K9625X0/32	KG425
Neff	K9625X0GB/31	KG425
Neff	K9625X0RK/01	KG425SC
Neff	K9625X0RK/02	K9625
Neff	K9625X1/01	KG525
Neff	K9625X1GB/01	K9625
Neff	K9625X1GB/02	K9625
Neff	K9625X1RK/01	K9625
Neff	K9625X2/01	KG525
Neff	K9625X2/02	KG525
Neff	K9625X2RK/01	K9625
Neff	K9625X3GB/01	
Neff	K9625X4RK/01	
Neff	K9625X4RK/02	
Neff	K9625X4RK/03	
Neff	K9625X4RK/04	
Neff	K9625X4RK/05	
Neff	KI26E40CH/32	
Neff	KI26E440/01	

Siemens	KI25M40/31	
Siemens	KI25M40/32	
Siemens	KI26E40/03	
Siemens	KI26E40/31	
Siemens	KI26E40/32	
Siemens	KI26E40CH/03	
Siemens	KI26E40CH/31	
Siemens	KI26E440/02	
Siemens	KI26E440/03	
Siemens	KI26E440/04	
Siemens	KI26E440/05	
Siemens	KI26E440/06	
Siemens	KI26E440CH/01	
Siemens	KI26E440CH/02	
Siemens	KI26E440CH/03	
Siemens	KI26E440CH/04	
Siemens	KI26E440CH/05	
Siemens	KI26E440CH/06	
Siemens	KI26ES40/01	
Siemens	KI26ES40/02	
Siemens	KI26M40GB/31	
Siemens	KI29M40/31	
Siemens	KI29M40/32	
Siemens	KI30E40/03	
Siemens	KI30E40/31	
Siemens	KI30E40/32	
Siemens	KI30E40CH/03	
Siemens	KI30E40CH/31	
Siemens	KI30E40CH/32	

Siemens	KI30E40GB/31	
Siemens	KI30E40GB/32	
Siemens	KI30E40IE/03	
Siemens	KI30E40IE/31	
Siemens	KI30E40IE/32	
Siemens	KI30E40NE/03	
Siemens	KI30E40NE/31	
Siemens	KI30E40NE/32	
Siemens	KI30E40RK/01	
Siemens	KI30E40RK/02	
Siemens	KI30E440/01	
Siemens	KI30E440/02	
Siemens	KI30E440CH/01	
Siemens	KI30E440CH/02	
Siemens	KI30E440FF/01	
Siemens	KI30E440IE/01	
Siemens	KI30E440IE/02	
Siemens	KI30E440NE/01	
Siemens	KI30E440NE/02	
Siemens	KI30E440RK/01	
Siemens	KI30E440RK/03	
Siemens	KI30ES40/01	
Siemens	KI30ES40/02	
Siemens	KI30ES40/03	
Siemens	KI30ES40/04	
Siemens	KI30M40/31	
Siemens	KI30M40/32	
Siemens	KI30M40GB/31	
Siemens	KI30M440/01	

Siemens	KI30M440/02	
Siemens	KI30M440GB/01	
Siemens	KI30M440GB/02	