

**Dream It.
Furnish It.
Love It.**

[WOODEN CHAIR] Instruction Manual

WOODEN CHAIRS

A good dining chair is a keeper of memories.
It witnesses the everyday and the extraordinary:

 Quiet solo breakfasts.

 Celebrations that stretch late into the night.

 First dates.

 Anniversaries.

 Family traditions that will outlive us.

Crafted with care, designed for comfort —

 its proportions invite a natural posture.

Its textures —wood, leather, woven fiber, soft upholstery
 — speak of warmth and tactility.

Its silhouette complements your space, be it minimalist, rustic, or
modern — always elevating the experience of gathering.

Close your eyes. Picture your dining room.

Not just a table, not just chairs — but a stage for life's most
 beautiful moments.

Your dining chair is a silent companion to them all.

When you choose a dining chair,
you are not choosing furniture.

 You are choosing a feeling:

 The joy of welcome.

 The art of lingering.

 The embrace of connection.

- the art of stillness

Contents/Inhalt

01

(English)

<i>Parts list</i>	1
<i>Installation</i>	2-3
<i>Overview</i>	4
<i>Notice</i>	5
<i>Maintenance</i>	6-7

02


(Deutsch)

<i>Teileliste</i>	8
<i>Installation</i>	9-10
<i>Überblick</i>	11
<i>Beachten</i>	12
<i>Wartung</i>	13-14

<i>Photos/Fotos</i>	15-16
---------------------	-------


Parts List

(EN)

	A	backrest	x1
	B	seat	x1
	C	legs	x2
	D	base	x1
	E	rung	x1
	F	screws M6*50	x2
	G	screws M8*60	x4
	H	flat washers M6*14	x2
	I	flat washers M8*17	x4
	J	hex key	x1


Installation

(EN)



STEP 1

- Align the holes of the wooden legs(C) and the base(D) (Please note that the wide side is on the outside)
- Put 4 screws(G) and 4 washers(I) on the corresponding holes
- Tighten them with a hex key(J).



STEP 2


- Use 2 screws(F) and 2 washers(H) to connect the crossbar(E) and the two wooden legs
- Tighten them with a hex key(J)



Do not tighten the screws if they are not aligned with the holes!


Installation

(EN)



STEP 3

- *Front view after installation*
- *Please note that the wide side is on the outside*



STEP 4

- *Finally, place the backrest(A) and seat cushion(B) directly on the assembled wooden frame.*



Do not tighten the screws if they are not aligned with the holes!



Description:

This stylish lounge chair draws inspiration from mid-century modern design, blending retro charm with contemporary sensibilities. Its clean, curved lines and bold, yet simple structure evoke a sense of elegance and comfort.

Constructed from durable rubber wood and multi-layered plywood, this chair is built to last. The cushioning is made from soft, supportive foam, covered in a textured fabric that adds an inviting touch of coziness to the design. The solid wood frame is finished in a sleek black color, providing a modern contrast that enhances the chair's visual appeal while maintaining strength and stability.

This chair is perfect for a variety of settings, from the living room to an office space, or even a reading nook. Its stylish appearance makes it an ideal accent piece in a modern home, and the comfortable cushioning ensures it's more than just visually pleasing. Whether used as a standalone chair or paired with other furniture, it adds sophistication and relaxation to any space.

Material:

- Frame: rubber wood
 - Seat/Backrest: plywood+foam+fabric
-

Notice

(EN)

- Please use the chair after you are fully familiar with the usage and operation.
- Please don't play on the chair.
- Please use the product correctly. It is prohibited to stand or lie on the product, and it is strictly prohibited to use it for other purposes such as ladders.
- This product can only be used when all screws and parts are tightened. Check the tightening screws and parts at least every three months.
- If any part is missing, damaged or worn, please stop using the chair, and use the accessories provided by us to repair or contact after-sales service.
- This product is designed for one person, and only one person can use it at a time.
- Please keep the chair away from fire.



Furniture should be arranged to avoid touching walls or heat sources to prevent damage from heat and moisture. As a general rule, it is recommended to lightly vacuum the furniture every week to get rid of dirt, dust, hair etc. and rotating reversible cushions frequently. Adding this simple step to your cleaning process will extend the life of your furniture significantly. Colours on textiles are also prone to light fading. Exposure to direct sunlight will damage fibres as well as dull colours, over time this will make the fibres brittle and cause them to break. Avoid direct sun where possible or hang protective curtains.

1) Piling

Piling may occur as a result of normal everyday use. It is a natural occurrence when loose fibres on the surface begin to twist. Pilling can be removed with a small, electric 'de-piller' and will not damage the fabric.

2) Overall cleaning

- How often your furniture needs cleaning will depend on your personal use and household. As a general recommendation most family room furniture should receive proper cleaning every 12 months. With furniture that sees 'normal wear', a yearly cleaning will preserve and enhance wool or woolblend upholstery.
 - Furniture that might be near food and beverages may need to be cleaned more often, as well as ones used by children and pets.
 - It is important to make sure you use the right cleaners for your upholstery as the wrong one might cause fading, staining etc.
 - Only use products designed for upholstery, and avoid any cleaners made for hard surface cleaning like ammonia, soap or bleach.
 - Some fabrics and covers can be washed in the washing machine, however this depends on the type of textile and the backing used.
 - If unsure, always use a cold wash cycle and non-dyed detergent.
 - Avoid dryers.
-

3) Spills and stains

With small spills and stains, time is of essence and spot cleaning should be the first step. Most stains can be avoided if treated right away.

Most stains can be cleaned with water, upholstery shampoo or a suitable spot cleaner. Do not leave stains to dry as this will make them harder to clean. Wipe up any excess liquid or solids, and with the right product work from the edge of the stain inwards to avoid spreading.

4) Spot cleaning

If you do not have a stain remover, here are some recommendations on how to deal with the most common stains:

- **INK** - Moisten with warm glycerine. Leave for 10 minutes. Apply liquid detergent and brush lightly. Blot with water and dry quickly. Upholstery shampoo can also be used for this.
- **ALCOHOLIC BEVERAGES** - After the moisture has been blotted up, dab at the stain with a clean cloth dampened in rubbing alcohol. Then blot repeatedly with liquid detergent mixed with cool water. Blot dry with a towel. Dab again with clear cool water and blot dry.
- **COFFEE/TEA** - Sponge with warm water. Apply warm glycerine. Leave for 30 minutes. Flush out with water and dry quickly.
- **BLOOD** - After the moisture has been blotted up, dab at the stain with a clean cloth dampened in rubbing alcohol. Then blot repeatedly with liquid detergent mixed with cool water. Blot dry with a towel. Dab again with clear cool water and blot dry.
- **CHEWING GUM** - Rub an ice cube over the gum to harden it, then scrape off the excess with a dull knife. To remove what's left, use dry cleaning fluid.


Teileliste

(DE)

	A	Rückenlehne	x1
	B	Sitz	x1
	C	Beine	x2
	D	Base	x1
	E	Sprosse	x1
	F	Schrauben M6*50	x2
	G	Schrauben M8*60	x4
	H	Unterlegscheiben M6*14	x2
	I	Unterlegscheiben M8*17	x4
	J	Sechskantschlüssel	x1


Installation

(DE)



SCHRITT 1

- Richten Sie die Löcher der Holzbeine (C) und der Basis (D) aus (die breite Seite muss außen liegen).
- Setzen Sie 4 Schrauben (G) und 4 Unterlegscheiben (I) in die entsprechenden Löcher ein.
- Ziehen Sie die Schrauben mit einem Inbusschlüssel (J) fest.




SCHRITT 2

- Verbinden Sie die Querstange (E) und die beiden Holzbeine mit 2 Schrauben (F) und 2 Unterlegscheiben (H).
- Ziehen Sie die Schrauben mit einem Inbusschlüssel (J) fest.




Ziehen Sie die Schrauben nicht fest, wenn sie nicht mit den Löchern fluchten!

SCHRITT 3



- Vorderansicht nach der Installation
- Bitte beachten Sie, dass die breite Seite außen liegt.



SCHRITT 4

- Zum Schluss werden die Rückenlehne (A) und das Sitzkissen (B) direkt auf den zusammengebauten Holzrahmen gelegt.



Ziehen Sie die Schrauben nicht fest, wenn sie nicht mit den Löchern fluchten!



Beschreibung:

Dieser stilvolle Lounge-Sessel ist vom Mid-Century-Modern-Design inspiriert und vereint Retro-Charme mit modernem Stil. Seine klaren, geschwungenen Linien und die markante, aber dennoch schlichte Struktur vermitteln ein Gefühl von Eleganz und Komfort.

Gefertigt aus robustem Gummibaumholz und mehrschichtigem Sperrholz, ist dieser Sessel besonders langlebig. Die Polsterung besteht aus weichem, stützendem Schaumstoff, bezogen mit einem strukturierten Stoff, der dem Design eine einladende, gemütliche Note verleiht. Das Massivholzgestell ist in elegantem Schwarz gehalten und bildet einen modernen Kontrast, der die Optik des Sessels unterstreicht und gleichzeitig Stabilität und Festigkeit gewährleistet.

Dieser Sessel eignet sich perfekt für verschiedenste Umgebungen, vom Wohnzimmer über das Büro bis hin zur Lesecke. Sein stilvolles Aussehen macht ihn zu einem idealen Akzentstück in einem modernen Zuhause, und die bequeme Polsterung sorgt dafür, dass er nicht nur optisch ansprechend ist. Ob als Einzelsessel oder in Kombination mit anderen Möbeln – er verleiht jedem Raum Eleganz und Entspannung.

Material:

- Rahmen: Gummibaumholz
 - Sitzfläche/Rückenlehne: Sperrholz + Schaumstoff + Stoff
-

- Bitte benutzen Sie den Stuhl erst, wenn Sie mit der Bedienung vertraut sind.
- Spielen Sie nicht mit dem Stuhl.
- Bitte verwenden Sie das Produkt ordnungsgemäß. Es ist verboten, auf dem Produkt zu stehen oder zu liegen. Die Verwendung für andere Zwecke, z. B. als Leiter, ist strengstens untersagt.
- Dieses Produkt darf nur verwendet werden, wenn alle Schrauben und Teile festgezogen sind. Überprüfen Sie die Schrauben und Teile mindestens alle drei Monate.
- Sollte ein Teil fehlen, beschädigt oder abgenutzt sein, verwenden Sie den Stuhl bitte nicht mehr und verwenden Sie zur Reparatur das von uns bereitgestellte Zubehör oder wenden Sie sich an den Kundendienst.
- Dieses Produkt ist für eine Person konzipiert und kann jeweils nur von einer Person verwendet werden.
- Bitte halten Sie den Stuhl von Feuer fern.



Möbel sollten so aufgestellt werden, dass sie keine Wände oder Wärmequellen berühren, um Schäden durch Hitze und Feuchtigkeit zu vermeiden. Generell empfiehlt es sich, die Möbel wöchentlich leicht abzusaugen, um Schmutz, Staub, Haare usw. zu entfernen, und Wendekissen häufig zu drehen. Dieser einfache Schritt in Ihrem Reinigungsprozess verlängert die Lebensdauer Ihrer Möbel erheblich. Farben auf Textilien neigen außerdem zum Verblasen durch Lichteinwirkung. Direkte Sonneneinstrahlung schädigt die Fasern und lässt die Farben verblassen. Mit der Zeit werden die Fasern dadurch spröde und brechen. Vermeiden Sie möglichst direkte Sonneneinstrahlung oder hängen Sie Schutzvorhänge auf.

1) Stapeln

Durch den normalen täglichen Gebrauch kann es zu Pilling kommen. Es ist ein natürliches Phänomen, wenn sich lose Fasern auf der Oberfläche verdrehen. Pilling lässt sich mit einem kleinen, elektrischen Entpiller entfernen, ohne den Stoff zu beschädigen.

2) Gesamtreinigung

- Wie oft Ihre Möbel gereinigt werden müssen, hängt von Ihrer persönlichen Nutzung und Ihrem Haushalt ab. Als allgemeine Empfehlung gilt, die meisten Wohnzimmersmöbel alle 12 Monate gründlich zu reinigen. Bei
- Möbeln, die „normaler Abnutzung“ ausgesetzt sind, schützt und verbessert eine jährliche Reinigung die Polsterung aus Wolle oder Wollmischung.
- Möbel, die sich in der Nähe von Lebensmitteln und Getränken befinden, müssen möglicherweise häufiger gereinigt werden, ebenso wie Möbel, die von Kindern und Haustieren benutzt werden.
- Es ist wichtig, dass Sie für Ihre Polsterung die richtigen Reiniger verwenden, da die falschen Reiniger zu Verblasen, Flecken usw. führen können. Verwenden Sie nur Produkte, die für Polstermöbel geeignet sind, und vermeiden Sie Reinigungsmittel für harte Oberflächen wie Ammoniak, Seife oder Bleichmittel.
- Einige Stoffe und Bezüge können in der Waschmaschine gewaschen werden, dies hängt jedoch von der Textilart und dem verwendeten Träger ab.
- Im Zweifelsfall immer Kaltwaschgang und farbstofffreies Waschmittel verwenden.
- Trockner vermeiden.

3) Verschüttetes und Flecken

Bei kleinen Verschüttungen und Flecken ist Zeit entscheidend, daher sollte die Fleckenreinigung der erste Schritt sein. Die meisten Flecken lassen sich durch sofortige Behandlung vermeiden.

Die meisten Flecken lassen sich mit Wasser, Polstershampoo oder einem geeigneten Fleckenreiniger entfernen. Lassen Sie Flecken nicht eintrocknen, da sie sonst schwerer zu entfernen sind. Wischen Sie überschüssige Flüssigkeiten oder Feststoffe auf und arbeiten Sie mit dem richtigen Produkt vom Rand des Flecks nach innen, um eine Ausbreitung zu vermeiden.

4) Fleckenreinigung

- Wenn Sie keinen Fleckenentferner haben, finden Sie hier einige Empfehlungen zum Umgang mit den häufigsten Flecken:
- **TINTE** - Mit warmem Glycerin befeuchten. 10 Minuten einwirken lassen. Flüssigwaschmittel auftragen und leicht bürsten. Mit Wasser abtupfen und schnell trocknen. Auch Polstershampoo kann verwendet werden.
- **ALKOHOLISCHE GETRÄNKE** - Nachdem Sie die Feuchtigkeit aufgesaugt haben, tupfen Sie den Fleck mit einem sauberer, in Reinigungsalkohol getränkten Tuch ab. Tupfen Sie ihn anschließend wiederholt mit flüssigem Reinigungsmittel und kaltem Wasser ab. Tupfen Sie ihn mit einem Handtuch trocken. Tupfen Sie ihn erneut mit klarem, kaltem Wasser ab und tupfen Sie ihn trocken.
- **KAFFEE/TEE** - Mit warmem Wasser abtupfen. Warmes Glycerin auftragen. 30 Minuten einwirken lassen. Mit Wasser ausspülen und schnell trocknen.
- **BLUT** - Nachdem Sie die Feuchtigkeit aufgesaugt haben, tupfen Sie den Fleck mit einem sauberer, in Reinigungsalkohol getränkten Tuch ab. Tupfen Sie ihn anschließend wiederholt mit Flüssigwaschmittel und kaltem Wasser ab. Tupfen Sie ihn mit einem Handtuch trocken. Tupfen Sie ihn erneut mit klarem, kaltem Wasser ab und tupfen Sie ihn trocken.
- **KAUGUMMI** - Reiben Sie den Kaugummi mit einem Eiswürfel, um ihn zu härtten, und kratzen Sie anschließend den Überschuss mit einem stumpfen Messer ab. Um die Reste zu entfernen, verwenden Sie Trockenreinigungsmittel.

Photos/Fotos





**Dream It.
Furnish It.
Love It.**

If you have any questions, please do not hesitate to contact us.