ALPENBEARS

Hinweise zum Gebrauch

15699

DEUTSCH

Sehr geehrte Kundin, sehr geehrter Kunde,
wir freuen uns, dass Sie sich für diese **ALPENBEARS Wanderstöcke** entschieden haben. Sollten Sie Fragen zum Produkt haben, kontaktieren Sie den Kundenservice über unsere Webseite: **www.ds-group.de/kundenservice**

Lieferumfang



A Wanderstock (3-teilig), 2 x
B Schneeteller, 2 x
C Schlammteller, 2 x
D Gummipuffer (Asphalt), 2 x
E Gummipuffer (Asphalt/Speed), 2 x
F Gummipuffer (Asphalt/Gelände), 2 x
- Tragetasche, 1 x
- Hinweise zum Gebrauch, 1 x

Den Lieferumfang auf Vollständigkeit und Transportschäden überprüfen. Bei Schäden nicht verwenden, sondern den Kundenservice kontaktieren. Eventuelle Folien, Aufkleber oder Transportschutz abnehmen. **Niemals eventuelle Warnhinweise entfernen!**

Wichtige Hinweise

- Das Produkt ist zur Verwendung als Wanderstöcke bestimmt.
- Das Produkt ist für den privaten Gebrauch, nicht für eine gewerbliche Nutzung bestimmt.
- Nur für den angegebenen Zweck und nur wie in den Hinweisen zum Gebrauch beschrieben nutzen. Jede weitere Verwendung gilt als bestimmungswidrig.
- Das Produkt schützen vor Feuer und lang anhaltender Feuchtigkeit.

Vorbereitung

Vor dem ersten Gebrauch

Je Wanderstock:
1. Verriegelung aufklappen.
2. Stock-Segmente ineinander stecken und **mindestens bis zur STOP-Markierung** zusammenschieben.
3. Verriegelung zuklappen.

Länge einstellen

1. Verriegelungen aufklappen.
2. Länge einstellen. Dabei die **Segmente maximal bis zur STOP-Markierung auseinander ziehen.** Zum Ermitteln der passenden Länge gibt es 2 Möglichkeiten:
   a) Anhand der Größentabelle:

Körpergröße (inkl. Schuhsohle)	**Stocklänge** (je Segment)
< 150 cm	100 cm
151 – 158 cm	105 cm
159 – 165 cm	110 cm
166 – 172 cm	115 cm
173 – 180 cm	120 cm
180 – 187 cm	125 cm
188 – 195 cm	130 cm
> 195 cm	135 cm

   b) Nach Körpergefühl bzw. Augenmaß. Dabei darauf achten, dass die **Arme** bei Gebrauch einen **rechten Winkel** bilden.
3. Verriegelungen mit **leichtem Druck** schließen. Dann mit dem Körpergewicht auf dem Stock abstützen. Der Stock darf sich bei Belastung **nicht** zusammenschieben. Die Hinweise im Abschnitt „Verriegelung prüfen und einstellen“ beachten.

Verriegelung prüfen und einstellen

Falls sich eine Verriegelung nur mit großem Kraftaufwand schließen lässt oder falls sich ein Stock bei Belastung zusammenschiebt, die nachfolgenden Schritte durchführen:
1. Verriegelung lösen.
2. Zugehörige Einstellschraube drehen:
   - **Verriegelung schließt schwergängig:** Gegen den Uhrzeigersinn drehen.
   - **Stock schiebt sich zusammen:** Im Uhrzeigersinn drehen.
3. Verriegelung schließen und Stock belasten. Bei Bedarf die Schritte erneut durchführen.

Aufsätze wechseln

- **Gummipuffer:** Mit leichtem Druck auf die Stockspitze stecken.
  Zum Entfernen vom Stock abziehen.
- **Teller:** Mit der **gewölbten Seite nach oben** auf die Stockspitze schieben. Anschließend **handfest** bis zum Anschlag festschrauben.
  Zum Entfernen abschrauben und abziehen.

Handschlaufe einstellen

1. Stopper lösen: Unteres Band senkrecht nach unten ziehen.
2. Länge einstellen.
3. Stopper festziehen: Am unteren **Schlaufenband** ziehen.

Reinigung und Aufbewahrung

Beachten

- Zum Reinigen des Produkts keine ätzenden oder scheuernden Reinigungsmittel verwenden.
- Wanderstöcke **nicht** schmieren oder ölen.

1. Verriegelungen lösen und Segmente auseinanderziehen.
2. Mit einem feuchten Tuch abwischen.
3. Vor dem Zusammenbauen vollständig trocknen lassen oder abtrocknen.

- Bei Nichtgebrauch für Kinder und Tiere unzugänglich aufbewahren.
- Vor längerem Nichtgebrauch die Verriegelungen öffnen.

Entsorgung

Das Verpackungsmaterial umweltgerecht entsorgen und der Wertstoffsammlung zuführen. Auch das Produkt umweltgerecht entsorgen.

Die Abfallvermeidung leistet einen noch wertvolleren Beitrag zum Umweltschutz. Sofern möglich, ist daher neben einer weiteren eigenen Nutzung auch die Abgabe an Zweitnutzer eine ökologisch wertvolle Alternative zur Entsorgung.

Produktdaten

Artikelnummer: 15699

Maße (ca.): min. 65 cm
max. 135 cm

ID Hinweise zum Gebrauch: Z 15699 M DS V1 0825 as

DS Produkte GmbH, Stormarnring 14,
22145 Stapelfeld, Deutschland

Kundenservice

Am Heisterbusch 1, 19258 Gallin, Deutschland

✆ +49 38851 314650 *)

kundenservice@dspro.de

*) Anruf in das deutsche Festnetz zum Tarif Ihres Anbieters.

Alle Rechte vorbehalten.

ALPENBEARS

Instructions for Use

15699

ENGLISH

Dear Customer,

We are delighted that you have chosen these **ALPENBEARS hiking poles**. If you have any questions about the product, contact the customer service department via our website:

www.ds-group.de/kundenservice

Items Supplied



A Hiking pole (3-piece), 2 x
B Snow plate, 2 x
C Mud plate, 2 x
D Rubber bumper (asphalt), 2 x
E Rubber bumper (asphalt/speed), 2 x
F Rubber bumper (asphalt/terrain), 2 x
G Mounting clip, 2 x
- Carrying bag, 1 x
- Instructions for use, 1 x

Check the items supplied for completeness and transport damage. If you find any damage, do not use the product but contact our customer service department. Remove any possible films, stickers or transport protection from the power tool. **Never remove possible warnings!**

Important Notices

- The product is intended for use as hiking poles.
- The product is for personal use only and is not intended for commercial applications.
- Use only for the specified purpose and as described in the instructions for use. Any other use is deemed to be improper.
- Protect the product from fire and prolonged exposure to moisture.

Preparation

Before first use

For each hiking pole:

1. Open the locks.
2. Insert the pole segments into each other and push them together **at least up to the STOP mark**.
3. Close the locks.

Adjusting the length

1. Open the locks.
2. Adjust the length. **Do not pull the segments apart any further than the STOP mark.** There are two ways to determine the correct length:
   a) Using the size chart:

Body height (incl. shoe sole)	**Pole length** (per segment)
< 150 cm	100 cm
151 – 158 cm	105 cm
159 – 165 cm	110 cm
166 – 172 cm	115 cm
173 – 180 cm	120 cm
180 – 187 cm	125 cm
188 – 195 cm	130 cm
> 195 cm	135 cm

   b) According to body feeling or eye measurement. Make sure that the **arms** form a **right angle** when in use.
3. Close the locks with **light pressure**. Then lean on the pole with your body weight. The pole must **not** collapse when loaded. Follow the instructions in the "Checking and Adjusting the Locks" section.

Checking and Adjusting the Locks

If a lock can only be closed with great force, or if a pole collapses under load, perform the following steps:

1. Release the lock.
2. Turn the corresponding adjustment screw:
   - **If a lock is difficult to close:** Turn counterclockwise.
   - **If a pole collapses:** Turn clockwise.
3. Close the lock and lean on the pole. Repeat the steps if necessary.

Changing the attachments

- **Rubber bumper:** Attach to the tip of the pole with light pressure.
  To remove, pull off the pole.
- **Plate:** Slide onto the pole tip with the **curved side facing up**. Then screw it on **hand-tight** until it stops.
  To remove, unscrew and pull off.

Adjusting the wrist strap

1. Release the stopper: Pull the lower strap vertically downwards.
2. Adjust the length.
3. Tighten stopper: Pull on the lower **loop strap**.

Cleaning and storage

Note

- Do not use any caustic or abrasive cleaning agents to clean the product.
- Do **not** lubricate or oil hiking poles.

1. Release the locks and pull the segments apart.
2. Wipe with a damp cloth.
3. Before assembly: Allow to dry completely or wipe dry.

- When not in use, keep the product out of the reach of children and animals.
- Before prolonged non-use: open the locks.

Disposal

Dispose of the packaging material in an environmentally friendly manner so that it can be recycled. Dispose of the product in an environmentally friendly manner as well.

Waste prevention makes an even more valuable contribution to protecting the environment. This means if possible, as well as continuing to use a product yourself, passing it on to another user also represents an ecologically beneficial alternative to disposal.

Product Data

Article number:	15699
Dimensions (approx.):	min. 65 cm max. 135 cm
ID instructions for use:	Z 15699 M DS V1 0825 as

DS Produkte GmbH, Stormarnring 14,
22145 Stapelfeld, Germany

Customer Service

Am Heisterbusch 1, 19258 Gallin, Germany

✆ +49 38851 314650 *)

kundenservice@dspro.de

*) Calls to German landlines are subject to your provider's charges.

All rights reserved.