












INSTRUCTION MANUAL



Master 50 SL



Master 50 SL
1xGU10



Master 50 SL2
2xGU10