

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Asko	438855	CC9658S
Asko	471114	CC9654S
Asko	494881	CC9634S
Asko	499065	CC9654S
Eskimo	342201	ESK6520CIXPOP
Eskimo	342214	ESK8520IXPOP
Eskimo	397587	ESK6530CIPOP
gorenje	228957	EC67553BX
gorenje	232273	EC67561AX-SW
gorenje	232278	EC7790E-SW
gorenje	232280	EC67551AX
gorenje	236828	BC7421AX
gorenje	236832	BC7306SX
gorenje	236851	BC7106SX
gorenje	236862	BC7121AX
gorenje	236863	BC7322BX
gorenje	239296	EC67351BX
gorenje	239300	EC67563BX-SW
gorenje	242674	BC7121AX
gorenje	245036	EC87551AX
gorenje	246163	BC7320SX
gorenje	249839	EC67328BX
gorenje	249840	EC67344BX
gorenje	250967	BC7328BX
gorenje	256816	BC5345BX
gorenje	256818	BC5348DX
gorenje	256820	BC7345BX
gorenje	256821	BC7349DX
gorenje	257759	EC67345BX
gorenje	257772	EC67346DX
gorenje	265952	EC67333AX
gorenje	265954	BC7446AX
gorenje	265955	BC7333AX
gorenje	265956	BC7333BX
gorenje	270128	EC66185BX
gorenje	270183	BC6320AX
gorenje	270185	BC6320BX
gorenje	270186	BC7483BX
gorenje	271636	BC7120ZX
gorenje	280793	BC7321PX
gorenje	297765	BC6306ZX
gorenje	298459	BC5301PX
gorenje	298461	BC5101-1PX
gorenje	313999	BC7111SX
gorenje	314001	BC7311SX

gorenje	335424	BC5306PX
gorenje	335426	BC5106PX
gorenje	337234	BC7457ZX
gorenje	345221	BC5332ZX
gorenje	357453	EC67320BX
gorenje	363298	BC536ZX
gorenje	380679	BC7322PX
gorenje	380680	BC7312SX
gorenje	382487	BC7121PX
gorenje	382488	BC7321PX
gorenje	393778	EC67337AXG
gorenje	415270	EC67151AX-SC
gorenje	439951	EC6306ZX
gorenje	452273	BC636X
gorenje	452276	BC636B
Körting	232215	KBC7128AX
Körting	232219	KBC7380AX
Körting	232269	KEC67320AXS
Körting	281012	KBC7380AX
Körting	281014	KBC7128AX
Körting	345427	KEC67337AXPOP
Körting	394080	KBC7120AXPOP
Mora	242570	MBC7303GX
Mora	332110	VTZ523GX
Mora	393460	VTZ523MX
privileg	301043	PCCF80211260X
privileg	236841	EH0150
privileg	428577	S6K244T2VU6I
privileg	236922	EH0600
privileg	236849	EH0650
privileg	428579	S6K236SVI
Sibir	276358	EH6300E