

Dual Battery Charger

2 Enduro Batteries Included HERO13 Black

This Dual Battery Charger conveniently charges two batteries dynamically to give you a fully charged battery as soon as possible¹ so you can keep adventuring.

Quick-check status lights let you know the batteries' charge status even when you're not plugged into power. Comes with two high-performance Enduro batteries that you can use as replacements or spares for HERO13 Black.



What's Included

- Dual Battery Charger
- 2 Enduro Batteries for HERO13 Black
- USB C-C Cable

Compatibility

- HERO13 Black

Dual Charger Features + Benefits



- Optimizes charging so you'll get a fully charged battery as quickly as possible¹
- Dual LEDs let you know the charge status of your camera batteries when inserted
- Battery quick check lets you see your batteries' charge status even when the charger is not plugged into power
- Extra-tall battery slots keep batteries more secure for travel
- Conveniently charges via USB-C port

Enduro Battery Features + Benefits



- Battery provides over 1.5 hours of continuous recording at 5.3K30, plus over 2.5 hours of continuous recording at 1080p30²
- Keeps your GoPro running even in below freezing temperatures down to 14°F (-10°C)
- Can be used as a replacement or spares for the battery that came with your HERO13 Black

LIMITED LIFETIME WARRANTY: GoPro warrants this product for its useful life (not to exceed two years for products with electrical or electronic components) against deficiencies in material and workmanship. This LIMITED LIFETIME WARRANTY does not cover products that are improperly used, abused, altered or repaired. Products found to be defective within the warranty period will be repaired or replaced at GoPro's discretion. GoPro reserves the right to make all determinations under this warranty. Products failing due to normal wear and tear, abuse or natural breakdown of materials over extended use and time may be repaired or replaced for a fee. For product support please visit gopro.com/help.

WARNING: Don't use the batteries if they have been damaged. Follow all warnings and instructions in the camera user manual.

¹ Use a 27 watt or greater USB-C adapter for optimal charging performance.

² Runtime measured at a temperature of 77°F (25°C) with a wind speed of 0.6m/sec with the Wide digital lens; wireless connections, Bluetooth and HyperSmooth on; front and rear LCD screens on with a 1-minute screensaver; voice control and GPS off.

See more at brand.gopro.com