



ASSEMBLY INSTRUCTIONS

HFSN-708


Ax1




Bx1




Cx1




Dx1




Ex1




Fx1




STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

