



D	Bitte überprüfen Sie in regelmäßigen Abständen den Festen Sitz der Schrauben!
GB	Please check the screws for tightness at regular intervals!
F	Veuillez contrôler régulièrement que les vis sont convenablement serrées !
ES	¡Compruebe periódicamente que los tornillos estén bien apretados!
IT	Controllare regolarmente che le viti siano ben strette!
PL	Malazj regularnie sprawdzac dokrecenie 5 rudi!
NL	Controleer op regelmatige afstanden of de schroeven goed vast zitten.
SWE	Kontrollera med jämna mellanrum att skruvarna sitter fast ordentligt!
SK	V pravidelných intervalech kontroľujte pevnú dotiahnutie skrutiek!
SL	Redno preverjajte, ali so vijaki trdno priviti!
HR	Redovito provjeravajte čvrsto naljezanje vijaka!

1	D	Vorderbeine	NL	Voorpoten
	GB	Front legs	SWE	Framben
	F	Pieds avant	SK	predné nohy
	RS	patas delanteras	SL	Sprednje noge
	IT	Gambe anteriori	HR	Prednje nožice
	PL	Nogi przednie		

2	D	Hinterbeine	NL	Achterpoten
	GB	Rear legs	SWE	Bakben
	F	Pieds arrière	SK	zadné nohy
	RS	patas traseras	SL	Zadnje noge
	IT	Gambe posteriori	HR	Straznje nožice
	PL	Nogi tylne		



DX1		EX1		A	M6*30mm	4
				B		4
				C		1